



Thermo Scientific S Series / X Series Centrifuges

Instructions for Use

50174277-b • 06 / 2026

Table of Contents

Preface

About this Manual	v
Where Do I Find Information about my Centrifuge?	v
Intended Use	v
Signal Words and Symbols	vii
Symbols Used on the Unit and Its Accessories	vii
Symbols Used in the Instructions for Use	ix
Safety Instructions	x

1. Transport and Set Up

1. 1. Unpacking	1-1
1. 2. Location	1-1
1. 3. Transporting	1-2
1. 4. Product Overview	1-7
1. 5. Connections	1-11
1. 6. Initial Startup	1-11

2. Operation

2. 1. Position of parts	2-1
2. 2. Power on/off the Centrifuge	2-4
2. 3. Open/Close the Centrifuge Lid	2-5
2. 4. How to Install and Remove a Rotor	2-5
2. 5. Load the Rotor	2-7

2. 6. Identify Rotor and Buckets	2-10
2. 7. Set Basic Centrifugation Parameters	2-11
2. 8. Pre-Temper the Centrifugation Chamber	2-11
2. 9. Centrifugation	2-11
2. 10. Aerosol-Tight Applications	2-13

3. Graphical User Interface

3. 1. Overview	3-1
3. 2. Set Basic Centrifugation Parameters	3-6
3. 3. Pre-Temper the Centrifugation Chamber	3-11
3. 4. Centrifugation	3-12
3. 5. Status, Alarms and Alerts	3-14
3. 6. Settings	3-29
3. 7. Display	3-41
3. 8. Logs	3-44

4. LCD Control Panel

4. 1. Overview	4-1
4. 2. Set Basic Centrifugation Parameters	4-2
4. 3. Programs	4-6
4. 4. Centrifugation	4-6
4. 5. Stop an Ongoing Centrifugation Run	4-7
4. 6. System Menu	4-8

5. Maintenance and Care

5. 1. Cleaning Intervals	5-1
5. 2. Basics	5-1
5. 3. Cleaning	5-2
5. 4. Disinfection	5-4
5. 5. Decontamination	5-4
5. 6. Autoclaving	5-5
5. 7. Maintenance	5-5
5. 8. Shipping	5-6
5. 9. Storage	5-6
5. 10. Disposal	5-6

6. Troubleshooting

6. 1. Mechanical Emergency Door Release	6-1
6. 2. Ice Formation	6-2
6. 3. Troubleshooting by Guide	6-2
6. 4. Information for the Customer Service	6-3

A. Technical Specifications

B. Rotor Specifications

C. Chemical Compatibility

Preface

Before starting to use the centrifuge, read through these instructions for use carefully and follow the instructions. The information contained in these instructions for use is the property of Thermo Fisher Scientific; it is prohibited to copy or pass on this information without explicit approval in writing by its owner.

Failure to follow the instructions and safety information in these instructions for use will result in the expiration of the seller's warranty.

About this Manual

This manual is subdivided into the following chapters:

- **Preface** (this chapter): Contains general introductory information, explains how to identify your centrifuge, spells out the intended use, explains the safety labels, and contains precautions.
- **Transport and Setup**: Contains the list of items supplied, explains how to transport the centrifuge to its intended location, how to connect power and Ethernet cables and how to accomplish the basic set-up.
- **Operation**: Contains instructions for centrifugation, including basic operations like loading and installing the rotor, entering centrifugation parameters, and running the centrifuge.
- **Graphical User Interface**: Explains the touchscreen and its menus.
- **LCD Control Panel**: Explains the LCD display, its front-panel controls and its functions.
- **Maintenance and Care**: Explains how to perform basic care activities like cleaning, disinfection, decontamination of the centrifuge and its rotors, and explains which parts are suitable for autoclaving. Also lists regular maintenance tasks like visual inspection, ventilation grid cleaning, and more specific maintenance tasks for selected rotor types, plus parts to be replaced by Thermo Fisher Scientific authorized service during preventive maintenance. And it contains general advice for storage and shipping.
- **Troubleshooting**: Explains how to use the emergency door release in order to open the centrifuge door when the device is out of power, how to remove icing from the centrifugation chamber, how to troubleshoot error messages that appear on the display, and how to gather device information before you call Thermo Fisher Scientific service.
- **Technical Specifications**: Lists the technical data for all centrifuge models described in this manual.
- **Rotors**: Contains rotor tables for all centrifuge models described in this manual as well as specifications and accessory information for all compatible rotors.
- **Chemical Compatibility Chart**: Contains a reference chart that indicates how centrifuge and rotor materials respond to attack through frequently-used chemical agents.
- **Index**: Lists keywords in alphabetical order, with pointers to pages where they occur.

Where Do I Find Information about my Centrifuge?

This manual covers multiple Thermo Scientific S Series and X Series centrifuge models.

You can identify your centrifuge model by gathering two items of information:

- the product series from the front panel—for example, Thermo Scientific X Series
- the product number and product name from the nameplate—for example, “75001042” and “Thermo Scientific X2T IVD-MD, 100–240 V” as shown in “List of Thermo Scientific Centrifuges” on page vii.

Intended Use

Intended Use for Laboratory Use Centrifuges

This centrifuge is designed to separate sample mixtures of different densities like chemicals, environmental samples and other non-human body samples.

Intended Use for IVD Centrifuges

This centrifuge can be used as IVD (In vitro diagnostic) laboratory equipment if used together with IVD tubes and IVD diagnostic analysis systems.

The centrifuge separates human blood. Blood is used in numerous diagnostic tests such as hematological screening (e.g. measurement of free hemoglobin), immunological screening (e.g. measurement of thrombocytes levels), cardio-vascular system assessment (e.g. analysis of potassium level).

Intended User

This centrifuge must be operated by trained personnel only.

Trained personnel can be a clinical laboratory technologist, a medical laboratory technician, or a person with an equivalent education.

Laboratory Use Centrifuges		
Article No.	Tabletop 4 L Centrifuge	Temperature Control
75007333	Thermo Scientific S4T 208–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007339	Thermo Scientific X4T 100 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007343	Thermo Scientific X4T 208–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007358	Thermo Scientific S4TR 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007363	Thermo Scientific X4TR 100 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007366	Thermo Scientific X4TR 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
Article No.	Tabletop 2 L Centrifuge	Temperature Control
75001041	Thermo Scientific S2T 100–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75001043	Thermo Scientific X2T 100–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75001046	Thermo Scientific S2TR 220–230 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75001039	Thermo Scientific X2TR 220–230 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75001049	Thermo Scientific X2TR 100 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
Article No.	Floorstanding 4 L Centrifuge	Temperature Control
75007354	Thermo Scientific S4FR 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007359	Thermo Scientific X4FR 100 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007362	Thermo Scientific X4FR 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated

In Vitro Diagnostics Centrifuges		
Article No.	Tabletop 4 L Centrifuge	Temperature Control
75007331	Thermo Scientific S4T IVD-MD* 120 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007332	Thermo Scientific S4T IVD-MD 208–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007340	Thermo Scientific X4T IVD-MD* 120 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007341	Thermo Scientific X4T IVD-MD 208–240 V $\pm 10\%$, 50 / 60 Hz	Ventilated
75007356	Thermo Scientific S4TR IVD-MD* 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007357	Thermo Scientific S4TR IVD-MD 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007364	Thermo Scientific X4TR IVD-MD* 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated
75007365	Thermo Scientific X4TR IVD-MD 120 / 208–240 V $\pm 10\%$, 50 / 60 Hz	Refrigerated

Article No.	Tabletop 2 L Centrifuge	Temperature Control
75001040	Thermo Scientific S2T IVD-MD 100–240 V $\pm$ 10%, 50 / 60 Hz	Ventilated
75001042	Thermo Scientific X2T IVD-MD 100–240 V $\pm$ 10%, 50 / 60 Hz	Ventilated
75001044	Thermo Scientific S2TR IVD-MD* 120 V $\pm$ 10%, 60 Hz	Refrigerated
75001045	Thermo Scientific S2TR IVD-MD 220–230 V $\pm$ 10%, 50 / 60 Hz	Refrigerated
75001047	Thermo Scientific X2TR IVD-MD* 120 V $\pm$ 10%, 60 Hz	Refrigerated
75001048	Thermo Scientific X2TR IVD-MD 220–230 V $\pm$ 10%, 50 / 60 Hz	Refrigerated
Article No.	Floorstanding 4 L Centrifuge	Temperature Control
75007352	Thermo Scientific S4FR IVD-MD* 120 / 208–240 V $\pm$ 10%, 50 / 60 Hz	Refrigerated
75007353	Thermo Scientific S4FR IVD-MD 120 / 208–240 V $\pm$ 10%, 50 / 60 Hz	Refrigerated
75007360	Thermo Scientific X4FR IVD-MD* 120 / 208–240 V $\pm$ 10%, 50 / 60 Hz	Refrigerated
75007361	Thermo Scientific X4FR IVD-MD 120 / 208–240 V $\pm$ 10%, 50 / 60 Hz	Refrigerated

* Compliant with US standards for centrifuges with flammable refrigerants

Table i: List of Thermo Scientific Centrifuges

Signal Words and Symbols

Signal Word and Colors	Degree of Hazard
WARNING	Indicates a hazardous situation that, if not avoided, could result in death or serious injury.
CAUTION	Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates information considered important, but not hazard-related.

Table ii: Signal Words and Symbols

Symbols Used on the Unit and Its Accessories

The symbols listed in the following caution users to observe the information contained in the instructions for use in order to keep themselves and their environment safe.

	This symbol refers to general hazards.. CAUTION means that material damage could occur. WARNING means that injuries or material damage or contamination could occur.		This symbol refers to hazards caused by flammable materials.
	This symbol refers to biological hazards.		This symbol refers to hazards from closing mechanical parts.
	This symbol refers to hazards from sharp items.		This symbol refers to hazards from cold surfaces on the centrifuge.



 eifu.thermofisher.com	This symbol refers to information on hazards, described within the manual.		This symbol on rotors and components refers to information on hazards, described within the manual.
	This symbol demands to disconnect mains before transporting or servicing the centrifuge.		This symbol shows the direction of rotation.
	Indicates that the device is not sterile.		Indicates the date after which the device is not to be used.
	Indicates the date when the device was manufactured.		Indicates the device manufacturer.
	Indicates the manufacturer's batch code so that the batch or lot can be identified.		Indicates the manufacturer's catalogue number so that the device can be identified.
	Indicates the manufacturer's serial number so that a specific device can be identified.		Indicates a device that is intended for one single use only.
	Indicates the need for the user to consult the instructions for use.		The crossed-out wheeled bin symbol indicates separate collection for EEE.
	Indicates a device that is intended to be used as an in vitro diagnostic medical device.		Indicates that the centrifuge can be operated alternatively on either 50Hz or 60Hz as the alternating current mains frequency.
	Indicates CE conformity.		UK Conformity Assessed Mark: Indicates conformity with the applicable requirements for products sold within Great Britain.
	Indicates conformity to Chinese environmental law.		Indicates conformity with Underwriter Laboratories (UL) requirements.
	Indicates conformity with Canadian Standards Agency (CSA) requirements.		Indicates the upper limit of temperature to which the product can be safely exposed to.
	Sterilizable in a steam sterilizer (autoclave) at the temperature specified.		Not sterilizable in a steam sterilizer (autoclave).
	Reminds you to ensure that the rotor is installed properly by lifting it slightly at the handle.		Floorstanding centrifuges: Cautions you to lock the castors before starting the centrifuge.

Table iii: Symbols Used on the Unit and Its Accessories

Symbols Used in the Instructions for Use

Observe the information contained in the instructions for use to keep yourself and your environment safe.

	General hazard		Electrical hazard
	Biological hazard		Danger of cuts
	Hazard caused by flammable materials		Hazard from cold surfaces in centrifuge
	Risk of crushing		Indicates information considered important, but not hazard-related.
	Wear protective gloves		Wear protective goggles

Table iv: Symbols used in the Instructions for Use

Safety Instructions



WARNING

Not following these safety instructions can lead to hazardous situations that, if not avoided, could result in death or serious injury.

Observe the safety instructions.

The centrifuge is to be used for its intended use only. Improper use can cause damages, contamination, and injuries with fatal consequences.

The centrifuge must be operated by trained personnel only.

It is the obligation of the operator to make sure that the proper protective clothing is used. Mind the “Laboratory Biosafety Manual” of the World Health Organization (WHO) and the regulations in your country.

Keep a safety zone of minimum 30 cm around the centrifuge. Refer to “Figure 1–1: Safety Zone”. Persons and hazardous substances must be kept out of this safety zone while centrifuging.

Do not modify the centrifuge and its accessories in any unauthorized way.

Do not operate a centrifuge if its housing is open or incomplete.



WARNING

Risk of damage due to incorrect power supply.

Make sure that the centrifuge is plugged only into a power outlet that has been properly grounded.



WARNING

Risk from handling hazardous substances.

When working with corrosive samples (salt solutions, acids, bases), the accessories and the centrifuge have to be cleaned thoroughly.

Extreme care should be taken with highly corrosive substances that can cause damage and impair the mechanical stability of the rotor. These should only be centrifuged in fully sealed tubes.

The centrifuge is neither inert nor protected against explosion. Never use the centrifuge in an explosion-prone environment.

Do not centrifuge toxic or radioactive materials or any pathogenic micro-organisms without suitable safety precautions.

When centrifuging any hazardous materials mind the “Laboratory Biosafety Manual” of the World Health Organization (WHO) and any local regulations. When centrifuging microbiological samples from the Risk Group II (according to the “Laboratory Biosafety Manual” of the World Health Organization (WHO)), aerosol-tight biological seals have to be used. Visit the internet page of the World Health Organization (www.who.int) for the “Laboratory Biosafety Manual”. For materials in a higher risk group, extra safety measures must be taken.

If toxins or pathogenic substances have contaminated the centrifuge or its parts, appropriate disinfection measures have to be taken (“Disinfection” on page 5-5).

If a hazardous situation occurs, turn off the power supply to the centrifuge and leave the area immediately.

Make sure to use the proper accessories for your applications to avoid hazardous contamination.

In any case of severe mechanical failure, such as rotor or bottle crash, personnel should be aware that the centrifuge is not aerosol-tight. Leave the room immediately. Contact the customer service. Aerosols need time to settle before opening the centrifuge after a crash. Ventilated centrifuges bear a higher risk of being contaminated after a crash than refrigerated centrifuges.



WARNING

Risk of contamination.

Potential contaminations will not remain in the centrifuge while the device is operated.

Take appropriate protection measures to prevent spread of contaminations.

A centrifuge is no closed containment.

**WARNING****Damage to health from centrifuging explosive or flammable materials or substances.**

Do not centrifuge explosive or flammable materials or substances.

**WARNING****Serious injuries can occur if you touch a spinning rotor with your hands or tools.**

A rotor can still be spinning after a power failure occurs.

Do not open the centrifuge before the rotor has stopped spinning. Do not touch a spinning rotor. Open the centrifuge only if the rotor has stopped spinning.

Never use your hands or tools to stop a spinning rotor.

The emergency door release may be used in emergencies only to recover the samples from the centrifuge, for example, during a power failure ("Mechanical Emergency Door Release" on page 6-1).

**WARNING**

The magnets built into the rotors can have a negative effect on active implants, such as cardiac pacemakers.

The magnets are mounted on the bottom of the rotor.

Always keep a distance of 20 cm between the rotor and the active implant, as the product generates permanent magnetic fields. The magnetic field strength at a distance of 20 cm is less than 0.1 mT, so there should be no interference.

**CAUTION****Risk of injuries from defective gas spring**

Make sure that the centrifuge door can be opened completely and that it will stay in its position.

Regularly check gas springs for their proper function.

Let an authorized service technician replace defective gas springs.

**CAUTION****Cutting injuries from broken display glass.**

Do not touch a damaged display.

**CAUTION****Safety can be impaired by wrong loading and worn accessories.**

Always make sure that the load is as equally distributed as possible.

Do not use rotors and accessories which show any signs of corrosion or cracks. Contact customer service for further information.

Do not operate the centrifuge with an unbalanced rotor. Use only rotors which have been loaded properly.

Never overload the rotor.

Make sure that rotors and accessories are installed properly before operating the centrifuge. Follow the instructions in section "How to Install and Remove a Rotor" on page 2-5.

**CAUTION****Physical harm caused by ignoring operative basics.**

Operate the centrifuge with a properly installed rotor.

Do not move the centrifuge while it is running.

Do not lean on the centrifuge.

Do not put anything on the centrifuge while it is running.

The centrifuge housing is not to be opened by the operator.

**CAUTION****Risk of accident while moving floorstanding centrifuge**

Assign at least two persons as handlers for moving a floorstanding centrifuge model. Instruct the handlers to push the centrifuge from both sides and stay out of the path of the moving centrifuge at all times.

**WARNING****Risk of overheating**

To avoid overheating of the centrifuge make sure that all ventilation openings are unobstructed at all times.

**WARNING****The centrifuge contains a flammable refrigerant under high pressure**

Do not tamper with the refrigerant circuits.

To avoid damage to or leaks in the refrigerant circuits and minimize the risk of possible ignition and fire:

- Handle and move the centrifuge with utmost care.
- Do not use heating devices, sharp or pointed tools or other mechanical devices to accelerate the defrosting process, other than those recommended by the manufacturer. Allow the ice to melt and clean up the residual liquid.
- Have the refrigerant circuits serviced by authorized service personnel and defective component parts replaced with original spare parts.
- In any case of severe mechanical failure, such as rotor or bottle crash, leave the room immediately. Flammable refrigerant might have leaked into the room. Ventilate the room.

**CAUTION****Due to air friction sample integrity may be affected.**

The temperature of the rotor may rise significantly while the centrifuge is spinning.

Ventilated units lead to a heat up of the rotor above the ambient temperature.

Refrigerated units can have a deviation from displayed and set temperature to the sample temperature.

Make sure the centrifuge temperature control capabilities meet your application specification. If necessary make a test run.

**NOTICE****In case of serious incident:**

Report any case of serious incident that has occurred in relation to the device to the manufacturer and your local authorities.

**NOTICE****Protection capability may be impaired due to using unapproved accessories.**

Use only accessories for this centrifuge which have been approved by Thermo Fisher Scientific. For a list of approved accessories refer to "Rotor Specifications" on page B-1.

Exceptions to this rule are commercially available glass or plastic centrifuge labware, provided they have been designed to fit in the rotor or the adapter cavities and are approved for the speed or the RCF value of the rotor.

**NOTICE****Damage to device or malfunction due to a damaged touch screen.**

Do not operate the device.

Power off the centrifuge. Disconnect the mains plug. Let an authorized service technician replace the touchscreen.

**NOTICE****To shut down the centrifuge:**

Press the "Stop" key. Turn off the centrifuge at the main switch. Pull out the power supply plug. In an emergency disconnect the power supply.

Make sure that the main switch and power supply plug can be accessed easily when setting up the centrifuge. The grounded electrical socket should be well accessible and located outside of the safety zone.

**NOTICE**

Working with the user interface of a floor-standing centrifuge is not ergonomic over the long term.

We recommend to use a seat if you are working on the user interface for long periods.



Maximum sound pressure of centrifuge operates below the hazard threshold of ≤ 70 dB(A) above a reference sound pressure of 20 μ Pa.

NOTICE

1. Transport and Set Up

NOTICE

It is your responsibility to ensure that all requirements are met for safety reasons.

1.1. Unpacking

The shipping carton should be inspected upon delivery. When received, carefully examine for any shipping damage before unpacking. If damage is discovered, the delivering carrier should specify and sign for the damage on your copy of the delivery receipt.

Open the carton carefully making certain that all parts (Table 1–1) are accounted for before packaging materials are discarded. Remove the packaging completely. After unpacking, if damage is found, report it to the carrier and request a damage inspection. Dispose of the packaging in accordance with local waste disposal regulations.

Failure to request an inspection of damage within a few days after receipt of shipment absolves the carrier from any liability for damage. You must call for a damage inspection.

Items Supplied

Please note that the centrifuge is supplied without a rotor. Rotors and items supplied with rotors are listed in the chapter “Rotor Specifications” on page B-1.

Item	Art. No.	Quantity
Thermo Scientific Centrifuge		1
Power Supply Cable		1
Printed Instructions for Use	50174277	1
Instructions for Use on USB drive	50174306	1
Anti-corrosion oil	70009824	1

Table 1–1: Items Supplied

If any parts are missing, please contact the nearest Thermo Fisher Scientific representative.

1.2. Location

Operate the centrifuge only indoors.

The set up location must meet these requirements:

- Keep a safety zone of minimum 30 cm around the centrifuge. Refer to “Safety Zone” on page 1-2.

Persons and hazardous substances must be kept out of this safety zone while centrifuging.

Centrifuges cause vibration. Do not store sensitive devices or dangerous objects or substances in the safety zone.

⚠ WARNING Risk of impact. The centrifuge can crush objects and persons in a radius of 30 cm while spinning. Keep a safety zone of 30 cm around the centrifuge for safe operation. Make sure that no one is in the safety zone while the centrifuge is spinning.

- The supporting structure must meet these requirements:

- » Be stable, solid, rigid and free of resonance.

- » Be applicable for horizontal set up of the centrifuge.

It is not allowed to put anything under the centrifuge to compensate for an uneven surface.

Do not operate the centrifuge on carts or stand-alone shelving that could move during operation or is inadequately sized for the centrifuge.

- » Be able to hold the weight of the centrifuge.

- The centrifuge is not equipped with any means for leveling. The supporting structure must be suitably level to allow proper set up.

⚠ CAUTION If you do not level the centrifuge, the centrifuge can crash because of imbalance. If you move the centrifuge, you must level it again. Do not move the centrifuge with a rotor attached to the drive shaft because damage can occur to the drive. Do not put anything below the centrifuge feet to level the centrifuge.

- Do not expose the centrifuge, accessories and samples to heat and strong sunlight.

⚠ CAUTION UV rays reduce the stability of plastics. Do not subject the centrifuge, rotors and plastic accessories to direct sunlight.

- The set up location must be well ventilated at all times.
⚠ **WARNING** Ensure that all ventilation openings of the centrifuge remain unobstructed at all times.
- The main switch and power supply plug must be easily accessible at all times. The grounded electrical wall socket should be well accessible and located outside of the safety zone.
⚠ **WARNING** The wall socket must not be installed in the safety zone.
- The room must have a minimum room volume of 16.25 m³.




Figure 1-1: Safety Zone

1. 3. Transporting

Before transporting a centrifuge make sure that

- the power supply cable is unplugged and removed from the centrifuge.
- the rotor is removed.
⚠ **CAUTION** Damage to centrifuge or drive shaft due to movement of an installed rotor. Always remove the rotor before you transport the centrifuge.
- the centrifuge door is closed.
⚠ **CAUTION** Hands can be squeezed by an open centrifuge door. Always close the centrifuge door before you transport the centrifuge.

Before transporting a rotor make sure that

- all components, like adapters and buckets are removed to prevent dropping damage.

1. 3. 1. Handling Tabletop Centrifuges

When handling a tabletop centrifuge make sure that

- the centrifuge is lifted at both sides and not at the front or back.




Figure 1-2: Lifting the Tabletop Centrifuge at Both Sides

⚠ WARNING Always lift the centrifuge on both sides. Never lift the centrifuge by its front or back. The centrifuge is heavy (see “Technical Specifications” on page A-1). Assign a minimum of 4 persons to lift and carry a refrigerated centrifuge. Assign a minimum of 2 persons to lift and carry a ventilated centrifuge.

1. 3. 2. Handling and Unpacking a Floorstanding Centrifuge

Floorstanding centrifuges come strapped to a custom-made shipping pallet. The pallet has angular stops on all four corners to prevent the centrifuge from rolling off. Supplied with each pallet is a pair of rails that serve as ramps for rolling off the centrifuge to level ground.

When moving a floorstanding centrifuge make sure that

- for long-haul transport, the centrifuge must be mounted on its original shipping pallet.
- for relocation on the premises, the castors and brakes of the centrifuge are fully functional.

⚠ CAUTION The centrifuge is heavy (see “Technical Specifications” on page A-1). Do not try to lift the centrifuge manually. To move the centrifuge using a forklift truck, strap it to its original shipping pallet. Never lift the centrifuge without the original shipping pallet.

⚠ WARNING Assign a minimum of 2 persons for moving the centrifuge. Instruct the handlers to push the centrifuge from both sides and stay out of the path of the moving centrifuge. A runaway centrifuge may crush a person in its path and inflict serious or lethal injury.




Figure 1-3: Space Required for Unloading

1. Place the pallet with the centrifuge so that you have at least 4 m of space in front of the pallet, as indicated by the cross-hatched area in Figure 1-3.




Figure 1-4: Removing the Outer Strapping and Packaging

2. Using a pair of scissors, cut and remove the outer strapping around the shipping package, as shown on the left side in Figure 1-4.
3. Using a screwdriver, remove the woodscrews (four times three pieces, as indicated in Figure 1-4 from the bottom of the cardboard box or wooden crate outer packaging.

4. Lift off the cardboard box or wooden crate, as shown on the right side in Figure 1-4.




Figure 1-5: Removing the Inner Strapping and Cardboard Protectors

5. Using a pair of scissors, cut and remove the second set of straps securing the centrifuge to the pallet, as shown on the left side in Figure 1-5.
6. Remove the two cardboard protectors from the top of the centrifuge, as shown on the right side in Figure 1-5.
7. Remove the shrinkwrap foil wrapped around the centrifuge.




Figure 1-6: Removing the Stops from the Pallet

8. Using a screwdriver, unscrew the woodscrews (two times two pieces, as indicated on the left side of Figure 1-6) from the angular stops on the rear corners of the pallet.
9. Remove the two rear stops from the pallet, as shown on the right side in Figure 1-6.




Figure 1-7: Mounting the Rails for Unloading

10. Locate the rails in the middle of the pallet underneath the centrifuge, as shown on the left side in Figure 1-7.
11. Using a screwdriver, remove the four woodscrews that secure the rails to the pallet. There are two screws on one side and two more screws on the opposite side of the rails that need to be removed.
12. Remove the rails from underneath the centrifuge and locate the numbers “1” and “2” on the rails and the pallet. These numbers indicate where you have to place the rail on the pallet.
13. Place each rail at its correct location just before the two rear castors of the centrifuge, as shown on the right side in Figure 1-7.
14. Make sure the rails are correctly positioned:
 - a. Rail “1” must be installed at position “1” of the pallet and rail “2” at position “2”.
 - b. The rails must be placed centered on the castors, so the castor wheels run exactly in the middle of each rail.
 - c. The pallet has a beveled edge. The end of the tab must rest on the beveled edge and be completely flush with the top surface of the pallet, as shown in Figure 1-7.
15. Using two of the leftover woodscrews, fasten each rail to the pallet, as shown on the right side in Figure 1-7.




Figure 1-8: Rolling the Centrifuge off the Pallet

16. Place one person on each side of the centrifuge, as shown in Figure 1-8.
- ⚠ CAUTION** Do not allow any persons in the path of the moving centrifuge. A runaway centrifuge may crush a person in its path and inflict serious injury.

17. Unlock the swiveling castors on the front side of the centrifuge by flipping up their locking levers, as shown in the rectangular box at the bottom center of Figure 1–7.
18. Have both persons grasp the rear corners of the centrifuge, so they can control the speed of the unit as it rolls down the ramp.
19. Push the centrifuge off the pallet and run it slowly down the rails, carefully controlling the speed until it reaches level ground.
20. Once the centrifuge has reached its intended location, lock the swiveling castors on the front side of the centrifuge to immobilize the centrifuge.

NOTICE

The swiveling castors can be identified by their brake levers. If you do not see the brake levers, turn the castors by 180 degrees so they stick out from under the front side of the centrifuge.




Figure 1–9: Locking the Centrifuge Castors

21. To lock the castors, step on the lever that sticks out from underneath the front side of the centrifuge, as shown in Figure 1–9.

1. 4. Product Overview


This chapter describes the locations of signal and power connectors, and the main power switch.

1. 4. 1. 2 L Refrigerated Tabletop Centrifuges

With Graphical User Interface (GUI)

Front

Back



Left


① USB; ② Ethernet; ③ RS-232; ④ Mains Connection; ⑤ Power Supply Switch

Figure 1-10: Product overview — refrigerated 2 L tabletop centrifuge with GUI

With LCD Control Panel

Front

Back



Left

① RS-232; ② Mains Connection; ③ Power Supply Switch


Figure 1-11: Product overview — refrigerated 2 L tabletop centrifuge with LCD control panel

1. 4. 2. 2 L Ventilated Tabletop Centrifuges

With Graphical User Interface

Front

Back




① USB; ② RS232; ③ Ethernet; ④ Mains Connection; ⑤ Power Supply Switch

Figure 1-12: Product overview — ventilated 2 L tabletop centrifuge with GUI

With LCD Control Panel

Front

Back



① RS232; ② Mains Connection; ③ Power Supply Switch

Figure 1-13: Product overview — ventilated 2 L tabletop centrifuge with LCD control panel

1. 4. 1. 4 L Refrigerated Tabletop Centrifuges

With Graphical User Interface (GUI)




Figure 1-14: Product overview — refrigerated 4 L tabletop centrifuge with GUI

With LCD Control Panel





Figure 1-15: Product overview — refrigerated 4 L tabletop centrifuge with LCD control panel

1. 4. 2. 4 L Ventilated Tabletop Centrifuges


With Graphical User Interface



① USB; ② RS232; ③ Ethernet; ④ Mains Connection; ⑤ Power Supply Switch

Figure 1-16: Product overview — ventilated 4 L tabletop centrifuge with GUI

With LCD Control Panel




① RS232; ② Mains Connection; ③ Power Supply Switch

Figure 1-17: Product overview — ventilated 4 L tabletop centrifuge with LCD control panel

1. 4. 3. 4 L Refrigerated Floorstanding Centrifuges

With Graphical User Interface (GUI)




① USB; ② Ethernet; ③ Mains Connection; ④ Power Supply Switch



Figure 1-18: Product overview — Refrigerated 4 L floorstanding centrifuge with GUI

With LCD Control Panel

Front



Back



Right

① RS232; ② Mains Connection; ③ Power Supply Switch

Figure 1-19: Product overview — Refrigerated 4 L floorstanding centrifuge with LCD control panel

1. 5. Connections

1. 5. 1. Mains Connection

NOTICE

Connect the centrifuge into grounded electrical sockets only.

Japanese-market 100V, 50/60Hz dual-frequency models

1. Turn off the Power Supply Switch.
2. Make sure that the power supply cable specification agrees with the safety standards of your country.
3. Make sure that the voltage and frequency are the same as the figures on the nameplate.
4. If you are installing a 100V, 50/60Hz dual-frequency model for the Japanese market, verify whether the AC mains frequency is set to 50Hz or 60Hz. The frequency selector switch is located on the left-hand side of the centrifuge and can be identified by the yellow 50/60Hz label attached next to it, as shown in Figure 1–20 below.
5. Insert a flat-blade screwdriver or other suitable tool into the slot next to the label and set the frequency selector switch to 50Hz or 60 Hz, as required by your AC mains supply.




Figure 1–20: AC mains 50/60Hz frequency selector switch

6. First plug the power supply cable into the mains socket of the centrifuge, then into the grounded electrical wall socket.
7. Make sure that the power supply cable is plugged in properly.

All other models

1. Turn off the Power Supply Switch.
2. Make sure that the power supply cable specification agrees with the safety standards of your country.
3. Make sure that the voltage and frequency are the same as the figures on the nameplate.
4. First plug the power supply cable into the mains socket of the centrifuge, then into the grounded electrical wall socket.
5. Make sure that the power supply cable is plugged in properly.

1. 5. 2. RS232

The centrifuge has a RS232 interface, which can be used to connect to a terminal device compliant with the following specifications: signal transmission according to TIA/EIA-232-F +- 10V, 10mA.

1. 5. 3. Ethernet

Some centrifuge models have a RJ45 Ethernet interface with Ethernet signal transmission according to the IEEE 802.3, without POE (Power Over Ethernet) specification. This interface port can be used to connect to a Local Area Network (LAN). Use only equipment conforming to the IEC 60950-1 standard with the RJ45 ethernet interface.

1. 5. 4. USB

Some centrifuge models have a USB-A 2.0 port (5 V / 1 A) for use with a USB drive. Use only equipment conforming to the USB 2.0 standard with this USB port.

1. 6. Initial Startup

Centrifuges with a graphical user interface (GUI)

In the initial startup sequence you must make some first settings:

- Language
- Unit Name
- City and Country
- Date Format
- Current Date


Complete these steps before using the unit. These settings can be changed again later. Refer to “Display” on page 3-42.

Centrifuges with a LCD control panel

LCD control panel centrifuges are factory setup using English as preset language. Settings can be changed later. Refer to “System Menu” on page 4-8.

2. Operation

2. 1. Position of parts



① Gas spring; ② Centrifugation chamber; ③ User Interface; ④ Centrifuge door; ⑤ Drive shaft

Figure 2-1: Position of centrifuge parts shown on a ventilated centrifuge with LCD control panel



① Rotor body; ② Cavity; ③ Rotor lid mounting

Figure 2-2: Position of rotor parts shown on a fixed angle rotor




① Slot; ② Key

Figure 2-3: Position of the slot in the bucket and the corresponding adapter key



① Bucket; ② Cap latch; ③ Bucket cap; ④ Rotor knob; ⑤ Auto-Lock button; ⑥ Rotor cross

Figure 2-4: Position of rotor parts shown on a swinging bucket rotor



① Rotor lid; ② Auto-Lock button; ③ Rotor lid knob; ④ Rotor cross with buckets within the windshield bowl; ⑤ Windshield bowl

Figure 2-5: Position of rotor parts shown on a windshielded swinging bucket rotor

2. 2. Power on/off the Centrifuge




Figure 2-6: Rear view of ventilated tabletop centrifuges, position of the mains switch




Figure 2-7: Side view of refrigerated tabletop centrifuge, position of the mains switch




Figure 2-8: Side view of floorstand centrifuge, position of the mains switch

To power on the centrifuge:

Push on the mains switch of the centrifuge to “1” to power it on.

When the centrifuge has completed booting it is ready for operation.

Once you have started running the centrifuge with your own parameters, it will show the settings from the last session after powering up.

To power off the centrifuge:

Set the mains switch of the centrifuge to “0” to power it off.

2. 3. Open/Close the Centrifuge Door

To open the centrifuge door:

Press the Door Open button  on the home screen of the GUI or  on the LCD control panel.

To close the centrifuge door:

Close the centrifuge door by pressing down on it lightly in the middle or on both sides. The locking mechanism engages to close the door safely. The door should audibly click into place.

Double-check whether the locking mechanism has engaged properly.

⚠ WARNING Do not reach into the gap between the door and the casing. The door is drawn shut automatically and may pinch your fingers.

⚠ WARNING Do not use the mechanical emergency door release as regular procedure to open the centrifuge. Use the mechanical emergency door release only if a malfunction or power failure occurs and only when you have made sure that the rotor has stopped spinning (see “Mechanical Emergency Door Release” on page 6-1).

2. 4. How to Install and Remove a Rotor

To install a rotor:

1. Press the Open button  on the home screen of the GUI or  on the LCD control panel to open the door of the centrifuge.
2. Place the rotor over the drive shaft and let it slide down slowly.
The rotor clicks into place automatically.
3. Make sure that the rotor is properly installed by lifting it slightly on the handle. If the rotor can be pulled up, then it must be reclamped to the drive shaft.
4. Make sure the rotor spins freely by turning it manually.
5. Swinging bucket rotors only: make sure that a full complement of buckets is installed before operating the rotor.
6. Rotor lid installation:
 - a. Put the rotor lid on the rotor.
Make sure the rotor lid is put centered on the rotor.




Figure 2-9: Put on/off the rotor lid

- b. Turn the rotor knob clockwise to close the rotor. Turn it counter-clockwise to open rotor.
There is no need to press the Auto-Lock key to close or open the rotor.



Figure 2-10: Turn the rotor knob

Before installing a rotor:

- Remove any dust, foreign objects or residue from the chamber, if necessary.
- Wipe the drive shaft and the rotor hub from the bottom side of the rotor with a clean cloth.
- Inspect the Auto-Lock and O-ring (Figure 2-12); both must be clean and undamaged.

To remove a rotor:

1. Press the Open button  on the home screen or  on the control panel to open the door of the centrifuge.
2. Remove samples, adapters or buckets.
3. Grasp the rotor handle with both hands.
4. Press the Auto-Lock key and, at the same time, pull the rotor directly upwards and away from the drive shaft with both hands. Make sure you do not tilt the rotor while lifting it.



Figure 2-11: Pressing the Auto-Lock key

⚠ CAUTION Do not force the rotor onto the drive shaft. If the rotor is very light, it may be necessary to carefully press it onto the drive shaft with little force.

⚠ WARNING If the rotor cannot be properly locked in place after several attempts, then the Auto-Lock is defective and you are not permitted to operate the rotor. Check for any damage to the rotor: Damaged rotors must not be used. Keep the drive shaft area of the rotor clear of objects.

⚠ CAUTION Make sure that the rotor is properly locked on the drive shaft before each use by pulling at its handle.

Supplementary Information



CAUTION

Unapproved or incorrectly combined rotors and accessories can cause serious damage to the centrifuge.

NOTICE

Some rotors may be too heavy to be handled by a single person. Assign a second person to assist when handling a heavy rotor. Refer to "Rotor Specifications" on page B-1 for the weight of a rotor.

The approved rotors are listed in the “Rotor Program” on page A-11. Operate the centrifuge only with rotors and accessories from this list. Make sure that all components of a rotor are safely fixed when carried.

The centrifuge is equipped with a Thermo Scientific™ Auto-Lock™ locking feature that automatically locks the rotor to the drive shaft.




Figure 2-12: Auto-Lock on the drive shaft

2. 5. Load the Rotor

2. 5. 1. Assembling TX-400 Round Buckets and Adapters

When running a 75003655 round bucket with a 75003683 or 75003682 adapter make sure that you assemble the bucket and adapter correctly.

The adapters have a rounded key feature that fits into a matching slot in the bucket. If the key is not in the slot, the bucket cap will not close properly and the centrifuge will not start and may cause damage to bucket, adapter and the sample.




Figure 2-13: Slot and Key on Paired Buckets and Rotors

2. 5. 2. Balance Loading

Load the compartments evenly. Balance opposite loads.

When using swinging bucket rotors mind the following in addition:

- Weigh the bucket content (adapter and tube). Make sure you do not exceed the maximum compartment load nor the weight difference limit for adjacent buckets if there is one for the rotor.
- Make sure to install all buckets if using swinging bucket rotors.
Make sure you install an identical bucket type in opposite positions.
- If in doubt, contact Thermo Fisher Scientific customer service.


Correct Loading ✓

Figure 2-14: Correct loading examples for fixed angle rotors




Figure 2-15: Correct loading examples for swinging bucket rotors


Incorrect Loading ✗

Figure 2-16: Incorrect loading examples for fixed angle rotors




Figure 2-17: Incorrect loading examples for swinging bucket rotors

Before loading a Rotor

1. Inspect the rotor and all accessory parts for damage, such as cracks, scratches, or traces of corrosion.
2. Inspect the centrifugation chamber, drive shaft and Auto-Lock device for damage, such as cracks, scratches, or traces of corrosion.
3. Check the suitability of the rotor and other used accessories against the Chemical Compatibility Chart. Refer to "Chemical Compatibility" on page C-1.
4. Make sure that:
 - » tubes or bottles fit in the rotor.
 - » the tubes or bottles do not touch the rotor lid or bucket caps.
 - » buckets or microplate carrier can swing freely by moving them carefully with your hand.

**CAUTION**

Incorrect loading can lead to damage. Always load the rotor symmetrically to avoid imbalance, noisy spinning and possible damage. A full complement of buckets needs to be installed before operating a swinging bucket rotor.

**CAUTION**

When using an aerosol-tight rotor lid or bucket caps, verify that the sample tubes don't interfere with the rotor lid or bucket cap and don't compromise its sealing efficiency.

**CAUTION**

Always use 2 identical bucket types in opposite positions. Make sure that opposite buckets are of the same weight class, if a weight class is labeled on the buckets.

**CAUTION**

Tubes may open and break during centrifugation because they do not fit properly to the cavities.
Contamination may occur.
Make sure that the length and width of the tubes are fitting into the adapter and cavities. Do not use tubes that are too short or too thick for the adapter and the cavities.

2. 5. 3. Maximum Loading

Each rotor is designed to run with its maximum load at maximum speed. The safety system of the centrifuge requires that the rotor is not overloaded.

The rotors are designed to work with substance mixtures with a density of up to 1.2 g/ml. If the admissible maximum load is exceeded, the following steps need to be taken:

- Reduce the fill level.
- Reduce the speed.

Use the following formula or the table given for each rotor in the chapter "Rotor Specifications" on page B-1 to calculate the maximum admissible speed for a given load:

$$n_{\text{adm}} = n_{\text{max}} \sqrt{\frac{w_{\text{max}}}{w_{\text{app}}}}$$

n_{adm} = admissible maximum application speed

n_{max} = maximum rated speed

w_{max} = maximum rated load

w_{app} = applied load

RCF Value Explained

The relative centrifugal force (RCF) is given as a multiple of the force of gravity (g). It is a unitless numerical value which is used to compare the separation or sedimentation capacity of various centrifuges, since it is independent of the type of device. Only the centrifuging radius and the speed are used for calculation:

$$\text{RCF} = 11,18 \times \left(\frac{n}{1000} \right)^2 \times r$$

r = centrifuging radius in cm

n = rotational speed in rpm

The maximum RCF value is related to the maximum radius of the tube opening.

Remember that this value is reduced depending on the tubes, buckets and adapters used.

This can be accounted for in the calculation above if required.

2. 5. 4. Use of Tubes and Consumables

Make sure that the tubes and bottles used in the centrifuge are:

- rated to or above the selected RCF to be spun at,
- used at their minimum fill volume and not above their maximum fill volume,
- not used above their design life (age or number of runs),
- undamaged,
- fitting well into the cavities.

Please refer to manufacturers' data sheets for further information.

2. 6. Identify Rotor and Buckets

The centrifuge has a rotor detection that identifies an installed rotor. If a swing-out rotor is identified **with a choice of buckets**, the centrifuge prompts you to identify the bucket type installed in that rotor.

Rotor detection relies on a list of rotors stored in the memory of the centrifuge. If an unknown rotor is detected, please contact customer service. An update for that rotor list might be available to accommodate new rotor models.

To identify a newly installed rotor and its buckets using a centrifuge with a GUI:

After installing the rotor, close the centrifuge door and start the centrifuge using the Start button ►. Wait for the "Rotor Detection" prompt to appear.




Figure 2-18: Rotor Detection: Choosing a Bucket Type for a TX-750 Rotor

- » Swinging bucket rotors with a choice of bucket types: Tap the **"buckets"** pop-up menu and choose the bucket type installed in your rotor.

If there is no need to confirm bucket type in the future—for example, because you use just one bucket type throughout, select the "Do not show this message again" checkbox.

This setting can be undone at any time using the "Bucket" setting, as explained in "Rotor Bucket" on page 3-41.

Tap the **Save** button to confirm your changes.

The rotor has been successfully detected, and the centrifuge is ready for use now.

The rotor detected by the centrifuge and the bucket type identified by the user appear.

If the rotor is unknown to the centrifuge, the "Unknown Rotor Detected" pop-up window will be shown. Tap the Cancel button to close this pop-up window, remove the unknown rotor, and replace it with a known type.

To identify buckets using a centrifuge with a LCD control panel:

Bucket selection is only possible for swing-out rotors. The bucket code corresponds to the last four digits of the bucket article number.

Rotors with only one bucket option do not require bucket code input. If one of the bucket keys is pressed, the message "No bucket to select" will appear on the display. The TX-1000, TX-400, TX-200, H-Flex1 and M-20 rotors do not require that you select a bucket code.

Proceed as follows to select the bucket type installed in the rotor:

1. Press the + or - button below the "Bucket" field of the LCD display window (see Figure 2-19) to select the correct bucket code for the buckets installed in your rotor.



Figure 2-19: Setting the Correct Bucket Code

2. Press the **Bucket** key repeatedly until the bucket code of the bucket being used is displayed.
3. Release the **+** or **-** button when the desired bucket code appears above the button.

Doing so selects the bucket code for future centrifugation runs (until the next time you choose to change this setting).

2. 7. Set Basic Centrifugation Parameters

NOTICE

For more details on settings refer to “Graphical User Interface” on page 3-1 or to “LCD Control Panel” on page 4-1.

Set Speed / RCF-Value

The centrifuge lets you set speed in rpm or as an RCF value (see “RCF Value Explained” on page 2-9). You may set speed either from within an ongoing centrifugation run (centrifuge running) or for the next centrifugation run (centrifuge at standstill).

Set Run Time

The centrifuge lets you set a run time after which the centrifugation run stops automatically.

Acceleration and Deceleration Profiles

The centrifuge offers a total of 9 acceleration profiles (numbered 1 through 9) and total of 10 deceleration profiles or braking curves (numbered 0 through 9) for centrifuging samples with a selected speed profile. An acceleration profile gradually increases the speed of the centrifuge after starting the centrifugation run. A deceleration profile gradually reduces the speed of the centrifuge towards the end of the centrifugation run.

NOTICE Avoid if possible speed ranges close to natural resonances of the system. Runs at resonance speeds may have show vibration and an adverse effect on the quality of separation.

Set Temperature

A refrigerated centrifuge allows for preselecting a temperature for the sample between -20 °C and +40 °C for the centrifugation run. If the ambient temperature is above 28 °C, the maximum set temperature is reduced to 25 °C. For ambient temperatures below 28 °C the full range of set temperatures is available (-20 to +40 °C). This feature is not available on ventilated models.

2. 8. Pre-Temper the Centrifugation Chamber

Refrigerated centrifuges allow for pre-tempering, that is pre-warming or pre-cooling, the centrifugation chamber and the empty rotor before the centrifugation run starts. If necessary pre-temper your samples using proper equipment. The centrifuge is not intended to be used to pre-temper your samples.

NOTICE Ventilated models cannot pre-temper the centrifugation chamber.

2. 9. Centrifugation



WARNING

Damage to health from centrifuging explosive or flammable materials or substances. Do not centrifuge explosive or flammable materials or substances.



CAUTION

Due to air friction sample integrity may be affected.
The temperature of the rotor may rise significantly while the centrifuge is spinning.
Ventilated units lead to a heat up of the rotor above the ambient temperature.
Refrigerated units can have a deviation from displayed and set temperature to the sample temperature.
Make sure the centrifuge temperature control capabilities meet your application specification. If necessary make a test run.

Mind the safety zone of minimum 30 cm around the centrifuge. Refer to “Safety Zone” on page 1-2. Persons and hazardous substances must be kept out of this safety zone while centrifuging.

When using a floorstanding centrifuge make sure the centrifuge castors are locked before starting centrifugation.

Once the main switch has been turned on, the rotor has been properly installed, the setpoints have been set as explained in the previous section, and the centrifuge door has been closed, you are ready to start.


You have various options to start a centrifugation run with a GUI:

- Continuous Mode: This is a fully manual mode. If you have chosen Continuous Mode instead of a preset runtime (see “Set Run Time” on page 3-8), use the Start button  and Stop button  to start and stop centrifugation manually, as explained in the section “Run in Continuous or Timed Mode” on page 3-13 further below.
- Timed Mode: This is a semi-automatic mode that relies on a timer. If you have preset a runtime (see “Set Run Time” on page 3-8), tap the Start button , then and wait for the timer to expire and the centrifuge to stop automatically, as explained in the section “Run in Continuous or Timed Mode” on page 3-13.
- Pulse Mode: This is a short-run centrifugation mode with selectable behaviors. You choose a behavior, then tap the Pulse button  and wait for the centrifuge to run and stop automatically, as explained in the section “Run in Pulse Mode” on page 3-14.
- Program Mode: This is a fully automatic mode. You prepare and save an automated program, then run it from the touchscreen, as explained in the section “Automate Processes Using Programs” on page 3-21.

NOTICE

For more details on settings refer to “Graphical User Interface” on page 3-1.

You have various options to start a centrifugation run with a LCD control panel:

- Continuous Mode: This is a fully manual mode. In Continuous Mode you use the **Start** key  and **Stop** key  to start and stop centrifugation manually, as explained in the section “Continuous Operation” further below.
- Timed Mode: This is a semi-automatic mode that relies on a timer. If you have preset a runtime (see “4. 2. 2. Set Run Time” on page 4-3), you press the **Start** key , then wait for the timer to expire and the centrifuge to stop down automatically.
- Program Mode: This is a fully automatic mode. You prepare and save an automated program, as explained in the section “Setting Up and Saving a Program” on page 4-6, then run it by pressing the appropriate program selection key .

NOTICE

For more details on settings refer to “LCD Control Panel” on page 4-1.

2. 10. Aerosol-Tight Applications

2. 10. 1. Basic Principles

Make sure that the sample containers are well suited for the desired centrifugation process.



CAUTION

Aerosol-tight rotors and tubes may only be opened in an approved safety work-bench when centrifuging dangerous samples. Mind the maximum permissible load.



CAUTION

Be sure to check all sealings before starting any aerosol-tight applications.

2. 10. 2. Fill Level

Do not fill the tubes beyond a safe level to prevent the sample from reaching the top of the tube during centrifugation. To be on the safe side, fill the tubes only to 2/3 of the rated level.

2. 10. 3. Aerosol-Tight Rotor Lids




Figure 2–20: Lid of an aerosol-tight rotor with mandrel

Placing O-ring

The O-ring fulfills its purpose best, when it is neither excessively stretched nor bulged. The O-ring shall be equally placed in the groove of the lid.

Place the O-ring as follows:

1. Place the O-ring above the groove.
2. Push the O-ring on two opposite places into the groove. Make sure the rest of the O-ring is equally distributed.
3. Push the centers of the loose parts into the groove.
4. Push the remaining O-ring into place.

⚠ NOTICE If the O-ring seems to be too long or too short, take it off the lid and repeat the process.



CAUTION

When using an aerosol-tight rotor lid, verify that the sample tubes do not interfere with the rotor lid and compromise its sealing efficiency.



CAUTION

Rotors supplied with a lid for aerosol-tight applications come with a mandrel as an accessory to the Auto-Lock device. Be sure not to place the lid on this mandrel. The lid may be damaged.

2. 10. 4. Aerosol-Tight Rotor Buckets

Aerosol-tight Closure with ClickSeal

1. If necessary, grease the lid joint before closing the lid. Use grease (76003500) for this.
2. Raise the latch.
The cap can now be easily placed on the bucket.
3. Lower the latch to close the bucket aerosol-tight; be sure the latch clicks into place.
Make sure that both sides of the latch are closing the bucket cap.




Figure 2-21: Bucket with open lid (left) and closed lid (right)



CAUTION

If the latch is not flipped down, the caps could be damaged during centrifugation. If the latch has not clicked into place, the bucket is not aerosol-tight. Never lift the bucket at its latch.



CAUTION

Make sure that the length of tubes used allow proper closing of the bucket cap. Otherwise the bucket will not be aerosol-tight.

2. 10. 5. Checking the Aerosol-Tightness

The aerosol-tightness testing of the rotors and buckets depends on the microbiological test process in accordance with the EN 61010-2-020 Appendix AA.

Whether or not a rotor is aerosol-tight depends primarily on proper handling.

Make sure that your rotor is aerosol-tight.

The careful inspection of the seals and seal surfaces for signs of wear and damage such as cracks, scratches and embrittlement is extremely important.

Aerosol-tight applications are not possible if the rotor is run without the lid.

Aerosol-tightness requires the correct operation when filling the sample vessels and closing the rotor lid.

Quick Test

As a quick test, it is possible to test the aerosol-tightness using the following process:

1. Lubricate all seals lightly.

Always use the special grease (76003500) when lubricating the seals.

2. Fill the bucket with approx. 10 ml of carbonated mineral water.
3. Close the bucket as explained in the handling instructions.
4. Shake the bucket vigorously using your hands.

This releases the carbonic acid gas which is bound in the water, resulting in excess pressure. Do not apply pressure to the lid when doing so.

Leaks can be detected by escaping water or the sound of escaping gas.

Replace the seals if you detect any leaks. Then repeat the test.

Dry the rotor, rotor lid and the cover seal.

⚠ CAUTION Prior to each use, the seals in the rotor are to be inspected in order to assure that they are correctly seated and are not worn or damaged. Damaged seals are to be replaced immediately. Replacement seals can be re-ordered as a spare part ("Rotor Specifications" on page B-1). When loading the rotor, ensure that the rotor lid closes securely. Damaged rotor covers are to be replaced immediately.



CAUTION

This quick test is not suited for validating the aerosol tightness of a rotor. Check the seals and sealing surfaces of the lid thoroughly.

3. Graphical User Interface

This chapter contains details for centrifuges with the graphical user interface described in this manual. Pictures shown are examples and may be different in details to your experience – for example the home screen for a ventilated unit does not feature an on-screen button entry for entering temperature.

3.1. Overview

The Graphical User Interface (GUI) is a color touchscreen display unit. The touchscreen is subdivided into four main screen regions. Figure 3–1 presents the arrangement of the screen areas described in the following.



Figure 3–1: Screen Areas

The four screen areas offer the following features:

- The “Info & Health Status” area (Region 1 in Figure 3–1 above) shows the name of the centrifuge, the current date and time, the unit’s overall health status, and a login area when password protection is activated. For an overview, “Info & Health Status Area (Region 1)” on page 3-2.
- The “Main” screen (Region 2 in Figure 3–1 above) displays the main operating parameters of the unit, including current speed, speed setpoint, acceleration and deceleration profiles, temperature, and current runtime as well as runtime setpoint. When alarms or reportable events occur, this part of the display screen shows alarm or event information. For an overview, “Main Screen (Region R2)” on page 3-2.
- The “Control Panel” (Region 2B in Figure 3–1 above) has touch-sensitive buttons for controlling the major functions of the unit, such as pre-tempering (refrigerated models only), pulse, stop, open door, and information. For an overview, “Control Panel (Region R2B)” on page 3-5.
- The navigation bar (Region R3 in Figure 3–1) holds iconic shortcuts to settings screens. Tapping any of these icons displays the settings screen in the “Main” screen area. For an overview, “Navigation Bar (Region R3)” on page 3-5.

Figure 3–2 shows the touchscreen display for a ventilated centrifuge.




Figure 3–2: Touchscreen Display for Ventilated Centrifuge

Figure 3–3 shows the touchscreen display for a refrigerated centrifuge, which has an additional button and a temperature field.




Figure 3-3: Touchscreen Display for Refrigerated Centrifuge

Info & Health Status Area (Region 1)

The “Info & Health Status” area at the top of the display window appears in all screen displays. Figure 3-4 shows an example of the “Info & Health Status” area on a unit that is in proper working condition.



Figure 3-4: Info & Health Status Area

The “Info & Health Status” area displays the following information:

- Unit Name (top left in Figure 3-4), as entered during the initial setup (see “Initial Startup” on page 1-14) or adjusted later on (“Unit Name” on page 3-45).
- Date/Time (bottom left in Figure 3-4), as entered during the initial setup (see “Initial Startup” on page 1-14) or adjusted later on (“3. 7. 4. Date” on page 3-43 and “Time” on page 3-44).
- The Unit Health Status icon (center in Figure 3-4) is a touch-sensitive area that opens a “Health Status” pop-up window on top of the “Main” Screen. Four different icons may appear in this place, representing the overall health status of the centrifuge:

	The heart-shaped Health Status Good icon indicates that the unit is in proper operating condition. For more details, “3. 5. Status, Alarms and Alerts” on page 3-15.
	The triangle is a health status warning icon. It indicates that there is an issue that does not stop the centrifuge immediately, yet requires the operator’s attention soon. For more details, “3. 5. Status, Alarms and Alerts” on page 3-15.
	The bell Health Status Alarm icon indicates that there are one or more major alarm conditions that need to be corrected because they may constitute a hazard to the operator, the unit itself, or the samples. The white digit in the blue circle indicates how many alarms exist. The sound waves on both sides of the bell indicate that the alarm is sounding. For more details, “3. 5. Status, Alarms and Alerts” on page 3-15.
	The Health Status Alarm icon indicates that there are one or more major alarm conditions that need to be corrected because they may constitute a hazard to the operator, the unit itself, or the samples. The white digit in the blue circle indicates how many alarms exist. The diagonal line across shows that the alarm has been snoozed. For more details, “3. 5. Status, Alarms and Alerts” on page 3-15.

- The “Login” prompt (top right in Figure 3-4) appears only if the unit is set up to operate in “Secure Mode” (“3. 6. 3. Access Control” on page 3-33).

Main Screen (Region R2)

The “Main” screen takes up the main part of the touchscreen and displays the content selected by tapping an icon in the navigation bar at left. The navigation bar lets you navigate to the full set of screens you need for operating and setting up the centrifuge.

Home Screen

Figure 3–5 shows the “Home” screen and its icon in the navigation bar.

The “Home” screen is the default screen from where you run all routine centrifuge operations. It has touch-sensitive fields and buttons that let you set speed, runtime, pre-tempering target temperature (refrigerated models only), start and stop the centrifuge, as well as open the door.

Figure 3–5 below shows an example of the “Home” screen when the centrifuge is in idle mode, with all running parameters at zero and the door open. The setpoints for the major operational parameters are already set, so the centrifuge can be started after closing the door.




Figure 3–5: Home Screen for Idle Centrifuge

Figure 3–6 and Figure 3–7 illustrate the “Home” screen when the centrifuge is running. The major operational parameters (speed, runtime and pre-tempering temperature) are at their current values.




Figure 3–6: Home Screen for Running Centrifuge, Ventilated Models




Figure 3–7: Home Screen for Running Centrifuge, Refrigerated Models

1	The Home button opens the “Home” screen shown in Figure 3–6 and Figure 3–7.
2	The speed box shows the current speed (top) and the speed setpoint (bottom) for the ongoing or upcoming centrifugation run. Tapping the speed box lets you set the speed setpoint and toggle the unit between rpm and x g. For more details, see “Overview” on page 3-1.
3	The rotor type / bucket type box shows the rotor type and bucket type installed. With certain rotor models, the rotor identification feature of the centrifuge will prompt you to confirm the bucket type before the centrifugation starts. For more details, see “Identify Rotor and Buckets” on page 2-10.
4	The acceleration / deceleration profile box shows the currently selected profile numbers for acceleration during startup or deceleration during rundown. Tapping the acceleration / deceleration profile box lets you choose an acceleration / deceleration profile. For more details, see “Acceleration and Deceleration Profiles” on page 3-9 .
5	The temperature box (refrigerated models only) shows the current temperature for the sample (top) and the pre-tempering setpoint (bottom) for the ongoing or upcoming centrifugation run. Tapping the temperature box lets you set the setpoint for pre-tempering. For more details, see “Pre-Temper the Centrifugation Chamber” on page 3-12.
6	The runtime box shows the remaining runtime (top) and the runtime setpoint (bottom) for the ongoing or upcoming centrifugation run. Tapping the runtime box lets you set the runtime in hours, minutes, and seconds. For more details, see “Set Run Time” on page 3-8.
7	The Start/Stop button starts and stops the centrifuge. The functions of the buttons are explained in the section “Control Panel (Region R2B)” on page 3-5.

Settings Screen

The “Settings” screen shown in Figure 3–8 is the point of entry for all settings you make to customize the centrifuge to your needs. You can display this screen by tapping the **Settings** icon from the navigation bar.




Figure 3–8: Settings Main Screen

The settings options for the centrifuge include:

- Alarms
- Alerts
- Controls
- Display
- Files and Info
- Access Control
- Service

Control Panel (Region R2B)

The “Control Panel” in Screen Region R2B contains a complete set of controls for operating the functions of the centrifuge. The inventory of buttons varies with the number of options built into the unit, as can be seen in Figure 3–9 and Figure 3–10.

The “Control Panel” is visible at all times below the “Home” Screen.

Figure 3–9 shows the “Control Panel” for a ventilated centrifuge.




Figure 3–9: Control Panel for Ventilated Centrifuge

Figure 3–10 shows the “Control Panel” for a refrigerated centrifuge.




Figure 3–10: Control Panel for Refrigerated Centrifuge

The icons on the control panel are grayed out while inactive and surrounded by a light gray frame while the function is in use. A frame dimmed to dark gray, as shown for the Pulse and Start buttons in the examples above, indicates that the function is available, but currently not in use. Functions that are currently working are identified by a light gray frame around the button, as shown with the Pretemp icon shown in Figure 3–10.



Tapping the Pretemp button and then the Start button starts pre-tempering of the centrifugation chamber to the target temperature previously set in the temperature box of the home screen. Tapping the Pretemp button one more time stops pre-tempering. This button is deactivated (left) when the centrifuge is running, activated (center) when the centrifuge is at standstill, and surrounded by a gray frame (right) while pre-tempering is ongoing.


For more details, see “Pre-Temper the Centrifugation Chamber” on page 3-12.



The Pulse button launches a continuous or timed run of the centrifuge, as pre-selected in the centrifuge’s settings. Tapping the Pulse button one more time (or the Stop button) stops the centrifuge.

This button is deactivated (top) when the centrifuge is started using the Start button, activated for launching Pulse mode when the centrifuge is at standstill (center), and surrounded by a gray frame while the centrifuge is running in Pulse mode (bottom).

For more details, see “Run in Pulse Mode” on page 3-14. The behaviour of the button can be customized, see “Pulse Customization” on page 3-38.



The Start button starts the centrifuge immediately, using the settings made in the boxes of the “Home” screen. When the centrifuge is running, the button label changes to Stop. Tapping the button one more time stops the centrifuge run and reverts the button label to Start.

For more details, see “Centrifugation” on page 3-13.



The Open button unlocks and opens the centrifuge door. This button is deactivated (left) while the centrifuge is running or pre-tempering, activated (center) for opening when the centrifuge is at standstill, and surrounded by a gray frame (right) while the centrifuge door is open.

Navigation Bar (Region R3)

Besides of the “Home” button described in the section “Main Screen (Region R2)” on page 3-2, the navigation bar holds icons for all major settings and the event logs of the centrifuge. Figure 3–11 shows the two states of the navigation bar.

By default the navigation bar (item 1 in Figure 3–11) is visible to the left of the “Home” screen. By tapping the **Show/Hide** arrow button (item 3 in Figure 3–11) in the middle, it can be hidden (item 2 in Figure 3–11) to show more of the “Home” screen. Tapping the **Show/Hide** arrow button again redisplay the navigation bar.




Figure 3-11: Navigation bar

The navigation bar has the following icons:

Icon	Function
	Back button: In multi-level menus, lets you run backwards through all screens previously displayed. For example, if you have tapped the Settings button, then opened another submenu, tapping this button will return you back up one level at a time. If there is no level to go back to, this icon is dark gray and not active. If there is a level to go back to, this icon is blue and can be tapped. This button is inactive and grayed out if you are on the “Home” Screen.
	Home button: Returns to the “Home Screen”, discussed in the section “Main Screen (Region R2)” on page 3-2.
	Settings button: Opens the “Settings” screen with various options for parameter settings; “Settings” on page 3-30.
	Event Log button: Opens a screen where you can view and export the event log of the centrifuge; “Logs” on page 3-45
	Files and Info button: Opens the “Files and Info” screen that provides product version information and allows administrators to perform a factory reset of the centrifuge; see “Files and Info” on page 3-51
	Alarm Settings button: Opens the “Alarm and Alerts Settings” screen where you can configure how alarms and alerts appear on screen; “3. 6. 1. Alarms” on page 3-30 and “Alerts” on page 3-32
	Programs button: Opens the “Programs” screen where you can program centrifugation runs; “Automate Processes Using Programs” on page 3-21.

Table 3-1: Navigation bar icons

3. 2. Set Basic Centrifugation Parameters

This section explains how to set up the centrifuge with speed / RCF values, acceleration and deceleration profiles, temperature (refrigerated models only) and other operating parameters.

3. 2. 1. Set Speed / RCF-Value

The centrifuge lets you set speed in rpm or as an RCF value (see “RCF Value Explained” further below). You may set speed either from within an ongoing centrifugation run (centrifuge running) or for the next centrifugation run (centrifuge at standstill).

NOTICE After the centrifuge is turned on, it shows the default selection made in the “Settings -> Setpoints” screen; see “Setpoints” on page 3-35.

RCF Value Explained

The relative centrifugal force (RCF) is given as a multiple of the force of gravity (g). It is a unitless numerical value which is used to compare the separation or sedimentation capacity of various centrifuges, since it is independent of the type of device. Only the centrifuging radius and the speed are used for calculation:

$$RCF = 11,18 \times \left(\frac{n}{1000} \right)^2 \times r$$

r = centrifuging radius in cm

n = rotational speed in rpm

The maximum RCF value is related to the maximum radius of the tube opening.

Remember that this value is reduced depending on the tubes, buckets and adapters used.

This can be accounted for in the calculation above if required.

Proceed as follows to set a speed or RCF value:

1. Tap the speed box on the “Home” screen.




Figure 3-12: Speed Box on Home Screen

The “Setpoints: Standard” screen shown in Figure 3-13 or “Setpoints: Advanced” screen shown in Figure 3-14 appears.




Figure 3-13: Setpoints: Standard Screen for Refrigerated Centrifuge

When the centrifuge is set up to run in “Advanced Mode” (see the section “Setpoints Mode” on page 3-37), the “Setpoints: Advanced” screen shown in Figure 3-14 appears instead.




Figure 3-14: Settings -> Controls -> Setpoints: Advanced Screen for Ventilated Centrifuge

2. Tap the **rpm** or **x g** radio button to toggle between speed (in rpm, which is short for revolutions per minute) and RCF (in x g, which means multiples of the force of gravity).



Figure 3-15: Setpoints Screen Detail for Centrifuge Speed, and Range

3. Tap in the **Speed** entry field shown in Figure 3-15, then use the keypad on the right to enter the desired speed.

The admissible speed range for the current rotor appears just below the “Speed” label to assist you in setting speed correctly.

When you tap the **Speed** entry field, the previous setting will be replaced immediately as you start entering digits on the keypad.

NOTICE If you select an extremely low RCF value, it will be automatically corrected if the resulting speed is less than 300 rpm. 300 rpm is the lowest selectable speed.

4. Tap the **Save** button to save the speed setting for the ongoing or the next centrifugation run.

Invalid Rotor Speed Setpoint

If the centrifuge cannot be run with the setpoint you have just entered, an Out of range warning appears beneath the setpoint entry field. You will not be able to continue until you have supplied an acceptable setpoint value.




Figure 3-16: Settings -> Controls -> Setpoints Screen: Out of Range Value Alert

Invalid Rotor Speed Set with Centrifuge Running

If you try to change the speed from within an ongoing centrifugation run and your settings are out of range, the Invalid “Rotor Speed” pop-up window appears.




Figure 3-17: Invalid Rotor Speed Pop-up Window)

Tap the **Stop Unit** button to stop the rotor, then tap the speed box one more time to correct your speed setting. Alternatively, tap the **Continue Running** button to continue at the maximum allowed speed.

3. 2. 2. Set Run Time

The centrifuge lets you set a run time after which the centrifugation run stops automatically.

NOTICE After the centrifuge is powered on, it shows the default selection made in the “Settings -> Setpoints” screen; see “Setpoints” on page 3-35. Proceed as follows to set run time:

1. Tap the **run time** box on the “Home” Screen.




Figure 3-18: Run Time Box on Home Screen

The “Setpoints: Standard” screen or “Setpoints: Advanced” screen is appears.

Run Time in Standard Mode

Tap in the **Time** entry field above and use the keypad shown to enter the desired run time period.

Run time is shown in “hh:mm:ss”. For example, if you want to enter 2 hours and 30 min you must first tap “2” on the keypad. This will set the run time to “00:00:02”. Then tap “3” on the keypad. This will set the run time to “00:00:23”. When tapping “000” next on the keypad the set run time shows “02:30:00”, which is 2 hours and 30 min.




Figure 3-19: Run Time Box on Home Screen

The admissible time range for the current rotor appears just below the “Time” label to assist you in setting run time correctly.

When you tap the **Time** entry field, the previous setting will be replaced immediately as you start entering digits on the keypad.

Run Time in Advanced Mode

In “Advanced Mode” the Time entry field has an extra click-wheel and changes its appearance with the option you select. You have three options to choose from:

- » Timed: Sets the run time in hours, minutes, and seconds.
- » Continuous: Starts a no-limit run, stopped only by tapping the Stop button ■ on the “Home” screen.
- » ACE (Accumulated Centrifugal Effect): The ACE feature is an integrator function that calculates the effect of speed in relation to time and adjusts run time to account for differences in acceleration.

ACE is a mathematical model that helps you to transfer applications and their parameter settings between centrifuges. For example, when you transfer an application to a new centrifuge, ACE ensures that the application runs in exactly the same way and yields the same results as on a legacy centrifuge.

2. Tap the **Save** button to save the run time setting for the ongoing or for the next centrifugation run.

3. 2. 3. Acceleration and Deceleration Profiles

The centrifuge offers a total of 9 acceleration profiles (numbered 1 through 9) and total of 10 deceleration profiles or braking curves (numbered 0 through 9). An acceleration profile gradually increases the speed of the centrifuge after starting the centrifugation run. A deceleration profile gradually reduces the speed of the centrifuge towards the end of the centrifugation run.

NOTICE Avoid if possible speed ranges close to natural resonances of the system. Runs at resonance speeds may have show vibration and an adverse effect on the quality of separation.

Proceed as follows to select an acceleration or deceleration profile:

1. Tap the **Accel / Decel** icon on the left in the “Acceleration / Deceleration Profile” box on the “Home” screen, shown in Figure 3-20 below.



Figure 3-20: Acceleration / Deceleration Profile Box on Home Screen

The “Setpoints: Standard” screen shown in Figure 3-13 or “Setpoints: Advanced” screen shown in Figure 3-14 appears.

Acceleration: Curve number 1 provides the slowest and curve number 9 the fastest acceleration rate.

Deceleration: Curve number 0 disables active deceleration. Curve number 1 provides the slowest active and curve number 9 the fastest active deceleration rate.

2. Tap in the **Accel** or **Decel** entry field, then use the keypad on the right to enter the number for the desired profile. The admissible range of numbers appears just below the “Accel” or “Decel” label to assist you in choosing the desired profile.
When you tap the **Accel** or **Decel** entry field, the previous setting will be replaced immediately as you start entering digits on the keypad.
3. Tap the **Save** button to save the acceleration and deceleration profile setting for the ongoing or for the next centrifugation run.

4. Release the  or  button when the number of the desired acceleration and deceleration profile appears in the display window.

Doing so selects the acceleration and deceleration profile for the next centrifugation run.

3. 2. 4. Set Temperature

A refrigerated centrifuge allows for preselecting a temperature for the sample between -20 °C and +40 °C for the centrifugation run. This feature is not available on ventilated models. Temperatures displayed by the centrifuge are the estimated sample temperatures.

⚠ CAUTION Due to air friction sample integrity may be affected. The temperature of the rotor may rise significantly while the centrifuge is spinning. Refrigerated units can have a deviation from displayed and set temperature to the sample temperature. Make sure the centrifuge temperature control capabilities meet your application specification. If necessary make a test run.

Proceed as follows to set a temperature for the next centrifugation run:

1. Tap the **temperature box** on the “Home” screen, shown in Figure 3–21 below.




Figure 3–21: Temperature Box on Home Screen

The “Setpoints: Standard” screen or “Setpoints: Advanced” screen is displayed.

2. Tap in the **Temp** entry field, then use the keypad on the right to enter the temperature for the sample setpoint. The admissible temperature range for the unit appears just below the “Temp” label to assist you in setting the temperature setpoint correctly.

When you tap the **Temperature** entry field, the previous setting will be replaced immediately as you start entering digits on the keypad.

3. Tap the **Save** button to save the setpoint temperature for the next centrifugation run.

3.3. Pre-Temper the Centrifugation Chamber

Refrigerated centrifuges allow for pre-tempering, that is pre-warming or pre-cooling, the centrifugation chamber and the empty rotor before the centrifugation run starts. If necessary pre-temper your samples using proper equipment. The centrifuge is not intended to be used to pre-temper your samples. Temperatures displayed by the centrifuge are the estimated sample temperatures.

NOTICE Ventilated models cannot pre-temper the centrifugation chamber.

Proceed as follows to set the pre-tempering target temperature for the centrifuge:

1. Tap the **temperature box** on the “Home” screen, shown in Figure 3–22 below.




Figure 3–22: Temperature Box on Home Screen

The “Setpoints: Standard” screen shown in Figure 3–13 or “Setpoints: Advanced” screen shown in Figure 3–14 appears.

2. Tap in the **Temp** entry field, then use the keypad on the right to enter the desired target temperature.
The admissible temperature range for the unit appears just below the “Temp” label to assist you in setting target temperature correctly.
When you tap the **Temp** entry field, the previous setting will be replaced immediately as you start entering digits on the keypad.
3. Tap the **Save** button to save the temperature setting for the pre-tempering run.
You will be returned to the “Home” screen. The new target temperature appears as the setpoint below the current temperature.
4. Tap the **Pre-Temp** button  on the “Home” screen and then the **Start** button  to start pre-tempering.
The centrifuge starts heating or cooling the centrifugation chamber to the setpoint temperature.
The current centrifugation chamber temperature displayed on top of the setpoint temperature starts to change towards the setpoint.
5. When the centrifugation chamber temperature reaches the pre-tempering setpoint, the “Pre-Temp Complete” pop-up window shown in Figure 3–23 appears, announcing that the centrifuge is correctly pre-tempered and ready.




Figure 3–23: Pre-Temp Complete Pop-up Window

6. Tap the **Pre-Temp** button  to exit the Pre-Temp mode.

3. 4. Centrifugation

Mind the safety zone of minimum 30 cm around the centrifuge. Refer to “Info & Health Status Area” on page 3-2. Persons and hazardous substances must be kept out of this safety zone while centrifuging.

Once the main switch has been turned on, the rotor has been properly installed, the setpoints have been set as explained in the previous section, and the centrifuge door has been closed, you are ready to start.

You have various options to start a centrifugation run:

- **Continuous Mode:** This is a fully manual mode. If you have chosen “Continuous Mode” instead of a preset runtime (see “Set Run Time” on page 3-8), use the Start button ► and Stop button ■ to start and stop centrifugation manually, as explained in the section “Run in Continuous or Timed Mode” further below.
- **Timed Mode:** This is a semi-automatic mode that relies on a timer. If you have preset a runtime (see “Set Run Time” on page 3-8), tap the Start button ►, then and wait for the timer to expire and the centrifuge to stop automatically, as explained in the section “Run in Continuous or Timed Mode”.
- **Pulse Mode:** This is a short-run centrifugation mode with selectable behaviors. You choose a behavior, then tap the Pulse button ►► and wait for the centrifuge to run and stop automatically, as explained in the section “Run in Pulse Mode” on page 3-14.
- **Program Mode:** This is a fully automatic mode. You prepare and save an automated program, then run it from the touchscreen, as explained in the section “Automate Processes Using Programs” on page 3-21.



WARNING

Damage to health from centrifuging explosive or flammable materials or substances. Do not centrifuge explosive or flammable materials or substances.

Run in Continuous or Timed Mode

Proceed as follows to run the centrifuge in continuous or timed mode:

1. Press the **Start** button ► on the “Home” screen.

The Start button ► turns into the Stop button ■.

The centrifuge starts running and the touchscreen shows the parameters increasing towards their setpoints. After one minute of continuous running without any intervention by the user, the touchscreen goes to lighthouse mode. In lighthouse mode the touchscreen shows the basic settings, like current speed and speed setpoint, rotor and bucket type, run time elapsed (or remaining) and run time setpoint (timed runs only), plus a progress bar for the run, and the Stop button ■.




Figure 3–24: Screen in Lighthouse Mode

2. Depending on the time mode you have chosen (see “Set Run Time” on page 3-8), do one of the following to stop the centrifuge:
 - a. Continuous mode: Press the Stop button ■ on the Home screen when you have finished centrifuging.
 - b. Timed and ACE modes: Wait until the timer expires and the centrifuge stops automatically, or press the Stop button ■ on the “Home” screen to abort the centrifugation run prematurely.
3. When the centrifuge has stopped centrifugation completely, press the **Open** button ► on the control panel to open the centrifuge door.

The centrifuge door pops open, and the Open button ► is surrounded by a light gray border now to indicate that the door is unlocked.

NOTICE You cannot open the centrifuge door as long as the centrifuge is spinning.

Run in Pulse Mode

Proceed as follows to use the unit for short-run centrifugation:

1. Check the preset Pulse Mode button behavior displayed on the Pulse button >> whether it suits your needs.
The different Pulse button behaviors are explained in the section “Pulse Customization” on page 3-38.
2. If desired, choose a “Pulse Mode” behavior in the “Settings”.
3. Press the **Pulse** button >> on the “Home” screen.

The Start button ▶ turns into the Stop button ■. The Pulse button >> appears with a gray border >> to indicate that the centrifuge is running in “Pulse Mode”.

The centrifuge starts running and the touchscreen shows the parameters increasing towards their setpoints.




Figure 3–25: Pulse Mode: Centrifuge Running for One Minute

4. Wait for the centrifugation run to end and the centrifuge to stop spinning.
NOTICE To abort the centrifugation run prematurely, you can press the Stop button ■ or the Pulse button >> on the “Home” screen.
5. When the centrifuge has stopped spinning, press the **Open** button 🚪 on the control panel to open the centrifuge door.

The centrifuge door unlocks, and the Open button 🚪 is surrounded by a light gray border now to indicate that the centrifuge door is unlocked.

NOTICE You cannot open the centrifuge door as long as the centrifuge is spinning.

3. 5. Status, Alarms and Alerts

This section explains how you can view current status information, alarms, and alerts using the buttons in the “Info & Health Status” area.

Status

When the centrifuge is in good health, the touchscreen display shows a green heart icon in the “Info & Health Status” area (see “Info & Health Status Area (Region 1)” on page 3-2). Tapping the green heart icon opens the “Status” screen. The “Status” screen consists of two successive screens that provide a full set of status information on the centrifuge. You navigate between the two screens by tapping the bullets or chevrons at the bottom of the screen.




Figure 3–26: Status Screen

1. The first “Status” screen consists of two columns called “Operating Details” (Totals) and “Rotor-Centrifuge Lifecycle”.

The “Operating Details” column lists operating data for the centrifuge. This data is actively updated while the centrifuge is running. The total amounts displayed include:

- » “Hours Spinning”: The total number of hours the centrifuge has been actively spinning.
- » “Hours Powered”: The total number of hours the centrifuge has been actively powered on.
- » “Spin Cycles”: The total number of spin cycles the centrifuge has completed.
- » “Compressor Cooling”: The total number of hours the compressor has been active cooling.
- » “Door Locks”: The total number of locking operations for the centrifuge door.

The “Rotor-Centrifuge Lifecycle” shows the name and operating data of the rotor currently installed. This data is actively updated while the centrifuge is running. If the rotor is changed, this section will reflect the new rotor installed. If a rotor with swinging buckets is installed, the bucket type is also displayed—for example: TX-750 (Round Bucket - 75003608). Refer to “Rotor Log” on page 3-48.

The total amounts displayed include:

- » “Total Spin Cycles”: The number of cycles the rotor type has been actively spinning.
- » “Remaining Cycles”: The number of spin cycles the rotor type has left.

NOTICE The number of cycles is estimated. Actual cycles will vary according to usage, number of rotors, and number of centrifuges used. Standard warranty applies.

2. The second “Status” screen displays the column called “Alarm Totals”.

The “Alarm Totals” column displays the total number of imbalance alarms the centrifuge has experienced.

Alerts

When a maintenance action becomes due or when a minor disturbance without any impact on the safe operation of the centrifuge occurs, the unit issues an alert. The centrifuge may continue to spin, but you must correct the root cause as soon as possible to avoid damage to the samples and/or the unit itself.

When an alert is issued, the touchscreen display shows a yellow bar on top of the current screen, as illustrated in the example in Figure 3–27 below. The “Info & Health Status” area (see “Info & Health Status Area (Region 1)” on page 3-2) displays a yellow warning triangle. A ticker-style message in the yellow alert bar explains the root cause of the problem and provides instructions on how to handle the alert.

Additionally, a single audible alert tone is sounded.




Figure 3–27: Rotor End of Life Alert Message on Top of Home Screen

After a short time, the yellow alert bar goes away. Only the yellow warning triangle in the “Info & Health Status” area indicates that alerts exist for the centrifuge, as shown in the example in Figure 3–28 below.




Figure 3–28: Home Screen with Alert Message

The warning triangle icon has a blue circle with a white border that shows the number of active alerts. In the example in Figure 3–27 above, there is only one alert. However, if there is more than one alert present, the alert count may be “2”, “3”, or more.

Tapping the **warning triangle** icon opens an alert list that lets you view all alerts and details about each single alert condition. This is explained in the following section.

Viewing and Handling Alerts

Tapping the warning triangle icon in the “Info & Health Status” area of the touchscreen display opens the “Status – Alert” screen shown in Figure 3–29 below. This screen lists all alerts that are currently active. The latest alert appears expanded to let you view the full details. You can scroll through the list and tap on any list item to expand it and read more.




Figure 3–29: Status – Alert Screen with Alert List

On the right-hand side of the “Status – Alert” screen, there is a stack of status information fields. You can tap and expand each field to view general information on the centrifuge and the current rotor. Figure 3–30 shows the “Operating Details” section expanded, with general operating information about the unit.




Figure 3–30: Status – Alert Screen: Operating Details Expanded

NOTICE These status information fields show the same content as the Status screen, plus the rotor log. This is described in the sections “Status” on page 3-15 and “Rotor Log” on page 3-48, respectively.

Proceed as follows to view the alert list with alert details:

1. Tap on the triangle icon  in the “Info & Health Status” area.
The “Status - Alert” screen shown in Figure 3–29 appears, with the latest alert list item already expanded.
2. To view background information about the centrifuge and rotor, tap the field header to expand the “Operating Details” (see Figure 3–30), “Rotor-Centrifuge Lifecycle”, “Rotor Log”, or “Imbalance Alerts” field.
3. Tap the field header again to hide the content of the information field.
4. Read the description and follow the instructions to correct the problem—for example:
 - a. Return to the Home screen.
 - b. Press the Door Open button .
 - c. Remove the rotor and the buckets.
 - d. Install a new rotor with new buckets.
 - e. Restart the centrifuge.

Refer to “Troubleshooting by Guide” on page 6-3 for a full list of errors.

5. When you have corrected the problem, tap the **Acknowledge** button to acknowledge and clear the alert. The checkbox next to the alert list entry is activated.

NOTICE If you acknowledge the alert without correcting the problem, the alert will return immediately.

6. If you wish to view more alerts from the list, tap the scrollbar and drag to scroll down.
7. Tap the desired alert list item.
The alert item is expanded to reveal the details.
8. Solve the problem and acknowledge the alert, then tap the alert list item one more time to reduce it.
Once you have solved and acknowledged all alerts, the “Status – Good Screen” appears to confirm that the centrifuge is free of alerts.
9. Tap the **X** icon  in the top right corner to return to the Home screen.

Alarms

When a major error condition occurs in the centrifuge, the unit issues an alarm. The centrifuge stops or must be stopped immediately to avoid damage to the samples and/or the unit itself. You must correct the root cause before you can continue operation.

When an alarm is issued, the touchscreen display shows a red bar on top of the current screen. The “Info & Health Status” area (see “Info & Health Status Area (Region 1)” on page 3-2) displays a red alarm bell enclosed by sound waves. Additionally, an audible alarm tone is constantly sounding.

Beneath the red alarm bar, a ticker-style message explains the root cause of the problem and provides instructions on how to handle the alarm.

A Snooze button appears, allowing you to temporarily silence the alarm. When the alarm condition is not cleared within the snooze period, the alarm returns. The duration of the snooze period can be chosen in the settings, as explained in the section “Snooze Timeout” on page 3-31.




Figure 3-31: Alarm Message on Top of Home Screen

Tapping the snooze button temporarily silences the audible alarm for the duration of the snooze period. It also hides the red alarm bar, but keeps the ticker message beneath the bell icon on-screen for a short time before it disappears as well. The bell icon is displayed with a diagonal line across it and a count-down timer to its right.




Figure 3-32: Alarm Message after Snoozing

The bell icon has a blue circle with a white border that shows the number of active alarms. In the example in Figure 3-32 above, there is only one alarm. However, if there is more than one alarm present, the alarm count may be “2”, “3”, or more.

Tapping the bell icon opens an alarm list that lets you view all alarms and details about each single alarm

condition. This is explained in the section “Viewing and Handling Alarms” on page 3-19.

The visible buttons, such as Pre-Temp, Pulse, Start/Stop, and Door Open, are still operable in this state, depending on whether centrifuge is still running or idle. For example, you can usually stop a running centrifuge and open the centrifuge door, or you can navigate to other screens using the left-hand navigation bar while alarms are present. The alarm bell and ticker message will continue to display on all screens you navigate to, unless you snooze the alarm, in which case a silenced bell is shown along with the snooze countdown timer.

There are more severe alarm conditions that cannot be solved by interacting with the touchscreen display. If such an alarm occurs, a large red overlay screen blanks out the current screen and its buttons.




Figure 3-33: Full Screen Alarm Message

You can neither snooze this kind of alarm nor tap any buttons to solve it, but only acknowledge it. Like the less severe alarm messages discussed above, this message gives troubleshooting instructions and refers you to field service if the issue cannot be solved.

Viewing and Handling Alarms

Tapping the red bell icon in the “Info & Health Status” area of the touchscreen display opens the “Status – Alarm” screen. This screen lists all alarms that are currently active. The latest alarm appears expanded to let you view the full details. You can scroll through the list and tap on any list item to expand it and read more.




Figure 3-34: Status – Alarm Screen with Rotor Imbalance Message

On the right-hand side of the “Status – Alarm” screen, there is a stack of status information fields. You can tap and expand each field to view general information on the centrifuge and the current rotor.




Figure 3-35: Status – Alarm Screen: Operating Details Expanded

NOTICE These status information fields show the same content as the “Status” screen, plus the rotor log. This is described in the sections “Status” on page 3-15 and “Rotor Log” on page 3-48, respectively.

Proceed as follows to view the alarm list with alarm details:

1. If you wish to silence the audible alarm (and hide the alarm message) temporarily, tap the Snooze button in the “Info & Health Status” area of the touchscreen (see Figure 3-33 for an example).
2. Tap on the alarm bell icon  in the “Info & Health Status” area.
The “Status - Alarm” screen shown in Figure 3-34 appears, with the latest alarm list item already expanded.
3. To view background information about the centrifuge and rotor, tap the field header to expand the “Operating Details” (see Figure 3-35), “Rotor-Centrifuge Lifecycle”, “Rotor Log”, or “Imbalance Alarms” field.
4. Tap the field header again to hide the content of the information field.
5. Read the description and follow the instructions to correct the problem—for example:
 - a. Return to the Home screen.
 - b. Press the Door Open button .
 - c. Remove the rotor and balance the load of the buckets.
 - d. Reinstall the rotor and restart the centrifuge.
6. When you have corrected the problem, tap the **Acknowledge** button to acknowledge and clear the alarm. The checkbox next to the alarm list entry is activated.

NOTICE If you acknowledge the alarm without correcting the problem, the alarm will return immediately.

7. If you wish to view more alarms from the list, tap the scrollbar and drag to scroll down.
8. Tap the desired alarm list item.
The alarm item is expanded to reveal the details.
9. Solve the problem and acknowledge the alarm, then tap the alarm list item one more time to reduce it.
Once you have solved and acknowledged all alarms, the “Status – Good” Screen appears to confirm that the centrifuge is free of alarms, as shown in Figure 3-36 below.




Figure 3-36: Status – Screen

10. Tap the **X** icon  in the top right corner to return to the “Home” screen.

Automate Processes Using Programs

To reduce the setup effort before a centrifugation run, the centrifuge lets you store up to 100 programs. Programs are pre-programmed centrifugation runs with a user-specified parameter set. Programs can consist of a single step that runs with just one parameter set, or of several steps with changing parameter sets.

A parameter set may consist of all or part of the operating parameters explained in previous sections of this chapter, including:

- speed in rpm or as an RCF value
- acceleration and deceleration profile
- run time
- temperature (refrigerated models only)

Setting Up and Saving a Program

Programs are created on the “Programs” screen. The “Programs” screen opens when you tap the **Programs** button  from the navigation bar on the left side of the touchscreen display.

If this is the first time you open the “Programs” screen on a newly installed centrifuge, you will see an empty programs list waiting to be filled, with basic instructions on how to get started with programs.




Figure 3-37: Pristine Programs Screen (Prior to Creating Programs)

Proceed as follows to create and store a program:

1. Tap the **Programs** button  on the navigation bar.

The “Programs” screen appears, either waiting to be filled with programs as shown in Figure 3-37, or listing the existing programs as in the example in Figure 3-47.

2. Tap the **Create New** button.

The “Add New Program Screen” shown in Figure 3-38 appears. The message “Tap to enter” in the “Name” field prompts you to start typing.




Figure 3-38: Programs -> Add New Program Screen, First Set of Options

3. Tap the **Name** field.

A keypad appears on top of the “Create New Program” screen (see Figure 3-39).




Figure 3–39: Programs with Keypad Overlay

4. Enter a program name of maximum 20 characters length.
5. Tap **rpm** or **x g** to choose the unit for centrifuge speed.
6. Tap the **Temp** field and enter a target temperature for pre-tempering (refrigerated models only).
7. Enter numbers for the acceleration and deceleration profiles, if desired (see “Settings -> Controls -> Setpoints Screen: Out of Range Value Alert” on page 3-8 and “Set Temperature” on page 3-11 for more details).
8. Tap the scroll bar on the right and drag further down to show the remaining options, as shown in Figure 3–40 below.




Figure 3–40: Programs -> Add New Program Screen, Second Set of Options

9. Tap the **Start Timer** field to choose whether the set time begins when the centrifuge is started or once the acceleration phase is completed.
10. Under the “Step 1” option, tap in the **Speed** field and enter the speed in rpm or x g, as chosen further up in the screen.
A keypad appears on top of the “Add New Program” screen, as shown in Figure 3–41 below.
11. Tap the **Time** field and enter a run time in hours, minutes, and seconds.

Acme Labs GP 2
11:22:24AM | May 12, 2015
Add New Program

Step 1

Speed: 15500 rpm

Time: 03:30:00 h:m:s

Next

Figure 3-41: Programs -> Add New Program Screen, Speed and Time for Step 1

12. If you wish to vary speed and run time during the centrifugation run, tap the **+ Add Step** button.
13. Tap the **Speed** field and enter a different speed for Step 2.
14. Tap the **Time** field and enter the start time for Step 2, that is, the time at which the speed should change.
15. Repeat the last three entries for as many additional steps as required.

NOTICE If you leave it at Step 1, the program will run at one speed only for the full duration.

16. Tap the **Save** button to store your program.

Your program is stored and ready to run now.

Advanced Program Settings

The **Advanced Settings** button on the main “Programs” screen opens the “Advanced Settings” screen that lets you make general settings for programs. The options on the “Advanced Settings” screen do the following:

- configure the run time timer on the “Home” screen to run up or down
- influence the way user-created programs are listed on the main “Programs” screen
- determine whether or not programs require the user to tap the Start button ► for confirmation before they run.

Acme Labs GP 2
11:22:24AM | May 12, 2015
Advanced Settings

View Time As: ☐ Elapsed ☒ Remaining

Organize by: ☐ Alphabetical ☒ 3 Most Used, then Alpha

Save

Figure 3-42: Programs -> Advanced Settings Screen

Proceed as follow to set advanced options for programs:

1. Under **View Time As**, choose either **Elapsed** or **Remaining** to show the timer on the “Home” screen as time elapsed (counting up) or time remaining (counting down.) The default setting is “Remaining”.
2. Under **Organize By**, choose either **Alphabetical** (default) to organize the program list in alphabetical order, or **3 Most Used**, then Alpha to have the most-used programs remain on the display and easily accessible.

NOTICE The three most used programs may change if some programs become more used than others.

3. If desired, check the **Start the centrifuge on program load** checkbox to start the program (unit spinning) immediately after tapping a program button from the main “Programs” screen (shown in Figure 3-47 further below).

NOTICE Leaving this box unchecked will load the program onto the main screen, but will require an additional tap on the Start button ► on the “Home” screen.

Previewing Program Parameters

The main “Programs” screen allows you to preview the parameters of a program listed there, so you can see what it does before you run it.

Proceed as follows to preview a program:

1. Tap the **Eye** button  next to the program you wish to preview.
The “Program Quick View” pop-up window shown in Figure 3–43 appears.




Figure 3–43: Programs -> Program Quick View Pop-up Window

2. If you are satisfied with the choice of parameters, tap the **Run Program** button to run the program immediately.

If you wish to change the program to better suit your needs, tap the **Edit Program** button and change the parameters as explained in the section “Setting Up and Saving a Program” on page 3-21.

If you do not wish to run the program yet, tap the **X** icon  to close the pop-up window and return to the main “Programs” screen.

Editing Program Parameters

The main “Programs” screen allows you to edit the parameters of a program listed there, so you can adapt it to your needs before you run it. You may change speed, run time, temperature (refrigerated models only), acceleration and deceleration profiles, add or remove steps, and rename the program.

Proceed as follows to edit a program:

1. On the main “Programs” screen, tap the **Pen** button  next to the program you wish to edit.
The “Edit Program” screen appears.




Figure 3–44: Programs -> Edit Program Screen

2. To change the program, edit the parameters as explained in the section “Setting Up and Saving a Program” on page 3-21.
3. To delete a program step, scroll down further to display the step you wish to remove.
4. Tap the **Minus** button  at the far right end of the program button.
The “Delete Confirm” window shown in Figure 3–45 appears.




Figure 3-45: Programs -> Delete Confirm Window for Program Step)

5. Tap **Delete** one more time to delete the step.
6. When you have finished making changes, tap the **Save** button to save your changes.
You will be returned to the main “Programs” screen. The program has been changed according to your entries.

Deleting a Program

The main “Programs” screen allows you to delete any program listed there to free up storage space.

Proceed as follows to delete a program:

1. On the main “Programs” screen, tap the **Pen** button  next to the program you wish to delete.
The “Edit Program” screen shown in Figure 3-44 further above appears.
2. To delete the program, tap the **Delete** button in the “Edit Program” screen.
The “Delete Confirm” window shown in Figure 3-46 below appears.




Figure 3-46: Programs -> Delete Confirm Window for Program

3. Tap **Delete** one more time to delete the program.
You will be returned to the main “Programs” screen. The program has been removed from the list.

Running a Program

Programs are run from the “Programs” screen shown in Figure 3–47. The “Programs” screen opens when you tap the “Programs” button  from the navigation bar on the left side of the touchscreen display.

You run an existing program by tapping on any of the user-named program buttons listed on the main “Programs” screen. In the example shown in Figure 3–47 below, there are three user-created programs. If you tap one of the program buttons, the screen display changes to the Home screen and indicates that the program is loaded. Depending on the advanced settings (see “Setting Up and Saving a Program” on page 3-21), the program will either start the unit spinning immediately, or it will load and wait for the user to tap the start button on the home screen.




Figure 3–47: Programs Screen with Pre-Stored User Programs

Proceed as follows to start a previously stored program.

1. Load and install the rotor.
Close the centrifuge door.
2. Tap the **Programs** button  on the navigation bar.
The “Programs” screen appears, listing the existing programs as in the example in Figure 3–47.
3. Tap the **Play** icon  on the program button of your choice.

NOTICE If the centrifuge is still running, the Unit Running pop-up window appears, asking you whether you wish to cancel the current run and start the new program instead.

The centrifuge displays the “Home” screen. There are two possible scenarios, depending on the “Advanced Settings” (see the section “Setting Up and Saving a Program” on page 3-21):

- a. If your centrifuge is set up to launch programs immediately, the program will start running.
- b. If your centrifuge is set up to require a user action, you will be prompted to start the program with the **Start** button on the “Home” screen.

When the program has been executed, the “Program Complete” pop-up window appears.

Sharing Programs between Centrifuges

The main “Programs” screen has two “Import” and “Export” buttons that allow you to export programs you have created on one centrifuge and import them to a second centrifuge of the same model and series. Insert a USB drive, such as a removable memory stick, into the USB port next to the touchscreen display of the centrifuge, then export, transfer, and re-import the files to the second unit.

You can export program files using the “Export Programs” screen.




Figure 3-48: Programs -> Export Programs Screen

The matching “Import Programs” screen is used for importing the programs on the target centrifuge.




Figure 3-49: Programs -> Import Programs Screen

Exporting Programs

Proceed as follows to export one or more programs:

1. Insert a USB drive with sufficient free storage space into the USB port of the centrifuge.
2. Tap the **Programs** button  on the navigation bar.
The “Programs” screen appears, listing the existing programs.
3. Tap the **Export** icon  at the bottom edge of the “Programs” screen.
The “Export Programs” screen appears.
4. Tap the appropriate checkboxes for the programs you wish to export. Choose either **Select All** for all programs, **or** scroll and **select individual checkboxes** for the desired programs.
5. Tap the **Export** button.

NOTICE If you have not inserted a USB drive into the USB port of the centrifuge, the “Export Programs” pop-up window appears, prompting you to insert a USB drive. If necessary, insert the USB drive into the USB port of the centrifuge.

The export will start now, as indicated by the “Export Programs” pop-up window shown in Figure 3-50 below. It shows a cautioning message not to remove the USB drive and a green and gray progress bar that lets you follow the process.




Figure 3-50: Programs -> Export Programs Pop-up Window with Progress Bar

NOTICE You may abort a running export at any time by tapping the Cancel button in the “Export Programs” pop-up window shown in Figure 3-50 above. If you do so, the export is aborted, and the “Export Error” message appears. This message lists all programs that have not been exported successfully.

NOTICE While the export is running, make sure you do not remove the USB drive from the USB port. If you remove the USB drive, the export is aborted, and the “Export Error” message appears. This message lists all programs that have not been exported successfully.

NOTICE While the export is running, the USB drive may run out of disk space. If that happens, the export is aborted, and the “Export Error” message appears.

When the export has been successfully completed, the “Export Complete” pop-up window shown in Figure 3-51 below appears.




Figure 3-51: Programs -> Export Complete Pop-up Window

6. Tap the **OK** button to acknowledge the message and remove the USB drive.
Your programs are now ready for importing to another centrifuge. On your USB drive, you will find one or more new files with the general filename **UnitName_ProgramName_YYYY_MM_DD.csv** or **UnitName_ProgramName_YYYY_MM_DD_01.csv** now.

Importing Programs

Proceed as follows to import one or more programs from a USB drive:

1. Insert the USB drive with exported programs into the USB port of the centrifuge.
2. Tap the **Programs** button  on the navigation bar.
The Programs screen appears, listing the existing programs as in the example in Figure 3-47.
3. Tap the **Import** icon  at the bottom edge of the Programs screen.

NOTICE If you have not inserted a USB drive into the USB port of the centrifuge, the “Import Programs” pop-up window below appears, prompting you to insert a USB drive. If necessary, insert the USB drive into the USB port of the centrifuge.

The Import Programs screen appears.

4. Tap the appropriate checkboxes for the programs you wish to import. Choose either **Select All** for all programs, **or** scroll and **select individual checkboxes** for the desired programs.
5. Tap the **Import** button.

If necessary, insert the USB drive into the USB port of the centrifuge.

The import will start now, as indicated by the “Import Programs” pop-up window shown in Figure 3-52 below. It shows a cautioning message not to remove the USB drive and a green and gray progress bar that lets you follow the process.




Figure 3-52: Programs -> Import Programs Pop-up Window with Progress Bar

NOTICE You may abort a running import at any time by tapping the Cancel button in the Import Programs pop-up window. If you do so, the import is aborted, and the Import Error message appears. This message lists all programs that have not been imported successfully.

NOTICE While the import is running, make sure you do not remove the USB drive from the USB port. If you remove the USB drive, the import is aborted, and the Import Error message appears. This message lists all programs that have not been imported successfully.

NOTICE While the import is running, the centrifuge may run out of memory when the maximum supported number of programs is exceeded. If that happens, the import is aborted, and the Import Error message appears. Repeat the import with fewer programs selected or delete programs from the centrifuge (see “Deleting a Program” on page 3-25) and repeat the import for the programs that were not imported.

NOTICE While the import is running, the centrifuge may encounter duplicate entries that bear the same name as existing programs. If that happens, the import is aborted, and the Import Error message appears. To resolve this conflict, tap the Overwrite button to allow the imported program to replace an existing program of the same name. Alternatively, you may tap the Skip button to retain the existing program stored on the centrifuge, rename the existing program, then repeat the import.

NOTICE While the import is running, the centrifuge verifies the programs being imported and discards any corrupted programs that will not run. If that happens, the import is aborted, and the Import Error message appears.

6. When the import has been successfully completed, the “Import Complete” pop-up window shown in Figure 3-53 below appears.




Figure 3-53: Programs -> Import Complete Pop-up Window

7. Tap the **OK** button to acknowledge the message and remove the USB drive. The imported programs are now ready for use.

3. 6. Settings

This section explains how to set up the centrifuge using the options of the Settings main screen.

The “Settings Main” screen opens up when you tap the **Settings** icon  in the navigation Bar and features eight buttons. Seven of the buttons provide instant access to sub-menus that let you activate additional features, change the factory default settings to customize the centrifuge to your needs, and modify items entered during the initial setup process.




Figure 3-54: Settings Main Screen

Most of the settings are open to normal users, but some require advanced user privileges. Where this is the case, you will be prompted to enter an administrator passcode. The eighth button, labeled Service, is reserved to Thermo Fisher Scientific service technicians and requires even more advanced user privileges. This is indicated by the padlock icon on the button.

Instructions for using the screens opened by the buttons on the “Settings Main Screen” appear in the following sections.

3. 6. 1. Alarms

Tapping the **Alarms** button  on the “Settings” screen takes you to the “Alarms Settings” screen.

From the “Alarms Settings” screen, you may change the volume, tone, and timing of several audible alarms emitted by the centrifuge.

Selections are made by dragging a slider or tapping drop-down lists on the screen. You may change one, several, or all of the options before confirming your selections with the **Save** button.

Alarm Volume

You may change the volume of the alarm tone directly on the main “Alarms Settings” screen by tapping on the **speaker** icon in the slider and dragging left to decrease or right to increase.



Figure 3-55: Alarms Settings -> Alarm Volume Slider

Proceed as follows to change the Alarm Volume:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alarms** button  on the “Settings” screen.
Alternatively, you can also tap the **Alarm** icon on the navigation bar to open the “Alarms Settings” screen.
3. Tap the **Alarm Volume** slider and drag to the left to decrease and or to the right to increase. Alternatively, you can tap the  or  buttons on both sides of the slider to decrease or increase.
The alarm tone will play briefly with the newly chosen volume.
4. Save your changes or change any other desired option on the “Alarms Settings” screen.

Alarm Tone

You may change the alarm tone for the front window directly on the main “Alarms Settings” screen by just tapping on the drop-down list labeled Alarm Tone and selecting one of the three options.

NOTICE The naming of the options may differ in each country.

Proceed as follows to change the Alarm Tone:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alarms** button  on the “Settings” screen.
Alternatively, you can also tap the **Alarm** icon on the navigation bar to open the “Alarms Settings” screen.
3. Tap the **Alarm Tone** drop-down menu and choose an option.
The selected alarm tone will play briefly.
Save your changes or change any other desired option on the “Alarms Settings” screen.

High and Low Temperature Alarms

You may change the high and low temperature alarm thresholds (refrigerated models only) for the centrifugation chamber temperature on the main “Alarms Settings” screen by tapping on the drop-down lists labeled “High Temperature Alarm” and “Low Temperature Alarm” and selecting one of the three options. The alarm threshold is set relative to the temperature setpoint and shifts every time you change the temperature setpoint.

Proceed as follows to change the High and Low Temperature Alarms:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alarms** button  on the settings screen.
Alternatively, you can also tap the **Alarm** icon on the navigation bar to open the “Alarms Settings” screen.
3. Tap the **High and Low Temperature Alarms** drop-down menu and choose an option.
The selected “High or Low Temperature Alarm” threshold is activated now.
4. Save your changes or change any other desired option on the “Alarms Settings” screen.

Snooze Timeout

You may set the timeout period during which an alarm is temporarily silenced when you tap the **Snooze** button directly on the main “Alarms Settings” screen. This is done by tapping on the drop-down list labeled “Snooze Timeout” and selecting one of the three periods.

Proceed as follows to change the Snooze Timeout period:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alarms** button  on the “Settings” screen.
Alternatively, you can tap the **Alarm** icon on the navigation bar to open the “Alarms Settings” screen.
3. Tap the **Snooze Timeout** drop-down menu and choose the period for which an alarm is silenced by the **Snooze** button.
The time period in the “Snooze Timeout” drop-down will change to the new setting.
4. Save your changes or change any other desired option on the “Alarms Settings” screen.

3.6.2. Alerts

Tapping the **Alerts** button  on the “Settings” screen takes you to the “Alerts Settings” screen.

On the “Alerts Settings” screen, you may change the alert volume, tone, and behavior of status messages issued by the centrifuge.




Figure 3–56: Settings -> Alerts Screen

Alert Volume

You may change the volume of the alert tone directly on the main “Alerts Settings” screen by tapping on the **speaker** icon in the slider shown in Figure 3–57 below and dragging left to decrease or right to increase.



Figure 3–57: Alerts Settings ->Alert Volume Slider

Proceed as follows to change the Alert Volume:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alerts** button  on the “Settings” screen.
3. Tap the **Alert Volume** slider and drag to the left to decrease and or to the right to increase. Alternatively, you can tap the  or  buttons on both sides of the slider to decrease or increase.
The alert tone will play briefly with the newly chosen volume.
4. Save your changes or change any other desired option on the “Alerts Settings” screen.

Alert Tone

You may change the alert tone for the front window directly on the main “Alerts Settings” screen by just tapping on the drop-down list labeled “Alert Tone” and selecting one of the three options.

NOTICE The naming of the options may differ in each country.

Proceed as follows to change the Alert Tone:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Alerts** button  on the “Settings” screen.
Alternatively, you can also tap the **Alert** icon on the navigation bar to open the “Alerts Settings” screen.
3. Tap the **Alert Tone** drop-down menu and choose an option.
The selected alert tone will play briefly.
4. Save your changes or change any other desired option on the “Alerts Settings” screen.

Alert Option Checkboxes

There are three checkboxes on the “Alerts Settings” screen:

1. Check or uncheck the “Display parameter settings” confirmations checkbox.
By default, this checkbox is checked and will display a “Save” confirmation pop-up window each time you change a main setpoint parameter, including run time, temperature, speed, acceleration and deceleration profile.
You may uncheck this box to disable the “Save” confirmation notifications for saving run time, temperature, speed, acceleration and deceleration parameter changes and have the Save button take effect immediately. “Save” confirmations will still be displayed for other settings—for example, changing alarm or alert settings.
2. Check or uncheck the “Display end of run” notifications checkbox.
By default, this box is checked and will display an “End of Run” notification pop-up window each time a centrifugation run has ended for both regular runs and program runs. You may uncheck this box to disable the End of Run message.
3. Check or uncheck the “Auto-close notifications after 5 seconds” checkbox.
By default, this box is checked and will auto-close all “Save” notifications, “End of run” notifications, and “Import/export” notifications after 5 seconds of no activity.
You may uncheck this box to require a manual tap of the **OK** button **or** the **X** icon  in the top right corner of the before-mentioned message screens.
4. Save your changes or change any other desired option on the “Alerts Settings” screen.

3. 6. 3. Access Control

Tapping the **Access Control** button  on the “Settings” screen takes you to the “Access Control” screen.

The “Access Control” screen allows you to toggle between “Open Mode” and “Secure Mode”.

By default, the centrifuge is in “Open Mode”, that is, you do not need to enter a passcode to access and operate the unit. “Secure Mode” requests a passcode from all users who want to operate advanced features of the centrifuge or change its settings (see Table 3–2 for a complete listing).




Figure 3–58: Settings -> Access Control Screen

“Secure Mode” displays a Login button in the top right corner of the touchscreen display. If you are not logged in and tap on any icon or button that invokes a passcode-protected feature, you will be prompted to enter the passcode and log in.

NOTICE Only the “Factory Settings” and “Field Certification” screens require specific passcodes, which are different from the admin passcode. These screens are reserved for Thermo Fisher Scientific service.

The following comparison of “Open Mode” versus “Secure Mode” indicates when a passcode login is required.

Action	Passcode Required in Open Mode	Passcode Required in Secure Mode
Set parameters and run the unit	No	No
Run programs	No	No
Create, edit, and delete programs	No	Yes
Change display settings	No	Yes
Change control settings	No	Yes
Change alarm settings	No	Yes
Change alert settings	No	Yes
View and export event log	No	No
Connect the unit to a wired network	No	Yes
View Files and Info screen	No	No
Snooze Alarms	No	No
Acknowledge alarms and alerts	No	No

Table 3-2: Passcode Login Requirements in Open and Secure Mode

If you switch from “Open Mode” to “Secure Mode”, you will, upon tapping the Save button, be prompted to enter the admin passcode before the change can be confirmed. All units ship with the same admin passcode pre-set at the factory and printed in the manual.

Changing the Admin Passcode

If you need to change the default passcode, you may do so from the “Access Control” screen by tapping the **Change Admin Passcode** button.

NOTICE The preset administrator passcode is “00000”.

Proceed as follows to change the admin passcode:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Access Control** button  on the “Settings” screen.
The “Access Control” screen shown in Figure 3-58 above appears.
3. Tap the **Change Admin Passcode** button in the “Access Control” screen.
A passcode prompt appears, asking you to enter the current admin passcode.
4. Enter the old admin passcode using the keypad.
Another passcode prompt appears, asking you to enter the new admin passcode.
5. Enter the new admin passcode using the keypad.
6. A third passcode prompt appears, asking you to re-enter the new admin passcode.
7. Enter the new admin passcode one more time to confirm, using the keypad.
You will be returned to the “Access Control” window. The mode has changed from open to secure, and the Save button has turned blue to indicate that you may save your changes now.
8. Tap the **Save** button to save the new passcode.
9. The “Passcode Changed” pop-up window appears, stating that your passcode has been changed.
10. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
11. Note the new admin passcode for future reference.

Switching to Secure Mode

Changing the access mode from open to secure is done from the “Access Control” screen by tapping the **Secure** radio button.

Proceed as follows to change the admin passcode:

1. If you do not know the passcode, look up the factory pre-set admin passcode in the user manual. Refer to “Changing the Admin Passcode” on page 3-34.
2. Tap the **Settings** icon on the navigation bar.
3. Tap the **Access Control** button  on the “Settings” screen.
The “Access Control” screen appears.




Figure 3-59: Settings -> Access Control: Access Control Screen in Secure Mode

4. Tap the **Secure** button in the “Access Control” screen.
The passcode prompt appears, asking you to enter the current admin passcode.
You will be returned to the “Access Control” window. The mode has changed from open to secure, and the Save button has turned blue to indicate that you may save your changes now.
5. Tap the **Save** button to save the new passcode.
The “Access Mode Change Success” pop-up window appears, indicating that the mode has been successfully changed to “Secure Mode” and that a passcode will be required from now on.
6. To confirm the changes, tap the **OK** button in the pop-up window. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Access Control” screen. The “Access Control” screen has a logout command and user name readout in the upper right corner now. Also new is the Create User Passcode button next to the Change Admin Passcode button.

Changing User Passcodes

Using the Create User Passcode button available in Secure Mode, you may, after logging in with the administrator passcode, create separate passcodes for other users. These users may then operate the centrifuge, but they may not change any settings.

3. 6. 4. Controls

Tapping the **Controls** button  on the “Settings” screen takes you to the “Controls” screen. The “Controls” screen offers a stack of eight buttons. These buttons allow for customizing the behavior of the controls and display items on the “Home” screen to suit your needs, altering the factory default settings. The options of the “Controls” screen include:

- “Setpoints”
- “Setpoints Mode”
- “View Time As”
- “Pulse Customization”
- “Door Auto Open”
- “Compressor Off” (refrigerated models only)
- “Scheduling”
- “Rotor Bucket”

The “Controls” screen holds more options than would fit on one screen. Therefore, it has a scrollbar on the right side of the button stack. By tapping the scrollbar and dragging, you can display the options that are currently hidden.

Setpoints

The **Setpoints** button opens a setpoint entry screen where you can enter the default values that appear in the speed, acceleration, deceleration, and temperature boxes on the “Home” screen when you turn on the centrifuge or when the centrifuge has spun down after a run. By entering your own choice of settings, you can change the factory defaults to best suit your needs.

In “Advanced Mode”, you can choose which timed mode the centrifuge runs in by default: ACE, Timed or Continuous. “Standard Mode” only allows for a timed setpoint.

Table 3–3 lists the items on “Setpoints” screen and explains their respective functions.







Field(s)	Function
	Speed field: Lets you set a default setpoint for the speed box on the “Home” screen. The value you enter is either rpm or x g, depending on the selection made with the radio buttons on the right.
	Accel field: Lets you choose between nine acceleration profiles from 1 to 9 (default is 1) for the accel box on the “Home” screen. “1” sets the slowest acceleration profile, while “9” chooses the fastest.
	Decel field: Lets you choose between ten deceleration profiles from 0 to 9 (default is 1) for the decel box on the “Home” screen. “1” sets the slowest braking profile, “9” chooses the fastest, and “0” lets the centrifuge slow down without active braking.
	Time field in Standard Mode: Use this field to set a default setpoint for the time box on the “Home” screen. Time field in Advanced Mode: Use this field to set a default setpoint for the time box on the “Home” screen and a default behavior for centrifugation runs (see “Set Run Time” on page 3-8).
	Temp field (refrigerated models only): Lets you set a default setpoint for the temperature box on the “Home” screen.
	Start Timer field: Use this field to choose whether the set time begins when the centrifuge is started or once the acceleration phase is completed.

Table 3–3: Settings -> Controls Settings -> Setpoints Screen Items Explained

Setpoints for Standard and Advanced Modes

When the centrifuge is set up to run in “Standard Mode” (see the next section “Setpoints Mode” on page 3-37), the “Setpoints: Standard” screen appears.




Figure 3–60: Settings -> Controls -> Setpoints: Standard Screen for Refrigerated Centrifuge

NOTICE Ventilated centrifuges do not have the “Temp” field.

When the centrifuge is set up to run in “Advanced Mode” (see the next section “Setpoints Mode” on page 3-37), the “Setpoints: Advanced” screen appears instead.




Figure 3-61: Settings -> Controls -> Setpoints: Advanced Screen for Ventilated Centrifuge

Proceed as follows to customize the setpoints for Standard Mode and Advanced Mode:

1. Tap the **Settings** icon on the navigation bar.
2. Tap the **Controls** button on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Setpoints** button.
The “Setpoints: Standard” screen or “Setpoints: Advanced” screen shown in Figure 3-61 above appears.
4. To customize the default setpoint that appears in the appropriate box of the “Home” screen, tap in the entry field, then use the keypad on the right to enter your default value.
The previous setting will be replaced immediately when you start entering digits on the keypad.
5. Tap **Next** on the keypad to continue to the next setpoint entry field.
If you have entered a correct speed value, the cursor will go to the next field.
If the centrifuge cannot be run with the setpoint you have just entered, an Out of range warning appears beneath the setpoint entry field, as shown in the example Figure 3-62 below. You will not be able to continue until you have entered an acceptable setpoint value.




Figure 3-62: Settings -> Controls -> Setpoints Screen: Out of Range Value Alert

6. Tap the **Save** button to save the new setpoint(s).
A pop-up window appears, indicating that the setpoints have been successfully changed.
7. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon closes this window and exits without saving.
You will be returned to the “Controls” screen.
The new setpoints will now appear in the respective boxes of the “Home” screen.

Setpoints Mode

This button lets you choose whether you wish to run the centrifuge in standard (factory default) or advanced setpoints mode. Standard mode allows you to run the centrifuge in a single timed mode only, while advanced mode lets you choose which timed mode to run before starting the centrifuge.

Proceed as follows to toggle between Standard Mode and Advanced Mode:

1. Tap the **Settings** icon on the navigation bar.
2. Tap the **Controls** button on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Setpoints Mode** menu and choose “Advanced” to customize, or “Standard” to return to the factory default.
4. Tap the **Save** button to save the new setpoints mode.
A pop-up window appears, indicating that the setpoints mode has been successfully changed.

- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.
If you have chosen “Advanced Mode”, a click-wheel with “Timed Run” options will now be added to the screen that opens when you tap the **Time** box on the “Home” screen.
If you have reverted to “Standard Mode”, there is no click-wheel with “Timed Run” options.
- To further customize “Standard” or “Advanced Mode”, please refer to the previous section “Setpoints” on page 3-35.

View Time As

The **View Time As** button lets you choose whether you wish to have the counter in the time box of the “Home” screen run up or down while the centrifuge is spinning. The options are:

- Elapsed: Makes the timer run forward in continuous mode or up to the time setpoint in a timed run.
- Remaining: Makes the timer count down to zero from the time setpoint.

Proceed as follows to toggle between count-up and count-down timer modes:

- Tap the **Settings** icon  on the navigation bar.
- Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
- Tap the **View Time As** menu and choose **Elapsed** to have the timer run forwards (factory default), or **Remaining** to have it run backwards.
- Tap the **Save** button to save the new timer mode.
A pop-up window appears, indicating that the timer mode has been successfully changed.
- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.

Pulse Customization

The **Pulse Customization** button opens the “Pulse Customization” screen that lets you set the default behavior for the Pulse button  on the “Home” screen. The following options are available for customizing the Pulse button:

- Continuous (factory default): This option makes the centrifuge run continuously at the maximum speed of the rotor until you stop it by tapping the Pulse button  or Stop button  on the “Home” screen.
- Max speed: This option makes the centrifuge spin up to maximum speed and then stop.
- 15sec, 30sec, 1min: These options delay the start of the time counter until maximum speed has been reached.

Proceed as follows to select the default behavior for the Pulse button :

- Tap the **Settings** icon  on the navigation bar.
- Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
- Tap the **Pulse Customization** button.
The “Pulse Customization” screen appears.
- Choose an option.
- Tap the **Save** button to save the new mode for the Pulse button .
A pop-up window appears, indicating that the Pulse button  has been successfully customized.
- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.

Door Auto Open

This menu lets you preset the door of the centrifuge to remain closed or unlock automatically once the run is complete. The drop-down list has two options only:

- Yes: Door will unlock automatically once the centrifugation run is complete.
- No: Door will remain closed after the end of the centrifugation run.

Proceed as follows to toggle between the auto-open and closed modes of the centrifuge door:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Door Auto Open** menu and choose **Yes** to have the door unlocked, or **No** to keep it closed (factory default).
4. Tap the **Save** button to save the open/closed default setting for the centrifuge door.
A pop-up window appears, indicating that the setting has been successfully saved.
5. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.

Compressor Off

The **Compressor Off** button opens the “Compressor Off” screen. On refrigerated centrifuges, this screen lets you set an energy-saving timer that turns off the compressor after a selectable period of inactivity.

NOTICE This screen is not present on ventilated models.

The following options are available for the compressor inactivity timer:

- Never (factory default): This option keeps the compressor running while the centrifuge is powered up, so you can tap the Pre-temp button on the Home screen and start pre-tempering of samples instantaneously.
- 30min, 1hr, 4hrs, 8hrs: These options turn off the compressor automatically after the selected period of inactivity. When you tap the Pre-temp button on the “Home” screen, you save energy but you may have to wait for the compressor to run up before the pre-tempering of your samples is started.

Proceed as follows to activate the inactivity timer for the compressor:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Compressor Off** button.
The “Compressor Off” screen below appears.
4. Choose an option.
5. Tap the **Save** button to save the new inactivity timer for the compressor.
A pop-up window appears, indicating that the timer for the compressor has been successfully set.
6. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.

Scheduling

The **Scheduling** button takes you to the “Scheduling” screen, where you can configure the refrigeration system to automatically turn on and/or off at specified times once per day for each day of the week.

You can set up one “Auto On” and “Auto Off” schedule and activate one or both right away, or keep one or both disabled for later use.

Auto On Scheduling

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Scheduling** button on the “Controls” screen.
The “Scheduling” screen appears.
If you have not configured any schedules yet, both the “Auto On” and “Auto Off” schedules will be disabled.
4. Tap the **Edit** button for the “Auto On” option to start setting up a schedule.
The “Edit Auto On” screen appears.
5. Tap on any day of the week—for example, M(onday).
6. Tap on **AM** or **PM** to select the period of the day

NOTICE The AM/PM division does not appear when the radio button in the “Settings -> Display -> Time”

screen is set to 24hr (see “Time” on page 3-44 for details).

7. Tap the **Time On** field and enter the time of day at which you wish the centrifuge to start.
8. Tap the **Temp** field (refrigerated models only) and set the target temperature for pre-tempering, if desired.

NOTICE Observe the note about cooling and take precautions to ensure that the centrifuge door is closed at the specified start time.

9. Tap more days and repeat this procedure for as many days of the week as required.
10. Tap the **Save** button to save the new “Auto On” schedule for the centrifuge.

A pop-up window appears, alerting you to the risk of condensation pools freezing over in the centrifugation chamber.

NOTICE Observe the condensation warning and take precautions to prevent condensation from freezing in the centrifugation chamber.

11. To confirm the changes, tap the **OK** button in the pop-up window shown above.
You will be returned to the “Schedule” screen.
12. On the “Schedule” screen, tap **the slider** above the schedule field, so it changes to **Enabled**.
Your “Auto On” schedule is active now, the centrifuge will turn on automatically at the specified times.

Auto Off Scheduling

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Scheduling** button on the “Controls” screen.
The “Scheduling” screen appears.
If you have not configured any schedules yet, both the “Auto On” and “Auto Off” schedules will be disabled.
4. Tap the **Edit** button for the “Auto Off” option to start setting up a schedule.
The “Edit Auto Off” screen appears.
5. Choose the day(s) of the week and set the stop times as described further above for “Auto On”.
6. Tap the **Auto open door** checkbox to have the centrifuge door open automatically after the centrifugation run, if desired.

NOTICE Observe the notes about how an open centrifuge door interferes with “Auto On” and about the requirement to open the centrifuge door along with “Auto Off” after cooling to prevent condensation.

7. Tap more days and repeat this procedure for as many days of the week as required.
8. Tap the **Save** button to save the new “Auto On” schedule for the centrifuge.
If you have chosen the “Auto Open Door” option, a pop-up window appears to alert you to the risk that an open door interferes with the next “Auto On” schedule.
NOTICE Observe the warning about the open door and take precautions to have the door closed before the next “Auto Off” schedule is effective.
9. To confirm the changes, tap the **OK** button in the pop-up window shown above.
You will be returned to the “Schedule” screen.
10. On the “Schedule” screen, tap **the slider** above the schedule field, so it changes to **Enabled**.
Your auto-off schedule is active now. The centrifuge will turn off automatically at the specified times.
The two sliders above the “Auto On” and “Auto Off” fields read “Enabled” (see Figure 3-63).




Figure 3-63: Settings -> Scheduling -Screen with All Schedules Disabled

Rotor Bucket

The **Rotor Bucket** button takes you to the “Rotor Bucket” screen. The “Rotor Bucket” screen allows you to enable and set the default bucket selection for the rotor detection prompt (see “Identify Rotor and Buckets” on page 2-10). Experience has shown that many users have a preferred bucket type for each rotor. Having this bucket identified as the default selection in the rotor detection prompt saves valuable time during the set-up process.

If there is no need to confirm bucket type in the rotor detection prompt because you do not use any other bucket type, the bucket type prompt can be disabled altogether.

Proceed as follows to set up a default rotor bucket selection:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Controls** button  on the “Settings” screen.
The “Controls” screen appears.
3. Tap the **Rotor Bucket** button.
The “Rotor Bucket” screen appears.
4. Tap on either of the drop-down lists to select a different bucket type.
If there is no need to confirm bucket type in the rotor detection prompt, disable the “Prompt for ...” rotor bucket at the start of each run checkbox.
5. Tap the **Save** button to save the default selections for the rotor detection prompt.
A pop-up window appears, indicating that the setting has been successfully saved.
6. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Controls” screen.

3. 7. Display

Tapping the **Display** button  on the “Settings” screen takes you to the “Display” screen. The “Display” screen offers a stack of buttons. These buttons allow for customizing general display properties for all screens of the Graphical User Interface to suit your needs, altering the factory default settings. The options on the “Display” screen include:

- “Brightness”
- “Language”
- “Auto Date/Time”
- “Date”
- “Time”
- “Region”
- “Unit Name”

The “Display” screen holds more options than would fit on one screen. Therefore, it has a scrollbar on the right side of the button stack.




Figure 3–64: Settings -> Display Screen

By tapping the scrollbar and dragging, you can display the options that are currently hidden.

Selections are made by dragging a slider or tapping **drop-down lists** on the screen. You may change one, several, or all of the options before confirming your selections with the **Save** button.

3. 7. 1. Brightness

If the ambient lighting conditions make the centrifuge’s display unit difficult to read, you can change the brightness directly on the “Display” screen. This is achieved by tapping on the “Brightness” slider and dragging.



Figure 3–65: Settings -> Display Screen -> Brightness

Proceed as follows to change the brightness:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Display** button  on the “Settings” screen.
The “Display” screen appears.
3. Tap the **Brightness** slider and drag to the left to decrease and or to the right to increase. Alternatively, you can tap the  or  buttons on both sides of the slider to decrease or increase.
The screen dims down or brightens up as you drag the slider.
If you make any changes, the Save button at the bottom of the screen is highlighted.
4. When you have finished adjusting brightness, tap the **Save** button to save the new brightness setting for the display unit.

- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will be returned to the “Display” screen.

3. 7. 2. Language

The **Language** button on the “Display” settings screen opens the “Language” screen where you may choose a display language of your choice, other than English (which is the factory default). This setting overwrites the display language selection made during the initial setup (see “Initial Startup” on page 1-14).

Proceed as follows to set the display language:

- Tap the **Settings** icon  on the navigation bar.
- Tap the **Display** button  on the “Settings” screen.
The “Display” screen appears.
- Tap the **Language** button on the “Display” screen.
The “Language” screen appears with a wheel picker, prompting you to choose a display language.
- Swipe your finger up or down across the wheel to set the language (default is English).
If you make any changes, the Save button at the bottom of the screen is highlighted.
- When you have finished choosing the language, tap the **Save** button.
- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will find the display language changed on the Graphical User Interface.

You will be returned to the “Display” screen.

3. 7. 3. Auto Date/Time

If the centrifuge is connected to the Local Area Network (LAN) through its ethernet port, setting the “Auto/Date Time” option ensures that it synchronizes its date, time and region information with the active network.

NOTICE The “Auto Date/Time” setting overrides and disables the separate settings for date, time, and region discussed in the following sections. If you prefer to set date, time, and/or region manually, you must turn this setting to “Off”.

Proceed as follows to toggle Auto Date/Time on and off:

- Tap the **Settings** icon  on the navigation bar.
- Tap the **Display** button  on the “Settings” screen.
The “Display” screen appears.
- Tap the **Auto Date/Time** pop-up menu and choose On to enable automatic date and time synchronization, or “Off” to disable it (in which case you have to set date, time and region manually).
If you make any changes, the Save button at the bottom of the screen is highlighted.
- When you have finished, tap the **Save** button to save the new setting for the centrifuge.
- To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will be returned to the “Display” screen.

With “Auto Date/Time” enabled, you will find the Date, Time, and Region buttons grayed out.

3. 7. 4. Date

The **Date** button on the “Display” screen opens the “Date” screen. The “Date” screen lets you set the date that appears in a date field in the “Info & Health Status” area on top of the “Home” screen.

Proceed as follows to set the date:

- Tap the **Settings** icon  on the navigation bar.
- Tap the **Display** button  on the “Settings” screen.
- Tap the **Date** button on the “Display” screen.
The “Date” screen appears with a wheel picker, prompting you to set the date.
- Tap the **MM/DD/YYYY**, **DD/MM/YYYY**, or **YYYY/MM/DD** radio button on the left side of the screen to choose a date format.

The segments of the wheel picker screen are rearranged to reflect the selected date format. For example, if you select the DD/MM/YYYY radio button, the wheel picker will change to 28 | Jul | 2018.

5. Tap the up/down arrows or swipe your finger up or down across the wheel to set the current month, day, and year on each of the three wheel picker segments.

If you have made any changes, the Save button at the bottom of the screen is highlighted.

6. When you have finished setting the date, tap the **Save** button.
7. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will be returned to the “Display” screen.

3.7.5. Time

The **Time** button on the “Display” screen opens the “Time” screen. The “Time” screen lets you set the time of day that appears in a time field in the “Info & Health Status” area on top of the “Home” screen.

Proceed as follows to set the date:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Display** button  on the “Settings” screen.
3. Tap the **Time** button on the “Display” screen.

The “Time” screen appears with a three-segmented wheel picker, prompting you to set the time of day.

4. If desired, tap the **24hr Display** radio button on the left side of the screen to choose the Central European Time (CET; 24-hour) time format. (Default time format is AM/PM, 12-hour format.)

The segments of the wheel picker screen are rearranged to reflect the Central European Time (CET; 24-hour) time format.

5. Tap the up/down arrows or swipe your finger across each wheel up or down to set the current time in hours and minutes.

If you have made any changes, the Save button at the bottom of the screen is highlighted.

6. When you have finished setting the time of day, tap the **Save** button.
7. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will be returned to the “Display” screen.

3.7.6. Region

The **Region** button on the “Display” screen opens the “Region” screen. The “Region” screen lets you set the region for your lab location to ensure that Daylight Saving Time (DST) is observed in the time-of-day displays of the centrifuge, and that the time of day is automatically updated when DST changes.

It saves you the trouble of having to change to daylight saving time and back twice a year and keeps the event log and charting data accurate.

Proceed as follows to select your region:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Display** button  on the “Settings” screen.
3. Tap the **Region** button on the “Display” screen.

The “Region” screen appears, prompting you to enter the region where your site is located and specify whether DST is applicable.

4. Tap on the **City/Country** field and type the first three letters of the next larger city.

The system will automatically start to look ahead after three letters and propose a list of matching cities and countries.

If you type or select a city and country that does not use DST, the system also automatically deselects the “Adjust for Daylight Saving Time” checkbox.

5. If you wish to disable DST explicitly, deselect the “Adjust for Daylight Saving Time” checkbox. (The default setting is on.)

If you have made any changes, the Save button at the bottom of the screen is highlighted.

6. When you have finished setting the time of day, tap the **Save** button.
7. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.

You will be returned to the “Display” screen.

3.7.7. Unit Name

The **Unit Name** button opens the “Unit Name” screen, where you can set a name for the centrifuge that will be displayed above the time/date field in the “Info & Health Status” area on top of the “Home” screen.

Proceed as follows to edit the name of the unit:

1. Tap the **Settings** icon  on the navigation bar.
2. Tap the **Display** button  on the “Settings” screen.
3. Tap the **Unit Name** button on the “Display” screen.
The “Unit Name” screen appears, prompting you to name the centrifuge.
4. Inspect the “Unit Name” field:
If no unit name has been previously set, the “Unit Name” field will read “Tap to enter”.
If a unit name has been previously set, that name appears in the “Unit Name” field.
5. Tap on the **Unit Name** field to display the keypad.
If no unit name has been previously set, a cursor will appear in the “Unit Name” field and prompt you to start typing.
If a unit name has been previously set, that name will be selected for overwriting.
6. Type the desired unit name.
7. When you have finished typing, do one of the following:
 - a. Tap the **Save** button on the keypad.
 - b. Tap anywhere outside of the keypad and the “Unit Name” field to hide the keypad, then tap the **Save** button at the bottom of the screen.
8. To confirm the changes, tap the **OK** button in the pop-up window that appears. Tapping the **X** icon  closes this window and exits without saving.
You will be returned to the “Display” screen.

3.8. Logs

Tapping the **Logs** button on the navigation bar opens the “Logs” main screen shown in Figure 3–66 below. The “Logs” main screen is the point of entry to all operating data logged by the centrifuge.




Figure 3–66: Logs Main Screen

The “Logs” main screen features three buttons that open detailed log screens, where you can view and export data:

- Event Log, described in the following section.
- Rotor Log, described in the section “Rotor Log” on page 3-48.
- Chart, described in the section “Chart” on page 3-49.

3.8.1. Event Log

Tapping the **Event Log** button on the “Logs” main screen opens the “Event Log” screen shown in Figure 3–67 below. The “Event Log” screen lists the last 100 events logged by the centrifuge with their time of occurrence, including normal operating status as well as abnormal conditions, such as alarms. The newest events appear at the top of the list, the oldest events at the bottom. Once the centrifuge log reaches 100 events, the newest events will replace the oldest ones.

A pop-up menu next to the event list allows for filtering the log to show selected classes of events only.




Figure 3–67: Event Log Screen

You can tap on any row to expand it and view additional information about one specific event.




Figure 3–68: Event Log Screen with Event Expanded

Additionally, you can export the event log data in Comma Separated Value format (CSV) for further processing in spreadsheets, or in Portable Document Format (PDF) for instant viewing and printing.

Viewing Events

Proceed as follows to navigate the event list and view more detailed information:

1. Tap the **Logs** icon  on the navigation bar.
The “Logs” main screen appears.
2. Tap the **Events** button.
The “Event Log” screen appears.
3. If necessary, tap and drag the scrollbar to the right of the events list to see more events.
4. Tap on the chevron on the far right end of each event list item to view more details for an individual event.
5. Tap on the **View All** pop-up menu to expand a list of filtering options.
6. Tap on any checkbox to deactivate a whole class of events.

NOTICE You can save finger gestures by tapping the “View All” checkbox to deactivate all options, then reactivate the one or two options you wish to retain.

NOTICE The “View All” checkbox is deactivated automatically when you deactivate any of the other options. If you are not satisfied with the selection you have made, it may be helpful to tap “View All” and start over selecting.

7. Tap anywhere outside the filter pop-up menu to return to the “Event Log” screen.
You will find a reduced event list in the “Event Log” screen and the title of the pop-up menu changed to “Filter ON”.
8. To remove the filter and show all events, tap **Filter ON** to expand the filter pop-up menu and reactivate the “View All” option.

NOTICE The filter is not saved. If you navigate away from the “Event Log” screen, you will find that it has reverted to showing all events the next time you return here.
9. Tap on the **Chart** button to view the events as a chart (see “Viewing Charts” on page 3-49).

Exporting the Event Log

Proceed as follows to export the event log:

1. Tap the **Logs** icon  on the navigation bar.
The “Logs” main screen appears.
2. Tap the **Events** button.
The “Event Log” screen appears.
3. Tap the **Export Log** button to start the export of the event log.
The “Export Event Log” screen appears, listing your export options for the event log.
4. Choose either **CSV** if you wish to process the event log data in a spreadsheet, or **PDF** if you want to obtain a document for instant viewing and printing.
5. Tap the **Events to Export** drop-down menu and filter the events as explained further above in the section “Viewing Events” on page 3-46.
6. Select a date range by tapping either **1 Day**, **7 Days**, **60 Days**, or **Custom**.
Tapping Custom displays two additional date entry fields that let you choose a specific period of time to export.
7. Tap the **Calendar** icon next to the From field.
The “Custom Date Range From:” wheel-picker shown on the left side appears,
8. Spin the wheel-picker and adjust the calendar to the desired date, for example April 15, 2015.
9. Tap the **Set From Date** button to confirm your choice,
You will be returned to the “Export Event Log” screen.
10. Tap the **Set To Date** button to confirm your choice,
You will be returned to the “Export Event Log” screen above.
11. Tap the **Export** button in the “Export Event Log” screen to start the export,
The export will start now, as indicated by the “Export Event Log” pop-up window. It shows a cautioning message not to remove the USB drive and a green and gray progress bar that lets you follow the process. If you have not inserted a USB drive into the USB port of the centrifuge, the “Export Event Log” pop-up window appears, prompting you to insert a USB drive.

NOTICE You may abort a running export at any time by tapping the Cancel button in the “Export Event Log” pop-up window. If you do so, the export is aborted, and the “Export Canceled” message appears. Acknowledge the message and repeat the export with an alternative selection of event log, if necessary.

NOTICE While the export is running, make sure you do not remove the USB drive from the USB port. If you do so, the export is aborted, and the “Export Error” message appears.

NOTICE While the export is running, the USB drive may run out of disk space. If that happens, the export is aborted, and the “Export Error” message appears. Free up space on the USB drive and repeat the export of the event log.

When the export has been successfully completed, the “Export Complete” pop-up window appears. Tap the **OK** button to acknowledge the message and remove the USB drive.

On your USB drive, you will find a new file with the general filename **UnitName_EventLog_YYYY_MM_DD.csv** or **UnitName_EventLog_YYYY_MM_DD.pdf** now.

3. 8. 2. Rotor Log

Tapping the **Rotor Log** button on the “Logs” main screen opens the “Rotor Log” screen. The “Rotor Log” screen keeps track of how many times individual rotor (bucket) types have been spun in the current centrifuge and issues warnings when a rotor reaches its end of life.




Figure 3–69: Rotor Log Screen

Each time a new rotor is installed in the unit, the rotor log is updated to reflect:

- Rotor Name (if it has not already been listed)
For a rotor with swinging buckets, the rotor name must also include the bucket type identified by the user (see “Identify Rotor and Buckets” on page 2-10). For example, the name for a TX-750 rotor with round buckets would read TX-750 (Round Bucket - 75003608).
- Total Spin Cycles (how often the rotor type has been spun in the current centrifuge).
- Remaining Cycles (how many times the rotor type can still be spun in the current centrifuge).
- Last Run (last date the rotor type was used in the current unit).

Deleting a Rotor from the Log

The “Rotor Log” screen lets you delete a rotor from the log—for example, one that has reached its end of life. Proceed as follows to delete a rotor type from the log:

1. Tap the **Minus** icon  to the right of the rotor entry:
The “Delete Rotor” pop-up window appears, asking you to confirm the deletion.
2. Tap the **Delete** button to confirm.

Resetting the Rotor Counter

The “Rotor Log” screen allows you to reset the cycle counter for a rotor type to zero. Proceed as follows to reset the counter for a rotor type:

1. Tap the **Reset** icon  to the left of the rotor type name:
The “Reset Counter” pop-up window appears, asking you to confirm the deletion.
2. Tap the **Reset** button to confirm.

Exporting the Rotor Log

Proceed as follows to export the rotor log:

1. Tap the **Logs** icon  on the navigation bar.
The “Logs” main screen shown in Figure 3–66 above appears.
2. Tap the **Rotor Log** button.
The “Rotor Log” screen appears.
3. Tap the **Export Rotor Log** button to start the export of the rotor log.
The export will start now, as indicated by the “Export Rotor” Log pop-up window below. It shows a cautioning message not to remove the USB drive and a green and gray progress bar that lets you follow the process. If you have not inserted a USB drive into the USB port of the centrifuge, the “Export Rotor Log” pop-up window appears, prompting you to insert a USB drive. If necessary, insert the USB drive into the USB port of the centrifuge.

NOTICE You may abort a running export at any time by tapping the Cancel button in the “Export Rotor Log” pop-up window above. If you do so, the export is aborted, and the “Export Canceled” message appears. Acknowledge the message and repeat the export, if necessary.

NOTICE While the export is running, make sure you do not remove the USB drive from the USB port. If you do so, the export is aborted, and the “Export Error” message appears. Reinsert the USB drive and repeat the export.

NOTICE While the export is running, the USB drive may run out of disk space. If that happens, the export is aborted, and the “Export Error” message appears. Free up space on the USB drive and repeat the export.

When the export has been successfully completed, the “Export Complete” pop-up window appears. Tap the **OK** button to acknowledge the message and remove the USB drive.

On your USB drive, you will find a new file with the general filename **UnitName_Rotor LogData_YYYY_MM_DD.csv** now.

3. 8. 3. Chart

Tapping the **Chart** button on the “Logs” main screen opens the “Chart” screen. The “Chart” screen lists the last 100 runs of the centrifuge. The newest runs appear at the top of the list, the oldest runs at the bottom. Once the centrifuge reaches 100 runs, the newest runs will replace the oldest runs.




Figure 3–70: Chart Screen

The Chart screen lets you do two things:

- tap on any of the rows in the chart list to display the chart for the selected run
- select all or individual runs and export the data

Viewing Charts

Proceed as follows to view a detailed chart for an individual run:

1. Tap the **Logs** icon  on the navigation bar.
The “Logs” main screen appears.
2. Tap the **Chart** button.
The “Chart” screen appears.
3. If necessary, tap and drag the scrollbar to the right of the charts list to see more charts.
4. Tap on the **chart list item** you wish to view.
The “Chart” details screen appears. The left axis shows speed data, the right axis shows temperature data (refrigerated models only; ventilated models will only show speed).




Figure 3-71: Chart Details Screen

5. Use finger gestures to move around the chart:
 - » Pinch to zoom in and out.
 - » Swipe left or right to navigate back in time or back to the current time.
 - » Tap and drag to scroll to a specific time period.

Exporting Chart Data

Proceed as follows to export chart data:

1. Tap the **Logs** icon  on the navigation bar.
The “Logs” main screen appears.
2. Tap the **Chart** button.
The “Chart” screen appears.
3. If necessary, tap and drag the scrollbar to the right of the charts list to locate the desired chart.
4. **Select individual runs** by activating the checkboxes next to the items you would like to export, **or** tap the **Select All** checkbox at the top of the screen to select all available runs.
5. Tap the **Export Chart Data** button to start the export of the selected charts.

The export will start now, as indicated by the “Export Chart Data” pop-up window below. It shows a cautioning message not to remove the USB drive and a green and gray progress bar that lets you follow the process. If you have not inserted a USB drive into the USB port of the centrifuge, the “Export Chart Data” pop-up window appears, prompting you to insert a USB drive. If necessary, insert the USB drive into the USB port of the centrifuge.

NOTICE You may abort a running export at any time by tapping the Cancel button in the “Export Chart Data” pop-up window. If you do so, the export is aborted, and the “Export Canceled” message appears. Acknowledge the message and repeat the export with an alternative selection of charts, if necessary.

NOTICE While the export is running, make sure you do not remove the USB drive from the USB port. If you do so, the export is aborted, and the “Export Error” message appears.

NOTICE While the export is running, the USB drive may run out of disk space. If that happens, the export is aborted, and the “Export Error” message appears. Free up space on the USB drive and repeat the export with a new selection of charts.

When the export has been successfully completed, the “Export Complete” pop-up window appears. Tap the **OK** button to acknowledge the message and remove the USB drive.

On your USB drive, you will find a new file with the general filename **UnitName_ChartData_YYYY_MM_DD.csv** now.

Files and Info

Tapping the **Files and Info** button on the navigation bar takes you to the “Files and Info” screen. The “File and Info” screen lets you view technical information about the centrifuge, such as serial number and installed firmware versions, and reset the centrifuge to its factory settings.




Figure 3-72: Files and Info Screen

Proceed as follows to reset the centrifuge to its factory settings:

1. Back up all data from the centrifuge you wish to preserve, such as user programs (see “Sharing Programs between Centrifuges” on page 3-26) and logs (see “Logs” on page 3-45).
2. Tap the **Files and Info** icon  on the navigation bar.
The “Files and Info” screen appears.
3. Tap the **Factory Reset** button.
The “Factory Reset” screen appears, cautioning you about the risk of losing settings.
4. If you are absolutely sure that you want to reset the centrifuge to its factory settings, tap the **Start** button to initiate the reset process.
The “Factory Reset” pop-up window appears. A progress bar lets you follow the process.
When the “Factory Reset” process is complete, the (Factory Reset) “Complete” pop-up window appears.

3. 8. 4. Service

The **Service** button is reserved to service technicians and requires a special passcode. Its options are not explained in this manual.

4. LCD Control Panel

This chapter contains details for the centrifuges with the LCD display described in this manual. Pictures shown are examples and may be different in details to your experience—for example, the LCD display for a ventilated unit does not have a key for entering temperature, nor a temperature readout.

NOTICE This chapter shows examples for refrigerated models only.

4.1. Overview

The LCD display combines a single-line LCD (Liquid Crystal Display) screen with membrane-protected keys for choosing commands or increasing and decreasing parameter values. Figure 4–1 presents the arrangement of the LCD screen areas and keys described in the following.




Figure 4–1: Functions on the LCD Control Panel

4. 2. Set Basic Centrifugation Parameters

This section explains how to set up the centrifuge with speed / RCF values, acceleration and deceleration profiles, temperature (refrigerated models only), and other operating parameters.

4. 2. 1. Set Speed / RCF-Value

The centrifuge lets you set speed in rpm or as an RCF value (see “RCF Value Explained” below). You may set speed either from within an ongoing centrifugation run (centrifuge running) or for the next centrifugation run (centrifuge at standstill).

RCF Value Explained

The relative centrifugal force (RCF) is given as a multiple of the force of gravity (g). It is a unitless numerical value which is used to compare the separation or sedimentation capacity of various centrifuges, since it is independent of the type of device. Only the centrifuging radius and the speed are used for calculation:

$$RCF = 11,18 \times \left(\frac{n}{1000} \right)^2 \times r$$

r = centrifuging radius in cm

n = rotational speed in rpm

The maximum RCF value is related to the maximum radius of the tube opening.

Remember that this value is reduced depending on the tubes, buckets and adapters used.

This can be accounted for in the calculation above if required.

Proceed as follows to set a speed or RCF value:

1. Press the **Arrow** keys below the xg / rpm LED indicators (left in Figure 4–2) to toggle between RCF (in xg, which means multiples of the force of gravity) and speed (in rpm, which is short for revolutions per minute).

The LED indicator **xg** or **rpm** is lit to indicate the selected mode, and the value in the LCD display switches to an **RCF** or **rpm** reading. The example in Figure 4–2 shows the rpm reading (bottom) and the equivalent RCF reading (top).




Figure 4–2: Choosing between RCF / rpm and setting the Centrifuge Speed

2. Press the **+** or **-** key below the **Speed** field of the LCD display to set the desired value.

NOTICE If you select an extremely low RCF value, it will be automatically corrected if the resulting speed is less than 300 rpm. 300 rpm is the lowest selectable speed.

3. Release the **+** or **-** key when the desired value appears.

Doing so selects the speed setting for future centrifugation runs (until the next time you choose to change this setting).

4. 2. 2. Set Run Time

The centrifuge lets you preset a run time after which the centrifugation run stops automatically.

Proceed as follows to set run time:

1. Press the **+** or **-** key below the **Time** field of the LCD display to set the desired duration for the centrifugation run.

The value displayed in the **Time** field (see Figure 4-3 below) changes accordingly.




Figure 4-3: Setting the Centrifuge Run Time

2. Release the key when the desired runtime in hours and minutes appears.

Doing so selects the runtime setting for future centrifugation runs (until the next time you choose to change this setting) .

4. 2. 3. Set Acceleration and Deceleration Profiles

The centrifuge offers a total of 9 acceleration curves (numbered 1 through 9). An acceleration curve gradually increases the speed of the centrifuge after starting the centrifugation run. An acceleration profile gradually increases the speed of the centrifuge after starting the centrifugation run. A deceleration profile gradually reduces the speed of the centrifuge towards the end of the centrifugation run.

NOTICE After the centrifuge is turned on, the last running profile selected is shown.

NOTICE Avoid if possible speed ranges close to natural resonances of the system. Runs at resonance speeds may have show vibration and an adverse effect on the quality of separation.

Acceleration Profile

Proceed as follows to select an acceleration curve:

1. Press the **+** or **-** key below the **Acceleration** field of the LCD display to cycle through the selection of available acceleration profiles.

Curve number 1 provides the slowest and curve number 9 the fastest acceleration rate.



Figure 4-4: Setting the Acceleration Profile

2. Release the **+** or **-** key when the number of the desired acceleration profile appears in the display window.

Doing so selects the acceleration profile for future centrifugation runs (until the next time you choose to change this setting) .

Deceleration Profiles

The centrifuge offers a total of 10 deceleration or braking curves (numbered 0 through 9). A deceleration curve gradually reduces the speed of the centrifuge towards the end of the centrifugation run.

NOTICE After the centrifuge is turned on, the last running profile selected is shown.

Proceed as follows to select a braking curve:

1. Press the **+** or **-** key below the **Deceleration** field of the LCD display window to cycle through the selection of available deceleration profiles.

Curve number 0 disables active deceleration altogether. Curve number 1 provides the slowest active and curve number 9 the fastest active deceleration rate.



Figure 4-5: Setting the Deceleration Profile

2. Release the **+** or **-** key when the number of the desired deceleration profile appears in the display window. Doing so selects the deceleration profile for future centrifugation runs (until the next time you choose to change this setting).

4. 2. 4. Pre-Temper the Centrifugation Chamber

Refrigerated centrifuges allow for pre-tempering, that is pre-warming or pre-cooling, the centrifugation chamber and the empty rotor before the centrifugation run starts. If necessary pre-temper your samples using proper equipment. The centrifuge is not intended to be used to pre-temper your samples. Temperatures displayed by the centrifuge are the estimated sample temperatures.

NOTICE This feature is not available on ventilated models.

To set the pre-tempering temperature for the centrifuge, proceed as follows:

1. Insert the rotor with all buckets installed.
2. Press the **PreTemp** key to enable pre-tempering adjustment.



Figure 4-6: Setting the Pre-cooling or Pre-warming Temperature (left)

3. Press the **+** or **-** key and hold it until the desired temperature appears.
4. Release the **+** or **-** key when the desired temperature appears above the **PreTemp** key. The centrifuge starts heating or cooling the rotor chamber to the preset temperature. The current rotor chamber temperature displayed to the right of the selected pre-tempering value starts to change towards the desired value.
5. Wait until the sample chamber temperature indicator is at the same value as the pre-tempering temperature.

4. 2. 5. Set Temperature

A refrigerated centrifuge allows for preselecting a rotor chamber temperature between -20 °C and +40 °C for the centrifugation run. Temperatures displayed by the centrifuge are the estimated sample temperatures.

⚠ CAUTION Due to air friction sample integrity may be affected. The temperature of the rotor may rise significantly while the centrifuge is spinning. Refrigerated units can have a deviation from displayed and set temperature to the sample temperature. Make sure the centrifuge temperature control capabilities meet your application specification. If necessary make a test run.

NOTICE This feature is not available on ventilated models.

Proceed as follows to preselect a temperature for the centrifugation run:

1. Press the **+** or **-** key below the **Temperature** field of the LCD display window (see Figure 4–7) to adjust the desired rotor chamber temperature.



Figure 4–7: Setting the Temperature for the Centrifugation Run (right)

2. Release the **+** or **-** key when the desired temperature appears above the key.
Doing so selects the temperature for future centrifugation runs (until the next time you choose to change this setting) .

4. 2. 6. Select the Bucket Type

Bucket selection is only possible for swing-out rotors. The bucket code corresponds to the last four digits of the article number of the bucket.

Proceed as follows to select the bucket type installed in the rotor:

1. Press the **+** or **-** key below the **Bucket** field of the LCD display window (see Figure 4–8) to select the correct bucket code for the buckets installed in your rotor.



Figure 4–8: Setting the Correct Bucket Code for the Rotor

2. Press the **Bucket** key repeatedly until the bucketcode of the bucket being used is displayed.
3. Release the **+** or **-** key when the desired bucket code appears above the key.
Doing so selects the bucket code for future centrifugation runs (until the next time you choose to change this setting).

4. 3. Programs

To reduce the setup effort before a centrifugation run, the centrifuge lets you enter a selection of desired program parameters and store them together as a program that may be retrieved for later use. You can include all or part of the run parameters explained in previous sections of this chapter, including:

- acceleration and braking profile
- speed or RCF value
- running time
- temperature
- bucket type by code

Setting Up and Saving a Program

All centrifuge models described in this section let you store up to six programs using dedicated front panel keys. You can retrieve and start the programs later on by pressing the program key assigned during storage.

Proceed as follows to store a program:

1. Set your choice of run parameters in one go, as explained for your centrifuge model in the previous sections of this chapter.
2. Press any of the program selection keys  for 4 seconds.

Your program is stored now.

For instructions on how to start a previously stored program, please refer to the section “Program Mode Operation” on page 4-7.

4. 4. Centrifugation

Mind the safety zone of minimum 30 cm around the centrifuge. Refer to “Safety Zone” on page 1-1. Persons and hazardous substances must be kept out of this safety zone while centrifuging.

Once the rotor has been properly installed, the main power switch has been turned on and the centrifuge door has been closed, you are ready to start centrifuging.

You have various options to start a centrifugation run:

- Continuous Mode: This is a fully manual mode. In Continuous Mode you use the **Start** key  and **Stop** key  to start and stop centrifugation manually, as explained in the section “Continuous Operation” further below.
- Timed Mode: This is a semi-automatic mode that relies on a timer. If you have preset a runtime (see “4. 2. 2. Set Run Time” on page 4-3), you press the **Start** key , then wait for the timer to expire and the centrifuge to stop automatically.
- Program Mode: This is a fully automatic mode. You prepare and save an automated program, as explained in the section “Setting Up and Saving a Program” on page 4-6, then run it by pressing the appropriate program selection key .



WARNING

Damage to health from centrifuging explosive or flammable materials or substances. Do not centrifuge explosive or flammable materials or substances.

Continuous Mode Operation

Proceed as follows to run the centrifuge in continuous, manual stop mode of operation.

1. Set the desired parameters, as explained in the section “4. 2. Set Basic Centrifugation Parameters” on page 4-2.

NOTICE Speed (see “4. 2. 1. Set Speed / RCF-Value” on page 4-2) must be set as a minimum requirement.

2. Press the **Start** key  on the control panel.

The centrifuge starts running up to the pre-set speed. The LCD display changes to reflect the acceleration process until the centrifuge reaches the pre-set speed.

When the centrifuge has accelerated to the pre-set speed, the timer starts counting the elapsed time.

3. Press the **Stop** key  when you have finished centrifuging.

NOTICE You cannot open the centrifuge door as long as the centrifuge is spinning.

Timed Mode Operation

Proceed as follows to run the centrifuge in timed mode of operation.

1. Set the desired parameters, as explained in the section “4. 2. Set Basic Centrifugation Parameters” on page 4-2.

NOTICE Speed (see “4. 2. 1. Set Speed / RCF-Value” on page 4-2) and runtime (see “4. 2. 2. Set Run Time” on page 4-3) must be set as a minimum requirement.

2. Press the **Start** key  on the control panel.

The centrifuge starts running and the LCD display changes to indicate the correct speed.

The timer starts counting the remaining time when the **Start** key  is pressed.

3. When the remaining time has elapsed, the centrifuge will stop automatically.

NOTICE You cannot open the centrifuge door as long as the centrifuge is spinning.

Program Mode Operation

Proceed as follows to start a previously stored program.

1. Press any of the program selection keys  to select a program.

NOTICE There is no need to set any parameters. All settings are included in the program.

2. Press the **Start** key  to start the centrifugation run with the selected program's settings.

The centrifuge starts running up to the pre-set speed.

The LCD display changes to reflect the acceleration process until the centrifuge reaches the pre-set speed.

When the centrifuge has accelerated to the pre-set speed, the timer starts counting the remaining time.

3. When the remaining time has elapsed, the centrifuge will stop automatically.

NOTICE You cannot open the centrifuge door as long as the centrifuge is spinning.

Handling Error Messages

Error messages may occur when you try to start the centrifuge. Frequent root causes include the following:

- Set speed exceeds admissible speed for rotor
- Imbalanced load
- Unapproved rotor found by rotor detection

A detailed list of error messages and troubleshooting instructions appear in the section “Troubleshooting by Guide” on page 6-3.

4. 5. Stop an Ongoing Centrifugation Run

You can stop the centrifuge at any time by pressing the **Stop** key  on the control panel.

Proceed as follows to stop an ongoing centrifugation run:

1. Press the **Stop** key  on the control panel.

2. Wait for the speed drop to zero.

The message END appears in the LCD display.

You can now open the centrifuge door and remove the centrifuged material, as explained in “How to Install and Remove a Rotor” on page 2-5.

4. 6. System Menu

To enter the system menu hold down any of the keys when powering on the centrifuge.

Use the **+** and **-** keys below Speed in order to navigate through the system menu.

Use the **+** and **-** keys below Bucket in order to navigate within the system menu points.

Within the system menu you can change the settings of the centrifuge. Following settings are available:

1. Language – following languages are supported: English, German, French, Spanish, Italian, Dutch, Russian.
2. End of run beep – select **YES** if the centrifuge shall make beep after the run. Otherwise select **NO**.
3. Keypad beep – select **YES** if the centrifuge shall make beep when pressing any key. Otherwise select **NO**.
4. LCD powersave – select **YES** if the centrifuge shall enter a powersave mode after the run. Otherwise select **NO**.
5. Auto door open – select **YES** if the centrifuge shall open after the run. Otherwise select **NO**.
6. Software ID – the current software version is shown here.
7. Cycle count – the current numbers of cycles are shown here.

5. Maintenance and Care

5.1. Cleaning Intervals

For the sake of personal, environmental, and material protection, you must clean and if necessary disinfect the centrifuge and its accessories on a regular basis.

5.2. Basics

- Use warm water with a neutral detergent that is suitable for use with the materials. If in doubt contact the manufacturer of the cleaning agent.
- Use a soft cloth for cleaning.
- Never use caustic cleaning agents such as soap suds, phosphoric acid, bleaching solutions or scrubbing powder.
- Remove rotor and clean centrifugation chamber with a small amount of cleaning agent on a clean cloth.
- Use a soft brush without metal bristles to remove stubborn residue.
- Afterwards rinse with a small amount of distilled water and remove any remains with absorbent towels.
- Use only cleaning and disinfecting agents with a pH of 6-8.



CAUTION

Not rated procedures or agents could deteriorate the materials of the centrifuge and lead to malfunction. Refrain from using any other cleaning or decontamination procedure, if you are not entirely sure that the intended procedure is safe for the equipment. Use only cleaning agents that will not damage the equipment. In doubt contact the manufacturer of the cleaning agent. If still in doubt, contact Thermo Fisher Scientific.

5.2.1. Rotor and Accessories Inspection

After thoroughly cleaning the rotors, they must be inspected for damage, wear and corrosion.

The cycle limits of the rotors and buckets are stated on some rotors and buckets and in the technical data section of each rotor ("Rotor Specifications" on page B-1).

NOTICE Usage beyond these limits might lead to rotor failure, sample loss and damage to the centrifuge.



CAUTION

Do not run any rotor or accessories with sign of damage. Ensure that the rotor, buckets and accessories are within their expected maximum number of cycles. It is recommended that you have rotors and accessories inspected yearly as part of your routine service to ensure safety.



CAUTION

Inspect sterilized articles upon delivery. Make sure that the protective polyethylene (PE) bags are not damaged. If the PE bags are damaged, do not use the article, sterilization may be compromised. If damaged do not use and call your sales representative.

Metal Parts

Make sure that the protective coating is complete. It can be removed through wear and chemical attack and can lead to unseen corrosion. In case of corrosion, such as rust or white / metallic pitting, the rotor or accessories must be removed from service immediately. Particular attention should be paid to the bottom of buckets on swinging bucket rotors and tube cavities on fixed angle rotors.

Slide Coated Rotors

Rotor crosses are provided with an anti-friction and corrosion resistant finish.

The following procedure is for rotor crosses and rotor trunnion bolts:

- Regular cleaning of contact area between the rotor and buckets (rotor cross trunnions and bucket grooves) is recommended with a mild detergent (every 300-500 cycles).
- The rotor cross is coated with a special advanced lubricating and protective coating, therefore no grease is necessary.
- Contaminating particles (dirt, dust or debris) in the rotor cross and bucket grooves may lead to imbalance

and cleaning will be required.

- The lubricating coating may, over extended periods or under heavy loads, become worn. If this occurs a small amount of greasing of the rotor cross trunnions will be required with bolt grease (75003786).

Plastic Parts

Check for signs of plastic crazing, fading, bruising or cracking. In case of damage the inspected item must be removed from service immediately.

O-Rings

Make sure that O-rings are still smooth, not brittle nor otherwise damaged. Some O-rings are not autoclavable. Replace brittle or damaged O-rings immediately. Refer to “Rotor Specifications” on page B-1 for details on O-rings as spare part.

5. 2. 2. Cycles of Rotors and Buckets

You have to count the cycles of the rotors and buckets using your own method. The centrifuge can not detect the change or replacement of rotors of the same type or of buckets of the same type.

The lifetime of a rotor and buckets depends on the amount of physical load. Do not use rotors and buckets that exceed the maximum number of cycles.

The maximum number of cycles for rotors and buckets is given in the chapter “Rotor Specifications” on page B-1. The maximum number of cycles for buckets is marked on the buckets themselves.

Fiberlite rotors are not limited in cycles, but have a limited lifetime of 15 years.

Centrifuges with a GUI

The centrifuge counts cycles for a rotor type or a bucket type. You have to count the cycles of the rotors and buckets using your own method. The centrifuge can not detect the change or replacement of rotors of the same type or of buckets of the same type.

You can check the number of cycles for a rotor type on the user interface of the centrifuge. The rotor log saves the information of the used rotor types and bucket types. Refer to “Rotor Log” on page 3-48 for detailed information and to “Status” on page 3-15 for a quick information.

Centrifuges with a LCD Control Panel

The centrifuge does not count cycles for a rotor type or a bucket type. You have to count the cycles of the rotors and buckets using your own method.

5. 3. Cleaning

Clean as follows:

1. Clean rotor, buckets and accessories outside of the centrifugation chamber.
2. Separate rotor, buckets, lids, adapters, tubes and O-rings to allow thorough cleaning.
3. Rinse rotor and all accessories with warm water and a neutral detergent that is suitable for use with the materials. If in doubt contact the manufacturer of the cleaning agent. Clean away the grease from the rotor trunnions (pivot point for swinging buckets).
4. Use a soft brush without metal bristles to remove stubborn residue.
5. Rinse rotor and all accessories with distilled water.
6. Place the rotors on a plastic grate with their cavities pointing down, to enable the cavities to fully drain and dry.
7. Dry all of the rotors and accessories after cleaning with a cloth or in a warm air cabinet at a maximum temperature of 50 °C. If drying boxes are used, the temperature must never exceed 50 °C. Higher temperatures could damage the material and shorten the lifetime of the parts.
8. Inspect the rotor and accessories for signs of damages (“Rotor and Accessories Inspection” on page 5-1).
9. After cleaning, treat the entire surface of aluminum parts including the cavities with corrosion protection oil (70009824).

Treat the bolts of swinging bucket rotors with bolt grease (75003786) if necessary.



CAUTION

Before using any cleaning methods, users should check with the manufacturer of the cleaning agents that the proposed method will not damage the equipment.

**CAUTION**

Drive and door lock can be damaged by entering liquids. Do not allow liquids, especially organic solvents, to get on the drive shaft, the drive bearings or the centrifuge door locks. Organic solvents break down the grease in the motor bearing. The drive shaft could lock up.


Touchscreen

1. Pull out the power supply plug.
2. Clean the touchscreen using a dry microfiber cloth.
3. If necessary moisten the microfiber cloth and wipe the touchscreen again.

Ventilation Grid

To clean the ventilation grid proceed as follows:

1. Pull out the power supply plug.
2. Remove the 2 screws of the ventilation grid ①
 - » 1 L models: on the right side of the centrifuge, as shown in Figure 5-1
 - » 4 L models: on the back side of the centrifuge, as shown in Figure 5-2
3. Remove the ventilation grid ② by pushing it downwards.
4. Use a vacuum cleaner to clean the ventilation grid and if necessary the condenser. Use a soft brush for detailed cleaning if needed.
5. Reinstall the ventilation grid.



- ① Screws
- ② Ventilation Grid

Figure 5-1: Removing the ventilation grid from a 2 L centrifuge




Figure 5-2: Removing the ventilation grid from a 4 L centrifuge

**CAUTION**

Cutting injuries can occur due to sharp metal. Do not touch the condenser with your hands when the ventilation grid is removed.

NOTICE

Do not remove the grid on the left side of a 4L centrifuge. Removing this grid is only necessary for maintenance work on the cooling system. The cooling system is not user-serviceable and any maintenance activities are strictly reserved to authorized service staff.

5. 4. Disinfection

You are responsible that the level of disinfection is achieved according to your requirements.

After disinfection:

1. Rinse the centrifuge and all affected accessories with water.
2. Allow to fully drain and dry.
3. After disinfecting, treat the entire surface of aluminum parts including the cavities with corrosion protection oil (70009824).

Treat the bolts of swinging bucket rotors with bolt grease (75003786) if necessary.



WARNING

Do not touch infected parts. Hazardous infection is possible when touching the contaminated rotor and centrifuge parts. Infectious material can get into the centrifuge when a tube breaks or as a result of spills. In case of contamination, make sure that no one is put at risk. Disinfect the affected parts immediately.



CAUTION

Equipment can be damaged by inappropriate disinfection methods or agents. Make sure that the disinfection agent or the method will not damage the equipment. In doubt contact the manufacturer of the disinfection agent. Observe the safety precautions and handling instructions for the disinfection agents used.

5. 5. Decontamination

You are responsible that the level of decontamination is achieved according to your requirements.

After decontamination:

1. Rinse the centrifuge and all affected accessories with water.
2. Allow to fully drain and dry.
3. After decontaminating, treat the entire surface of aluminum parts including the cavities with corrosion protection oil (70009824).

Treat the bolts of swinging bucket rotors with bolt grease (75003786) if necessary.



WARNING

Do not touch contaminated parts. Exposure to radiation is possible when touching the contaminated rotor and centrifuge parts. Contaminated material can get into the centrifuge when a tube breaks or as a result of spills. In case of contamination, make sure that no one is put at risk. Decontaminate the affected parts immediately.



CAUTION

Equipment can be damaged by inappropriate decontamination methods or agents. Make sure that the decontamination agent or the method will not damage the equipment. In doubt contact the manufacturer of the decontamination agent. Observe the safety precautions and handling instructions for the decontamination agents used.

5. 6. Autoclaving

As preparation always separate rotor, buckets, lids, tubes and sealing rings to allow thorough cleaning. If installed, remove lids from rotors, buckets and tubes.

If not stated otherwise on the parts themselves, all parts can be autoclaved at 121 °C for 20 min. The only exception is the Microliter 48 x 2 rotor at 138 °C for 20 min. Refer to “Rotor Specifications” on page B-1 for details on rotors.

Make sure that the necessary sterility is achieved according to your requirements.

After autoclaving, treat the entire surface of aluminum parts including the cavities with corrosion protection oil (70009824).

Treat the bolts of swinging bucket rotors with bolt grease (75003786) if necessary.



CAUTION

Never exceed the permitted temperature and duration when autoclaving.

NOTICE

No chemical additives are permitted in the steam.

5. 7. Maintenance

Lifetime

The centrifuges are specified for a lifetime of 10 years or 75 000 cycles, whichever occurs first. Decommissioning the centrifuge is suggested when either limit is reached.

The lifetime of rotors, buckets and lids is based on cycles and specified individually for each rotor in the chapter “Rotor Specifications” on page B-1. The lifetime of Fiberlite rotors is limited to 15 years. Other accessories are not limited by a specific lifetime and need only be replaced when damaged or worn.

Preventive Maintenance

In order to keep this product able to perform the intended applications reliably and safely, ongoing preventive maintenance is necessary in accordance with the following recommended schedule:

- The anti-vibration mounts of the motor suspension and motor cover are suggested to be replaced at three-year intervals.
- The seals of the centrifuge door are suggested to be inspected annually and need to be replaced when they are damaged or start to come loose.
- The gas spring of the centrifuge door is to be inspected annually and to be replaced when spring action deteriorates.
- The door hooks, hinges and door lock assembly are suggested to be inspected annually and to be replaced when the door ceases to open, close and lock smoothly.
- For rotors and buckets mind the information in “Rotor and Accessories Inspection” on page 5-1.



CAUTION

Usage beyond these limits might affect the safety of the overall system.

NOTICE

In the worst case the centrifuge, the used accessories and the samples can be damaged.

NOTICE

Maintenance activities must be performed by Thermo Fisher Scientific authorized service technicians only.

Service

Thermo Fisher Scientific recommends having the centrifuge and accessories serviced once a year by an authorized service technician. The service technician checks the following:

- electrical equipment and connections
- suitability of set-up site
- centrifuge door lock and safety system
- rotor

- fixation of rotor and drive shaft of the centrifuge
- rubber gasket
- protective casing
- anti-vibration mounts

Before service, centrifuge and rotors should be thoroughly cleaned and decontaminated to ensure full and safe inspection can be completed.

Thermo Fisher Scientific offers inspection and service contracts for this work. Any necessary repairs are performed for free during the warranty period and afterwards for a charge. That is only valid if the centrifuge has only been maintained by an authorized Thermo Fisher Scientific service technician.

A validation of the centrifuge is recommended and can be ordered from customer service.

5. 8. Shipping

Before shipping the centrifuge:

- The centrifuge must be clean and decontaminated.
- You must confirm the decontamination with a decontamination certificate.



WARNING

Before shipping the centrifuge and accessories you must clean and, if necessary, disinfect or decontaminate the full system. If you are not sure, consult with Thermo Fisher Scientific customer service.

5. 9. Storage

- Before storing the centrifuge and the accessories it must be clean and if necessary disinfected and decontaminated.

Centrifuge, rotors, buckets and accessories have to be fully dry before storage.

- Keep the centrifuge in a clean, dry and dust-free location.
- Do not store the centrifuge in direct sunlight.



WARNING

When you remove the centrifuge and accessories from use, clean and if necessary disinfect or decontaminate the full system. If you are not sure speak to the Thermo Fisher Scientific customer service.

5. 10. Disposal

For the disposal of the centrifuge mind the regulations in your country. Contact the Thermo Fisher Scientific Customer Service for the disposal of the centrifuge. For contact information check the backpage of this manual or visit www.thermofisher.com/centrifuge

For the countries of the European Union the disposal is regulated by the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2012/19/EC.

Mind the information on transport and shipping ("Shipping" on page 5-7 and "Transporting" on page 1-2).



WARNING

When removing the centrifuge and accessories from use for disposal you have to clean and if necessary disinfect or decontaminate the entire system. In doubt contact the Thermo Fisher Scientific customer service.

6. Troubleshooting

6.1. Mechanical Emergency Door Release


During a power failure, you will not be able to open the centrifuge door with the regular electric door release. A mechanical override is provided to allow sample recovery in the case of an emergency. However, this should be used only in emergencies and **after the rotor has come to a complete stop**.

Always wait until the rotor has come to a stop without braking. The brake does not work when there is no power. The braking process lasts much longer than usual.


Proceed as follows:

1. **Wait until the rotor has stopped.** This can take longer than 40 minutes.
2. Pull out the power supply plug.
3. On the back side of the housing there are two plastic plugs. You can pry these plugs out of the back plate with a screwdriver. Pull the release cord attached to trigger the mechanical door release. The centrifuge door will open and the samples can be removed.

2 L Refrigerated Tabletop Centrifuge




2 L Ventilated Tabletop Centrifuge




① Plastic plugs attached to the release cords

Figure 6-1: Emergency door release on the left side of 2 L centrifuges

4 L Refrigerated Tabletop Centrifuge




4 L Ventilated Tabletop Centrifuge



① Plastic plugs attached to the release cords

Figure 6-2: Emergency door release on the back side of 4 L tabletop centrifuges

4 L Floorstanding Centrifuge



① Plastic plugs attached to the release cords

Figure 6-3: Emergency door release on the back side

NOTICE You need to pull both cords in order to unlock both locks.

4. Push the cord(s) back into the centrifuge and mount the plug(s).
5. Reconnect the centrifuge once the power has been restored.
6. Switch on the centrifuge.
7. Press the **OPEN** key to have the door locks operative again.

⚠ **WARNING** If you pull only one cord or you did not press the **OPEN** key to have the door locks operative again, the door might open while the rotor is still spinning.



WARNING

Serious injuries can occur if you touch a spinning rotor with your hands or tools. A rotor can still be spinning after a power failure occurs. Do not open the centrifuge before the rotor has stopped spinning. Do not touch a spinning rotor. Never use your hands or tools to stop a spinning rotor.

6. 2. Ice Formation

Warm humid air in combination with a cold centrifugation chamber can lead to formation of ice. To remove the ice from the centrifugation chamber, proceed as follows:

1. Open the centrifuge door.
2. Remove the rotor. See “How to Install and Remove a Rotor” on page 2-5.
3. Let the ice melt.
4. **NOTICE** Do not use any sharp tools, aggressive liquids or fire to fasten the melting process. If necessary use warm water to speed up the melting process.
5. Remove the water from the centrifugation chamber.
6. Clean the centrifuge chamber. See “Maintenance and Care” on page 5-1.

6. 3. Troubleshooting by Guide

NOTICE

If problems occur other than those listed in this table, the authorized customer service representative must be contacted.

Error Message	Description	Troubleshooting
Numbers not stated here	The centrifuge can not be operated. The run does not start or the centrifuge runs down without being braked.	Restart the centrifuge. If the error message still shows, contact a service technician.
14	Overtemperature detected.	Overheating in chamber. Check the function of the refrigeration unit. Clean the air inlet for the condenser. Restart the centrifuge. If the error message still shows, contact a service technician.
17–23	Rotor detection failed.	Make sure the rotor can be used in the centrifuge. Refer to “Rotor Program” on page A-11. Makes sure the rotor is properly installed. Refer to “How to Install and Remove a Rotor” on page 2-5. Restart the centrifuge. If the error message still shows, contact a service technician.
33	Overpressure in the refrigeration unit.	Clean the air inlet for the condenser. Restart the centrifuge. If the error message still shows, contact a service technician.
37	Refrigeration system fan detection failed.	Make sure the air inlets are not blocked. Restart the centrifuge. If the error message still shows, contact a service technician.
40	The centrifuge accelerates too slowly.	Is the rotor properly installed? Check whether you have selected the right bucket. Is it easy to turn the rotor when the door is open? Does the rotor rub against the device? Restart the centrifuge. If the error message still shows, contact a service technician.
97	Mechanical emergency door release.	Close the centrifuge door. Do not touch a spinning rotor. Never use your hands or tools to stop a spinning rotor. Restart the centrifuge. If the error message still shows, contact a service technician.
98	Imbalance detected.	Check the loading of the rotor. Check the lubrication of the trunnion bolts of the rotor body if a swinging bucket rotor is used. Restart the centrifuge. If the error message still shows, contact a service technician.

Table 6–1: Error Messages

6. 4. Information for the Customer Service

If you need to contact customer service, please provide the order no. and the serial no. of your device. This information can be found on the type plate.

To identify the software version on a centrifuge with an LCD control panel, proceed as follows:

1. Enter the system menu by holding down any of the keys while powering up the centrifuge.
2. Use the + and - **Speed** keys to navigate the system menu.
3. Go to the Software ID option where the version information is displayed.

To identify the software version on a centrifuge with a GUI, proceed as follows:

Press the **Files and Info** button on the navigation bar. Product version information is displayed.

A. Technical Specifications

A. 1. Thermo Scientific S2T / X2T

Model	Thermo Scientific S2T Thermo Scientific S2T IVD-MD	Thermo Scientific X2T Thermo Scientific X2T IVD-MD
Environmental Conditions	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C
Environmental Conditions during Storage and Shipping	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %
Permissible Ambient Temperature during Operation 220 V, 60 Hz models ¹ All other models	+2 °C to +30 °C +2 °C to +35 °C	+2 °C to +30 °C +2 °C to +35 °C
Average Heat Dissipation ² 100–240 V, 50 / 60 Hz	0.65 kW/h	0.65 kW/h
Overvoltage Category	II	II
Pollution Degree	2	2
IP	20	20
Running Time	9 h, 59 min (1-minute increments)	99 h, 59 min, 59 s (1-second increments)
Maximum Speed n_{max}	15200 rpm (depending on rotor)	15200 rpm (depending on rotor)
Minimum Speed n_{min}	300 rpm	300 rpm
Maximum RCF Value at n_{max}	25830 x g (depending on rotor)	25830 x g (depending on rotor)
Noise Level TX-400 rotor ³ Standard usage ⁴	< 60 dB(A) < 42 dB(A)	< 60 dB(A) < 42 dB(A)
Maximum Kinetic Energy 100–240 V, 50 / 60 Hz	41 kJ	41 kJ
Temperature Setting Range	-	-
Dimensions Height (door open / door closed) Table top height Width Depth (with mains connection)	855 mm / 364 mm 320 mm 445 mm 660 mm	855 mm / 364 mm 320 mm 445 mm 660 mm
Weight ⁵ 100–240 V, 50 / 60 Hz	61 kg	61 kg

¹ At ambient temperatures above 28 °C, the maximum temperature setting is limited to 25 °C. For ambient temperatures below 28 °C, the full range of temperature settings is available (-20 to +40 °C).

² F15 8x50cy rotor; 15-minute run followed by 5 minutes with centrifuge door open; repeated 3 times in 1 hour

³ Measured with TX-400 at 5000 rpm

⁴ Measured with TX-400 at 500 x g

⁵ Without rotor.

Table A-1: Technical Data – Thermo Scientific S2T / X2T Centrifuges

A. 2. Thermo Scientific S2TR / X2TR

Model	Thermo Scientific S2TR Thermo Scientific S2TR IVD-MD	Thermo Scientific X2TR Thermo Scientific X2TR IVD-MD
Environmental Conditions	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C
Environmental Conditions during Storage and Shipping	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %
Permissible Ambient Temperature during Operation 220 V, 60 Hz models ¹ All other models	+2 °C to +30 °C +2 °C to +35 °C	+2 °C to +30 °C +2 °C to +35 °C
Average Heat Dissipation ²	1.0 kW/h	1.0 kW/h
Overvoltage Category	II	II
Pollution Degree	2	2
IP	20	20
Running Time	9 h, 59 min (1-minute increments)	99 h, 59 min, 59 s (1-second increments)
Maximum Speed n_{max}	15200 rpm (depending on rotor)	15200 rpm (depending on rotor)
Minimum Speed n_{min}	300 rpm	300 rpm
Maximum RCF Value at n_{max}	25830 x g (depending on rotor)	25830 x g (depending on rotor)
Noise Level TX-400 rotor ³ Standard usage ⁴	<52 dB(A) <52 dB(A)	<52 dB(A) <52 dB(A)
Maximum Kinetic Energy	41 kJ	41 kJ
Temperature Setting Range	-20 °C to 40 °C	-20 °C to 40 °C
Dimensions Height (door open / door closed) Table top height Width Depth (with mains connection)	855 mm / 364 mm 320 mm 625 mm 660 mm	855 mm / 364 mm 320 mm 625 mm 660 mm
Weight ⁵ 220–230 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	94 kg 92 kg 96 kg	94 kg 92 kg 96 kg

¹¹ At ambient temperatures above 28 °C, the maximum temperature setting is limited to 25 °C. For ambient temperatures below 28 °C, the full range of temperature settings is available (-20 to +40 °C).

² F15 8x50cy rotor; 15-minute run followed by 5 minutes with centrifuge door open; repeated 3 times in 1 hour

³ Measured with TX-400 at 5000 rpm

⁴ Measured with TX-400 at 500 x g

⁵ Without rotor.

Table A-2: Technical Data – Thermo Scientific S2TR / X2TR Centrifuges

A. 3. Thermo Scientific S4T / X4T

Model	Thermo Scientific S4T Thermo Scientific S4T IVD-MD	Thermo Scientific X4T Thermo Scientific X4T IVD-MD
Environmental Conditions	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C
Environmental Conditions during Storage and Shipping	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %
Permissible Ambient Temperature during Operation	+2 °C to +35 °C	+2 °C to +35 °C
Average Heat Dissipation ¹ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	1.2 kW/h 1.0 kW/h 0.9 kW/h	1.2 kW/h 1.0 kW/h 0.9 kW/h
Overvoltage Category	II	II
Pollution Degree	2	2
IP	20	20
Running Time	9 h, 59 min (1-minute increments, > 10 min)	99 h, 59 min, 59 s (1-second increments)
Maximum Speed n_{max}	15200 rpm (depending on rotor)	15200 rpm (depending on rotor)
Minimum Speed n_{min}	300 rpm	300 rpm
Maximum RCF Value at n_{max}	25830 x g (depending on rotor)	25830 x g (depending on rotor)
Noise Level TX-1000 ² Standard usage ³	< 63 dB(A) < 50 dB(A)	< 63 dB(A) < 50 dB(A)
Maximum Kinetic Energy 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	62.5 kJ 51.7 kJ 51.7 kJ	62.5 kJ 51.7 kJ 51.7 kJ
Temperature Setting Range	-	-
Dimensions Height (door open / door closed) Table top height Width Depth (with mains connection)	861 mm / 362 mm 325 mm 566 mm 690 mm	861 mm / 362 mm 325 mm 566 mm 690 mm
Weight ⁴ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	89 kg 89 kg 89 kg	89 kg 89 kg 89 kg

¹ TX-750 rotor with rectangle buckets run at 4 100rpm; 15-minute run followed by 5 minutes with centrifuge door open; repeated 3 times in 1 hour

² Measured with TX-1000 at 3800 rpm

³ Measured with TX-1000 cell culture protocol at 2070 rpm

⁴ Without rotor.

Table A-3: Technical Data – Thermo Scientific S4T / X4T Centrifuges

A. 4. Thermo Scientific S4TR / X4TR

Model	Thermo Scientific S4TR Thermo Scientific S4TR IVD-MD	Thermo Scientific X4TR Thermo Scientific X4TR IVD-MD
Environmental Conditions	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C
Environmental Conditions during Storage and Shipping	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %
Permissible Ambient Temperature during Operation	+2 °C to +35 °C	+2 °C to +35 °C
Average Heat Dissipation ¹ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	1.6 kW/h 1.1 kW/h 1.0 kW/h	1.6 kW/h 1.1 kW/h 1.0 kW/h
Overvoltage Category	II	II
Pollution Degree	2	2
IP	20	20
Running Time	9 h, 59 min (1-minute increments, > 10 min)	99 h, 59 min, 59 s (1-second increments)
Maximum Speed n_{max}	15200 rpm (depending on rotor)	15200 rpm (depending on rotor)
Minimum Speed n_{min}	300 rpm	300 rpm
Maximum RCF Value at n_{max}	25830 x g (depending on rotor)	25830 x g (depending on rotor)
Noise Level TX-1000 ² Standard usage ³	55 dB(A) 51 dB(A)	55 dB(A) 51 dB(A)
Maximum Kinetic Energy 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	62.5 kJ 51.7 kJ 51.7 kJ	62.5 kJ 51.7 kJ 51.7 kJ
Temperature Setting Range	-20 °C to 40 °C	-20 °C to 40 °C
Dimensions Height (door open / door closed) Table top height Width Depth (with mains connection)	860 mm / 361 mm 325 mm 746 mm 690 mm	860 mm / 361 mm 325 mm 746 mm 690 mm
Weight ⁴ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	125 kg 125 kg 129 kg	125 kg 125 kg 129 kg

¹ TX-750 rotor with rectangle buckets run at 4 100 rpm; cooling switched on; 15-minute run followed by 5 minutes with centrifuge door open; repeated 3 times in 1 hour

² Measured with TX-1000 at 4 200 rpm set to -20 °C

³ Measured with TX-1000 cell culture protocol at 2 070 rpm set to 23 °C

⁴ Without rotor.

Table A-4: Technical Data – Thermo Scientific S4TR / X4TR Centrifuges

A. 5. Thermo Scientific S4FR / X4FR

Model	Thermo Scientific S4FR Thermo Scientific S4FR IVD-MD	Thermo Scientific X4FR Thermo Scientific X4FR IVD-MD
Environmental Conditions	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C	Use in interior spaces only. Altitudes of up to 3000 m above sea level. Max. relative humidity 80 % up to 31 °C; decreasing linearly to 50 % relative humidity at 40 °C
Environmental Conditions during Storage and Shipping	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %	Temperature: -10 °C to 55 °C Humidity: 15 % to 85 %
Permissible Ambient Temperature during Operation	+2 °C to +35 °C	+2 °C to +35 °C
Average Heat Dissipation ¹ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	1.6 kW/h 1.1 kW/h 1.0 kW/h	1.6 kW/h 1.1 kW/h 1.0 kW/h
Overvoltage Category	II	II
Pollution Degree	2	2
IP	20	20
Running Time	9 h, 59 min (1-minute increments, > 10 min)	99 h, 59 min, 59 s (1-second increments)
Maximum Speed n_{max}	15200 rpm (depending on rotor)	15200 rpm (depending on rotor)
Minimum Speed n_{min}	300 rpm	300 rpm
Maximum RCF Value at n_{max}	25830 x g (depending on rotor)	25830 x g (depending on rotor)
Noise Level TX-1000 ² Standard usage ³	56dB(A) 54dB(A)	56dB(A) 54dB(A)
Maximum Kinetic Energy 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	62.5 kJ 51.7 kJ 51.7 kJ	62.5 kJ 51.7 kJ 51.7 kJ
Temperature Setting Range	-20 °C to 40 °C	-20 °C to 40 °C
Dimensions Height (door open / door closed) Table top height Width Depth (with mains connection)	1350 mm / 835 mm 800 mm 564 mm 696 mm	1350 mm / 835 mm 800 mm 564 mm 696 mm
Weight ⁴ 208–240 V, 50 / 60 Hz 120 V, 60 Hz 100 V, 50 / 60 Hz	155 kg 155 kg 159 kg	155 kg 155 kg 159 kg

¹ TX-750 rotor with rectangle buckets run at 4300 rpm; cooling switched on; 15-minute run followed by 5 minutes with centrifuge door open; repeated 3 times in 1 hour

² Measured with TX-1000 at 4200 rpm set to -20°C

³ Measured with TX-1000 cell culture protocol at 2070 rpm set to 23°C

⁴ Without rotor.

Table A-5: Technical Data – Thermo Scientific S4FR / X4FR Centrifuges

A. 6. Directives, Standards and Guidelines

Centrifuge	Region	Directive	Standard
Thermo Scientific S Series, IVD-MD Thermo Scientific X Series, IVD-MD	Europe	(EU) 2017/746 In vitro diagnostic regulation (IVDR) 2006/42/EC Machinery (Protective Goals) 2014/35/EU Low Voltage (Protective Goals) 2014/30/EU Electromagnetic Compatibility (EMC) (Protective Goals) 2011/65/EU RoHS Directive on the Restriction of the use of certain Hazardous Substances in electrical and electronic equipment	EN 61010-1 EN 61010-2-020 EN/IEC 61010-2-011 EN 61010-2-101 EN 61326 -1 Class B EN 61326-2-6 EN 62304 EN 62366-1 EN ISO 14971 EN ISO 13485
	USA & Canada	FDA listed Product Code JQC Centrifuges for Clinical Use Device Class 1	UL 61010-1 UL 61010-2-020 UL 61010-2-011 UL 61010-2-101 FCC Part 15 ICES-001 IEC 62304 IEC 61326-1 Class B IEC 61326-2-6 IEC 62366-1 ISO 14971 ISO 13485
	Japan South Korea China		IEC 61010-1 IEC 61010-2-020 IEC 61010-2-011 IEC 61010-2-101 IEC 61326-1 Class B IEC 61326-2-6 IEC 62304 IEC 62366-1 ISO 14971 ISO 13485

Table A-6: Directives and Standards for S/X IVD-MD Series Centrifuges

Centrifuge	Region	Directive	Standard
Thermo Scientific S Series Thermo Scientific X Series	Europe	2006/42/EC Machinery 2014/35/EU Low Voltage (Protective Goals) 2014/30/EU Electromagnetic Compatibility (EMC; Protective Goals) 2011/65/EU RoHS Directive on the Restriction of the use of certain Hazardous Substances in electrical and electronic equipment	EN 61010-1 EN 61010-2-020 EN/IEC 61010-2-011 EN 61326 -1 Class B EN ISO 14971 EN ISO 9001
	USA & Canada		UL 61010-1 UL 61010-2-020 UL 61010-2-011 IEC 61326-1 Class B FCC Part 15 ICES-001 ISO 14971 ISO 9001
	Japan South Korea China		IEC 61010-1 IEC 61010-2-020 IEC 61010-2-011 IEC 61326-1 Class B ISO 14971 ISO 9001

Table A-7: Directives and Standards for S/X Series Centrifuges

NOTE This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

A. 7. Refrigerants

Article No.	Centrifuge	Refrigerant	Quantity	Pressure	GWP	CO2e
75007352	Thermo Scientific S4FR IVD-MD*	R-290	0.11 kg	26 bar	3	0.33 kg
75007353	Thermo Scientific S4FR IVD-MD	R-290	0.11 kg	26 bar	3	0.33 kg
75007354	Thermo Scientific S4FR	R-290	0.11 kg	26 bar	3	0.33 kg
75007356	Thermo Scientific S4TR IVD-MD*	R-290	0.11 kg	26 bar	3	0.33 kg
75007357	Thermo Scientific S4TR IVD-MD	R-290	0.11 kg	26 bar	3	0.33 kg
75007358	Thermo Scientific S4TR	R-290	0.11 kg	26 bar	3	0.33 kg
75007360	Thermo Scientific X4FR IVD-MD*	R-290	0.11 kg	26 bar	3	0.33 kg
75007361	Thermo Scientific X4FR IVD-MD	R-290	0.11 kg	26 bar	3	0.33 kg
75007359	Thermo Scientific X4FR	R-290	0.11 kg	26 bar	3	0.33 kg
75007362	Thermo Scientific X4FR	R-290	0.11 kg	26 bar	3	0.33 kg
75007364	Thermo Scientific X4TR IVD-MD*	R-290	0.11 kg	26 bar	3	0.33 kg
75007365	Thermo Scientific X4TR IVD-MD	R-290	0.11 kg	26 bar	3	0.33 kg
75007363	Thermo Scientific X4TR	R-290	0.11 kg	26 bar	3	0.33 kg
75007366	Thermo Scientific X4TR	R-290	0.11 kg	26 bar	3	0.33 kg
75001044	Thermo Scientific S2TR IVD-MD,	R-290	0.115 kg	23 bar	3	0.395 kg
75001045	Thermo Scientific S2TR IVD-MD	R-290	0.098 kg	26 bar	3	0.294 kg
75001046	Thermo Scientific S2TR	R-290	0.098 kg	26 bar	3	0.294 kg
75001047	Thermo Scientific X2TR IVD-MD	R-290	0.115 kg	23 bar	3	0.395 kg
75001048	Thermo Scientific X2TR IVD-MD	R-290	0.098 kg	26 bar	3	0.294 kg
75001049	Thermo Scientific X2TR	R-290	0.115 kg	23 bar	3	0.395 kg
75001039	Thermo Scientific X2TR	R-290	0.098 kg	26 bar	3	0.294 kg

* Compliant with US standards for centrifuges with flammable refrigerants.

Contains hydrocarbon greenhouse gases in a hermetically sealed system.

Table A-8: Refrigerants Used for S Series and X Series Centrifuges

A. 8. Mains Supply

The following table contains an overview of the electrical connection data for the S Series and X Series Centrifuges. This data is to be taken into consideration when selecting the mains connection socket.

Art. No.	Centrifuge	Mains Voltage (V)	Frequency (Hz)	Rated Current (A)	Power Consumption (W)	Building Fuse (AT)	Equipment Fuse (AT)
75007331	Thermo Scientific S4T IVD-MD	120	50/60	10.5	1300	15	15A
75007332	Thermo Scientific S4T IVD-MD	208–240	50/60	7.5	1600	15	15A USA 16A Europe
75007333	Thermo Scientific S4T	208–240	50/60	7.5	1600	15	15A USA 16A Europe
75007340	Thermo Scientific X4T IVD-MD	120	50/60	10.5	1300	15	15A
75007341	Thermo Scientific X4T IVD-MD	208–240	50/60	7.5	1600	15	15A USA 16A Europe
75007339	Thermo Scientific X4T	100	50/60	11	1100	15	15A
75007343	Thermo Scientific X4T	208–240	50/60	7.5	1600	15	15A USA 16A Europe
75007352	Thermo Scientific S4FR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007353	Thermo Scientific S4FR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007354	Thermo Scientific S4FR	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007356	Thermo Scientific S4TR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007357	Thermo Scientific S4TR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007358	Thermo Scientific S4TR	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007360	Thermo Scientific X4FR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007361	Thermo Scientific X4FR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007359	Thermo Scientific X4FR	100	50/60	15	1300	15	15A
75007362	Thermo Scientific X4FR	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007364	Thermo Scientific X4TR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007365	Thermo Scientific X4TR IVD-MD	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75007363	Thermo Scientific X4TR	100	50/60	15	1300	15	15A
75007366	Thermo Scientific X4TR	120/208–240	50/60	15	1450	15	15A USA 16A Europe
75001040	Thermo Scientific S2T IVD-MD	100–240	50/60	8.5	850	15	15A USA 16A Europe
75001041	Thermo Scientific S2T	100–240	50/60	8.5	850	15	15A USA 16A Europe
75001042	Thermo Scientific X2T IVD-MD	100–240	50/60	8.5	850	15	15A USA 16A Europe
75001043	Thermo Scientific X2T	100–240	50/60	8.5	850	15	15A USA 16A Europe

Art. No.	Centrifuge	Mains Voltage (V)	Frequency (Hz)	Rated Current (A)	Power Consumption (W)	Building Fuse (AT)	Equipment Fuse (AT)
75001044	Thermo Scientific S2TR IVD-MD	120	60	10	1200	15	15A USA
75001045	Thermo Scientific S2TR IVD-MD	220–230	50/60	6,5	1400	15	16A Europe
75001046	Thermo Scientific S2TR	220–230	50/60	6,5	1400	15	16A Europe
75001047	Thermo Scientific X2TR IVD-MD	120	60	10	1200	15	15A USA
75001048	Thermo Scientific X2TR IVD-MD	220–230	50/60	6,5	1400	15	16A Europe
75001049	Thermo Scientific X2TR	100	50/60	12	1200	15	15A USA
75001039	Thermo Scientific X2TR	220–230	50/60	6,5	1400	15	16A Europe

Table A-9: Electrical Connection Data for Used for S Series and X Series Centrifuges

A. 9. Rotor Program

For more details on rotors and accessories refer to “Rotor Specifications” on page B-1

Thermo Scientific - Rotor Name	S Series Centrifuges	X Series Centrifuges
TX-200 (75003658)	✓	✓
TX-400 (75003181)	✓	✓
TX-750 (75003180)	✓	✓
TX-1000 (75003017)	✓	✓
H-FLEX 1 (75003300)	✓	✓
H-FLEX HS4 (75003330)	✓	✓
HIGHPlate 6000 (75003606)	✗	✓
M-20 Microplate (75003624)	✓	✓
BIOShield 720 (75003183)	✓	✓
BIOShield 1000A (75003182)	✓	✓
CLINIConic (75003623)	✓	✓
HIGHConic II (75003620)	✓	✓
8 x 50 ml Sealed (75003694)	✓	✓
Microliter 30 x 2 (75003652)	✓	✓
Microliter 48 x 2 (75003602)	✓	✓
MicroClick 30 x 2 (75005719)	✓	✓
MicroClick 18 x 5 (75005765)	✓	✓
Fiberlite F13-14 x 50cy (75003661)	✗	✓
Fiberlite F14-6 x 250 LE (75003662)	✗	✓
Fiberlite F15-6 x 100y (75003698)	✓	✓
Fiberlite F15-8 x 50cy (75003663)	✗	✓
Fiberlite F21-48 x 2 (75003664)	✓	✓
Fiberlite H3-LV (75003665)	✗	✓
Fiberlite F10-6 x 100 LEX (75003340)	✓	✓

Table A-10: Rotor Program

A. 10. Connectivity

Description	Cat. No.
Software and accessories	
SECURE-Spin mode	75009990
Centri-Log Plus Software** (requires SECURE-Spin mode)	75007742
Sample tracking kit* (requires Centri-Log Plus software)	For floorstanding centrifuges (barcode scanner, holder, and cable)
	For tabletop centrifuges (barcode scanner and cable)
Network access kit* (cable)	75007741

* Product sold separately.

** Centri-Log Plus software version must be at least 2.12.0

Table A-11: Connectivity Options

B. Rotor Specifications

This section lists the rotors and their accessories.

For more details on adapters and accessories refer to the separate rotor subchapters in this chapter.



B. 1. TX-200

B. 1. 1. Items Supplied

Article No.	Item	Quantity
75003658	TX-200 Rotor	1
50157859	Rotor safety information	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

B. 1. 2. Technical Data

General Technical Data	
Weight (empty)	2.5 kg
Maximum Permissible Load	4 x 275 g
Max. Cycle Number	20 000
Radius _{max} / min.	165 / 64 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5500 rpm
Maximum RCF-Value at n_{max}	5580 x g
K-Factor at n_{max}	7921
Acceleration / Braking Time	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5500 rpm	5500 rpm	5500 rpm
Maximum RCF-Value at n_{max}	5580 x g	5580 x g	5580 x g
K-Factor at n_{max}	7921	7921	7921
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	5500 rpm	5500 rpm	5400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -5 °C 60 Hz: -8 °C	1 °C	5 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5500 rpm
Maximum RCF-Value at n_{max}	5580 x g
K-Factor at n_{max}	7921
Acceleration / Braking Time	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5500 rpm	5500 rpm	5500 rpm
Maximum RCF-Value at n_{max}	5580 x g	5580 x g	5580 x g
K-Factor at n_{max}	7921	7921	7921
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	5500 rpm	5500 rpm	5400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -5 °C 60 Hz: -8 °C	1 °C	5 °C



B. 1. 3. Accessories

Article No.	Description
Accessories	
75003659	TX-200 round buckets (4x)
75003660	TX-200 round ClickSeal biocontainment lids (4x)
75003687	Replacement TX-200 O-rings for lids (4x)
75003800	180 ml bio-bottle - polypropylene (12x)
Adapters for Laboratory Use	
75003801	100 ml round bottom open-top tube
75003802	50 ml DIN round bottom tube
75003815	50 ml round bottom tube
75003805	25 ml DIN round/flat bottom tube
75003806	20 ml round bottom tube
75003810	5/7 ml round bottom open-top tube
75003811	3/5 ml RIA or round bottom tube
Adapters for IVD Use	
75003803	50 ml conical or skirted tube
75003771	15 ml conical tube
75003809	15 ml blood collection tube
75003807	14 ml conical urine tube
75003808	10 ml blood collection tube
75003804	30 ml Sterilin Universal tube
75003812	1.5/2 ml Microtube
75003785	5/7 ml or 4.5/6 ml blood collection tube

B. 1. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment testing of Thermo Scientific swing out bucket rotor 75003658 and buckets 75003659

Report No. 77-08 G

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific centrifuge bucket 75003659 with aerosol tight lid (Max speed 5,500 rpm) was supplied by Thermo Fisher and containment tested at 5,500 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By



B. 2. TX-400

B. 2. 1. Items Supplied

Article No.	Item	Quantity
75003181	TX-400 rotor cross	1
50157859	Rotor safety information	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

B. 2. 2. Technical Data

General Technical Data	
Weight (empty)	4.1 kg
Maximum Permissible Load	4 x 570 g
Max. Cycle Number	50 000
Radius _{max.} / min.	168 / 68 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5 000 rpm
Maximum RCF-Value at n_{max}	4 696 x g
K-Factor at n_{max}	9 153
Acceleration / Braking Time	25 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5 000 rpm	5 000 rpm	5 000 rpm
Maximum RCF-Value at n_{max}	4 696 x g	4 696 x g	4 696 x g
K-Factor at n_{max}	9 153	9 153	9 153
Acceleration / Braking Time	25 s / 35 s	30 s / 35 s	30 s / 35 s
Max. Speed at 4 °C	5 000 rpm	5 000 rpm	5 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -9 °C 60 Hz: -12 °C	-4 °C	0 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5 000 rpm
Maximum RCF-Value at n_{max}	4 696 x g
K-Factor at n_{max}	9 153
Acceleration / Braking Time	25 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5 000 rpm	5 000 rpm	5 000 rpm
Maximum RCF-Value at n_{max}	4 696 x g	4 696 x g	4 696 x g
K-Factor at n_{max}	9 153	9 153	9 153
Acceleration / Braking Time	25 s / 35 s	30 s / 35 s	30 s / 35 s
Max. Speed at 4 °C	5 000 rpm	5 000 rpm	5 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	2 °C	50 Hz: 5 °C 60 Hz: 4 °C



B. 2. 3. Accessories

Article No.	Description
Accessories	
75003655	TX-400 round buckets (4x)
75003656	TX-400 round ClickSeal biocontainment lids (4x)
75003657	Replacement TX-400 o-rings for lids (4x)
75007585	400 ml bio-bottle - polypropylene (12x)
Adapters for Laboratory Use	
75003788	250 ml Thermo Scientific Nalgene™ bottle; 200 ml Thermo Scientific Nunc conical bottle (requires Nunc #377585); 225 ml/175 ml BD Falcon conical bottle (requires BD #352090)
75003708	100 ml round bottom open-top tube
75003707	50 ml DIN round bottom tube
75003799	50 ml Nalgene™ Oak Ridge tube
75003703	30/25 ml DIN round/flat bottom tube
75003704	15 ml round bottom tube (Sarstedt)
75003793	3 ml RIA or round bottom tube (without cap)
Adapters for IVD Use	
75003683	50 ml conical tube
75003682	15 ml conical tube
75003794	15 ml blood collection tube (17 x 125 mm)
75003798	14 ml round or conical urine tube
75003681	10 ml blood collection (16 x 100 mm)
75003706	30 ml Sterilin Universal tube
75003680	5/7 ml blood collection tube (13 x 75-100 mm)
75003700	1.5/2 ml Microtube
75003825	4.5/6 ml blood collection tube (Greiner)

B. 2. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment testing of Thermo Scientific swing out bucket rotor 75003629 and buckets 75003655

Report No. 77- 08 E

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific centrifuge bucket 75003655 with aerosol tight lid (Max speed 5,000 rpm) was supplied by Thermo Fisher and containment tested at 5,000 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By

NOTICE: This certificate is also valid for 75003181.



B. 3. TX-750

B. 3. 1. Items Supplied

Article No.	Item	Quantity
75003180	TX-750 rotor	1
50157859	Rotor safety information	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

Technical Data (Round Buckets)

General Technical Data	
Weight (empty)	7.4 kg
Max. Permissible Load	4 x 800 g
Max. Cycle Number Rotor Cross / Bucket	120 000 / 70 000
Radius max. / min.	195 mm / 83 mm
Angle	90°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	O-ring 75003610

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4 700 rpm	4 700 rpm	4 500 rpm
Max. RCF-Value at n_{max}	4 816 x g	4 816 x g	4 415 x g
K-Factor at n_{max}	9 783	9 783	10 672
Acceleration/Braking Time	40 s / 45 s	55 s / 45 s	60 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	13 °C	12 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4 700 rpm	4 700 rpm	4 500 rpm
Max. RCF-Value at n_{max}	4 816 x g	4 816 x g	4 415 x g
K-Factor at n_{max}	9 783	9 783	10 672
Acceleration / Braking Time	40 s / 45 s	50 s / 50 s	60 s / 50 s
Max. Speed at 4 °C	4 700 rpm	4 700 rpm	4 100 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-2 °C	-2 °C	-3 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4 700 rpm	4 700 rpm	4 500 rpm
Max. RCF-Value at n_{max}	4 816 x g	4 816 x g	4 415 x g
K-Factor at n_{max}	9 783	9 783	10 672
Acceleration / Braking Time	40 s / 45 s	55 s / 45 s	60 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	13 °C	12 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4 700 rpm	4 700 rpm	4 500 rpm
Max. RCF-Value at n_{max}	4 816 x g	4 816 x g	4 415 x g
K-Factor at n_{max}	9 783	9 783	10 672
Acceleration / Braking Time	40 s / 45 s	50 s / 50 s	50 s / 50 s
Max. Speed at 4 °C	4 700 rpm	4 400 rpm	4 400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-2 °C	-2 °C	-3 °C



B. 3. 2. Technical Data (Rectangular Buckets)

General Technical Data	
Weight (empty)	6.8 kg
Max. Permissible Load	4 x 750 g
Max. Cycle Number	
Rotor Cross	120 000
Bucket	100 000
Radius max. / min.	195 mm / 89 mm
Angle	90°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	O-ring 75003610

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4500 rpm	4300 rpm	4100 rpm
Max. RCF-Value at n_{max}	4415 x g	4031 x g	3665 x g
K-Factor at n_{max}	9800	10732	11805
Acceleration / Braking Time	40 s / 40 s	50 s / 40 s	55 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	10 °C	9 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm	4300 rpm	4100 rpm
Max. RCF-Value at n_{max}	4816 x g	4031 x g	3665 x g
K-Factor at n_{max}	8983	10732	11805
Acceleration / Braking Time	40 s / 45 s	40 s / 45 s	50 s / 45 s
Max. Speed at 4 °C	4600 rpm	4300 rpm	4100 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	5 °C	-1 °C	-3 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4500 rpm	4300 rpm	4100 rpm
Max. RCF-Value at n_{max}	4415 x g	4031 x g	3665 x g
K-Factor at n_{max}	9800	10732	11805
Acceleration / Braking Time	40 s / 40 s	20 s / 40 s	55 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	10 °C	9 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm	4300 rpm	4100 rpm
Max. RCF-Value at n_{max}	4816 x g	4031 x g	3665 x g
K-Factor at n_{max}	8983	10732	11805
Acceleration / Braking Time	40 s / 45 s	40 s / 40 s	50 s / 45 s
Max. Speed at 4 °C	4600 rpm	4300 rpm	4100 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	5 °C	-1 °C	-3 °C



B. 3. 3. Technical Data (Microplate Carriers)

General Technical Data	
Weight (empty)	7.3 kg
Max. Permissible Load	4 x 500 g
Max. Cycle Number	120000
Rotor Cross	
Bucket	
Radius max. / min.	155 mm / 99 mm
Angle	90°
Aerosol-tight	No
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at $n_{\max}$	3828 x g	3828 x g	3828 x g
K-Factor at $n_{\max}$	5135	5135	5135
Acceleration / Braking Time	35 s / 40 s	45 s / 40 s	50 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	10 °C	10 °C	10 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at $n_{\max}$	3828 x g	3828 x g	3828 x g
K-Factor at $n_{\max}$	5135	5135	5135
Acceleration / Braking Time	30 s / 45 s	40 s / 45 s	45 s / 45 s
Max. Speed at 4 °C	4700 rpm	4400 rpm	4400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-2 °C	-2 °C	-3 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at $n_{\max}$	3828 x g	3828 x g	3828 x g
K-Factor at $n_{\max}$	5135	5135	5135
Acceleration / Braking Time	35 s / 40 s	45 s / 40 s	50 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	10 °C	10 °C	10 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at $n_{\max}$	3828 x g	3828 x g	3828 x g
K-Factor at $n_{\max}$	5135	5135	5135
Acceleration / Braking Time	30 s / 45 s	40 s / 45 s	45 s / 45 s
Max. Speed at 4 °C	4700 rpm	4400 rpm	4400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-2 °C	-2 °C	-3 °C

B. 3. 4. Accessories

TX-750 (round buckets)



Article No.	Description
Accessories	
75003180	TX-750 rotor cross
75003608	TX-750 round buckets (4x) *
75003609	TX-750 round ClickSeal biocontainment lids (4x)
75003610	Replacement TX-750 round O-rings for lids (4x)
75006443	750 ml Bio-Bottle - Polypropylene (1 each)
75003795	Microplate Carriers and T-75 Flask (includes tray and pads) (2x)
75003617	Microplate Carriers and T-75 Flask (includes tray and pads) (4x)
Adapters for Laboratory Use	
75003792	250 mL Corning conical bottle (open buckets only) and 250 mL Nalgene conical bottle (with biocontainment)
75003710	250 ml Nalgene bottle
75003710	225 ml/175 ml BD Falcon conical bottle (requires BD #352090) (open buckets only)
75003710	200 ml Nunc conical bottle and 250 ml Nunc conical tube (requires Nunc #377585) (open buckets only)
75003710	175 ml Nalgene conical bottle (requires Nalgene #DS3126-0175) (open buckets only)
75003713	100 ml round bottom open-top tube
75003715	50 ml Nalgene Oak Ridge tube
75003724	5 ml RIA or round bottom tube (with out cap)
75003732	5/7 ml round bottom tube (without cap) with decanting aid
75008383	T-75 Nunc Easy Flask
75008384	T-25 Nunc Easy Flask
Adapters for IVD Use	
75003714	50 ml conical tube (includes sealing vessel) can be combined with ClickSeal lids
75003638	50 ml conical tube
75003824 (New number: 75006533 x 4)	50 ml conical or skirted tube
75003716	30 ml Sterilin Universal tube
75003639	15 ml conical tube
75003719	15 ml blood collection tube (17 x 125 mm) (inner circle only)
75003719	10 ml blood collection (16 x 100 mm) or 15 ml Corex/Kimble tube
75003718	14 ml round or conical urine tube
75003723	5/7 ml or 4.5/6 ml blood collection tube (13 x 75-100 mm)
75003733	1.5/2 ml Microtube

TX-750 (rectangular buckets)

Article No.	Description
Accessories	
75003180	TX-750 rotor cross
75003614	TX-750 rectangular Buckets (4x)
75003615	TX-750 rectangular ClickSeal biocontainment lids (4x)
75003610	Replacement TX-750 rectangular O-rings for lids (4x)
Adapters for Laboratory Use	
75003737	250 ml flat bottom bottle
75003738	150 ml round bottom open-top tube
75003742	100 ml round bottom open-top tube
75003749	50 ml round bottom tube
75003750	45 ml flat/round tube
75003756	25 ml DIN round bottom tube
75003758	14 ml flanged round bottom tube
75003769	5/7 ml round bottom tube (13 x 75-100 mm)
Adapters for IVD Use	
75003685	50 ml conical tube
75003684	15 ml conical tube
75003759	14 ml round or conical urine tube
75003767	10 ml blood collection
75003768	5/7 ml or 4.5/6 ml blood collection tube
75003755	30 ml Sterilin Universal tube
75003770	1.5/2 ml Microtube

TX-750 (microplate carriers)

Article No.	Description
Accessories	
75003180	TX-750 rotor cross
75003795	Microplate carriers and T-75 flasks (including plate trays and rubber pad) (2x)
75003617	Microplate carriers and T-75 flasks (including plate trays and rubber pad) (4x)

* Mind the information on assembling page 2-7.

B. 3. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing


**Containment testing of Thermo Scientific
Swing out bucket rotor 75003607 and
bucket 75003608**

Report No. 59-08 C

Report prepared for: Thermo Fisher
Issue Date: 15th January 2009

Test Summary

A Thermo Scientific 75003608 centrifuge bucket with aerosol tight lid (Max speed 4,700 rpm) was supplied by Thermo Fisher and containment tested at 4,700 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By  **Report Authorised By**  (28/1/09)

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing


**Containment testing of Thermo Scientific
swing out bucket rotor 75003607 and
bucket 75003614**

Report No. 59-08 D

Report prepared for: Thermo Fisher
Issue Date: 15th January 2009

Test Summary

A Thermo Scientific 75003614 centrifuge bucket with aerosol tight lid (Max speed 4,700 rpm) was supplied by Thermo Fisher and containment tested at 4,700 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By  **Report Authorised By**  (28/1/09)



B. 4. TX-1000

B. 4. 1. Items Supplied

Article No.	Item	Quantity
75003017	TX-1000 rotor cross	1
75003001	TX-1000 buckets	4
50157859	Rotor safety information	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

B. 4. 2. Technical Data

General Technical Data	
Weight (empty)	9.8 kg
Max. Permissible Load	4 x 1500 g
Max. Cycle Number	55000
Radius max. / min.	209 mm / 108 mm
Angle	90°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	3800 rpm	3800 rpm	3800 rpm
Max. RCF-Value at n_{max}	3374 x g	3374 x g	3374 x g
K-Factor at n_{max}	11567	11567	11567
Acceleration / Braking Time	60 s / 60 s	75 s / 65 s	85 s / 70 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	9 °C	9 °C	9 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4200 rpm	4200 rpm	4200 rpm
Max. RCF-Value at n_{max}	4122 x g	4122 x g	4122 x g
K-Factor at n_{max}	9469	9469	9469
Acceleration / Braking Time	65 s / 75 s	85 s / 75 s	85 s / 70 s
Max. Speed at 4 °C	4200 rpm	4200 rpm	4200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	0 °C	-1 °C	0 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	3800 rpm	3800 rpm	3800 rpm
Max. RCF-Value at n_{max}	3374 x g	3374 x g	3374 x g
K-Factor at n_{max}	11567	11567	11567
Acceleration / Braking Time	60 s / 60 s	75 s / 65 s	85 s / 70 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	9 °C	9 °C	9 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4200 rpm	4200 rpm	4200 rpm
Max. RCF-Value at n_{max}	4122 x g	4122 x g	4122 x g
K-Factor at n_{max}	9469	9469	9469
Acceleration / Braking Time	65 s / 75 s	85 s / 75 s	85 s / 70 s
Max. Speed at 4 °C	4200 rpm	4200 rpm	4200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	0 °C	-1 °C	0 °C



B. 4. 3. Accessories

Article No.	Description
Accessories	
75003017	TX-1000 rotor cross
75003001	TX-1000 buckets (4x)
75007309	TX-1000 ClickSeal biocontainment lids (4x)
75007001	Replacement O-rings
75007300	1000 ml Bio-bottle - polypropylene (4x)
Adapters for Laboratory Use	
75007301	1000 ml Bio-bottle (75007300)
75007304	750 ml polypropylene Bio-bottle
75004253	500 ml Nalgene bottle
75007302	500 ml Corning bottle (requires Corning 431124)
75005392	250 ml Corning Conical bottle or 200 ml Nunc™ bottle or 175 ml Nalgene conical bottle
75007305	250 ml Nalgene bottle / 225 ml BD Falcon™ (requires BD #352090) / 200 ml Nunc conical bottle (requires Nunc #377585) / 175 ml Nalgene conical bottle (requires Nalgene #DS3126-0175)
75004252	50 ml Nalgene Oak Ridge tube
75003829	Small bag/cell culture bags 4 x 2 bags (< 350 ml; 3600 rpm max.)
Adapters for IVD Use	
75003674	50 ml conical tube
75004255	50 ml double biocontainment vessel for 50 ml conical tube (can be combined with ClickSeal lids)
75007306	15 ml conical tube
75003672	10 ml blood collection tube (16 x 100 mm) or Corex™/Kimble™ tubes
75003697	9/10 ml blood collection tube (Sarstedt™)
75003671	5/7 ml blood collection tube (13 x 75-100 mm)
75003709	4.5/6 ml blood collection tube (Greiner™)
75007303	Microplate carriers

B. 4. 4. Biocontainment Certificate

Health Protection Agency
Microbiology Services
Porton Down
Salisbury
Wiltshire
SP4 0JG



Certificate of Containment Testing

Containment Testing of Thermo Scientific TX-1000 Rotor in a Thermo Scientific Centrifuge

Report No. 170-12 G1

Report Prepared For: Thermo Fisher Scientific
Issue Date: 10th October 2012 re-issued 21st August 2013

Test Summary

Thermo Scientific TX-1000 Rotor is identical to the rotor tested according to report 170-12 G. We consider that this rotor will match the performance of that previously containment tested in a Thermo Scientific centrifuge at 5,500 rpm, using Annex AA of IEC 61010-2-020:2006 (2nd Ed.). The sealed rotor was shown to contain all contents.

Report Written By  Name: Ms Anna Moy Title: Biosafety Scientist	Report Authorised By  Name: Mr Simon Parks Title: Senior Biosafety Scientist
---	---

Thermo Scientific is a trademark of Thermo Fisher Scientific and is registered with the USPTO.



B. 5. H-FLEX 1

B. 5. 1. Items Supplied

Article No.	Item	Quantity
75003300	H-FLEX 1 rotor	1
50157859	Rotor safety information	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

B. 5. 2. Technical Data

General Technical Data	
Weight (empty)	6.0 kg
Maximum Permissible Load	2 x 1115 g
Max. Cycle Number	55000
Radius r_{max} / min.	174 mm / 32 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	O-ring 20058488

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm
Maximum RCF-Value at n_{max}	4297 x g
K-Factor at n_{max}	19394
Acceleration / Braking Time	35 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	9 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at n_{max}	4297 x g	4297 x g	4297 x g
K-Factor at n_{max}	19394	19394	19394
Acceleration / Braking Time	40 s / 40 s	40 s / 40 s	45 s / 40 s
Max. Speed at 4 °C	4700 rpm	4700 rpm	4700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -9 °C 60 Hz: -11 °C	0°C	-3°C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm
Maximum RCF-Value at n_{max}	4297 x g
K-Factor at n_{max}	19394
Acceleration / Braking Time	35 s / 35 s
Sample temperature increase after 1 h of continuous run, tolerance $\pm 2K$	9 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4700 rpm	4700 rpm	4700 rpm
Max. RCF-Value at n_{max}	4297 x g	4297 x g	4297 x g
K-Factor at n_{max}	19394	19394	19394
Acceleration / Braking Time	40 s / 40 s	40 s / 40 s	45 s / 40 s
Max. Speed at 4 °C	4700 rpm	4700 rpm	4700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -9 °C 60 Hz: -11 °C	0°C	-3°C



B. 5. 3. Accessories

Article No.	Description
Accessories	
75003301	H-Flex 1 Rotor bucket, set of 2
75003302	Bucket cap H-Flex 1, set of 2
Adapters for Laboratory Use	
75003308	Adapter for TX-400 (see page B-5)
Adapters for IVD Use	
75003303	50 ml conical tube
75003304	15 ml conical tube
75003305	10/12 ml blood collection tube
75003306	5/7 ml blood collection tube
75003307	Microplate carriers

B. 5. 4. Biocontainment Certificate



Public Health England
National Infection Service
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

**Containment Testing of Thermo Scientific
Swinging Buckets (75003301) and
Sealing Caps (75003302)
in a H-Flex 1 (75003300) rotor
in a Thermo Scientific Centrifuge**

Report No. 18-015

Report Prepared For: Thermo Fisher Scientific
Issue Date: 04 September 2018

Test Summary

Thermo Scientific Swinging Buckets (75003301) and Sealing Caps (75003302) in a H-Flex 1 rotor (75003300) were containment tested in a Thermo Scientific centrifuge at 4,700 rpm, using Annex AA of IEC 61010-2-020:2016 (3rd Ed.). The sealed buckets were shown to contain all contents.

Report Written By

Anna Moy

Name: Ms Anna Moy
Title: Biosafety Scientist

Report Authorised By

Sara Speight

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not put the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.



B. 6. H-FLEX HS4

B. 6. 1. Items Supplied

Article No.	Item	Quantity
75003330	H-FLEX HS4 rotor	1
76003500	Rubber seal grease	1
75003786	Bolt grease	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6100 rpm	6100 rpm	6100 rpm
Max. RCF-Value at n_{max}	7196 x g	7196 x g	7196 x g
K-Factor at n_{max}	11474	11474	11474
Acceleration / Braking Time	65 s / 85 s	70 s / 85 s	80 s / 85 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6100 rpm	6100 rpm	6100 rpm
Max. RCF-Value at n_{max}	7196 x g	7196 x g	7196 x g
K-Factor at n_{max}	11474	11474	11474
Acceleration / Braking Time	65 s / 85 s	70 s / 85 s	80 s / 85 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

B. 6. 2. Technical Data

General Technical Data	
Weight (empty)	5.4 kg
Maximum Permissible Load	2 x 1115 g
Max. Cycle Number	22000
Radius max. / min.	173 mm / 32 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	Gasket 20290682

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6100 rpm	6100 rpm	6100 rpm
Max. RCF-Value at n_{max}	7196 x g	7196 x g	7196 x g
K-Factor at n_{max}	11474	11474	11474
Acceleration / Braking Time	60 s / 70 s	60 s / 70 s	70 s / 70 s
Max. Speed at 4 °C	6100 rpm	6100 rpm	6100 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-5 °C	-6 °C	-3 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6100 rpm	6100 rpm	6100 rpm
Max. RCF-Value at n_{max}	7196 x g	7196 x g	7196 x g
K-Factor at n_{max}	11474	11474	11474
Acceleration / Braking Time	60 s / 70 s	60 s / 70 s	70 s / 70 s
Max. Speed at 4 °C	6100 rpm	5600 rpm	5600 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-5 °C	-6 °C	-3 °C



B. 6. 3. Accessories

Article No.	Description
Accessories	
75003338	Bucket H-Flex HS4 (2x)
75003339	Windshield Lid H-Flex HS4
Adapters for Laboratory Use	
75003308	Adapter TX-400
Adapters for IVD Use	
75003303	50 ml conical tube
75003304	15 ml conical tube
75003305	10/12 ml blood collection tube
75003306	5/7 ml blood collection tube
75003307	Microplate carriers

B. 6. 4. Biocontainment Certificate



Public Health England
National Infection Service
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

**Containment Testing of
Thermo Scientific
H-Flex HS4 rotor (75003330) in
a Thermo Scientific Centrifuge**

Report No. 19-085

Report Prepared For: Thermo Fisher Scientific
Issue Date: 22 July 2020

Test Summary

Thermo Scientific H-Flex HS4 rotor (75003330) was containment tested in a Thermo Scientific centrifuge at 6,100 rpm, using Annex AA of IEC 61010-2-020:2016 (3rd Ed.). The sealed rotor was shown to contain all contents.

Report Written By

Name: Ms Helen Hookway
Title: Biosafety Scientist

Report Authorised By

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not put the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.



B. 7. HIGHPlate 6000

B. 7. 1. Items Supplied

Article No.	Item	Quantity
75003606	HIGHPlate 6000	1
76003500	Rubber seal grease	1
75003786	Bolt grease	1
50158588	GP rotors information card	1
50117083	Carrier	2
20056846	Rubber plates	2
50157859	Rotor safety information	1

B. 7. 2. Technical Data

General Technical Data	
Weight (empty)	8.0 kg
Maximum Permissible Load	2 x 500 g
Max. Cycle Number	60000
Radius max. / min.	139 mm / 58 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	Gasket 50117078

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6300 rpm	6300 rpm	6300 rpm
Max. RCF-Value at n_{max}	6168 x g	6168 x g	6168 x g
K-Factor at n_{max}	5571	5571	5571
Acceleration / Braking Time	45 s / 65 s	55 s / 65 s	65 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	16 °C	16 °C	16 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6300 rpm	6300 rpm	6300 rpm
Max. RCF-Value at n_{max}	6168 x g	6168 x g	6168 x g
K-Factor at n_{max}	5571	5571	5571
Acceleration / Braking Time	50 s / 65 s	50 s / 65 s	55 s / 55 s
Max. Speed at 4 °C	6300 rpm	6300 rpm	6300 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-6 °C	-5 °C	-3 °C



B. 7. 3. Accessories

Article No.	Description
Accessories	
75003622	Sealing kit

B. 7. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of Thermo Scientific rotor 75003606


Report No. 59-08 H

Report prepared for: Thermo Fisher
Issue Date: 15th January 2009

Test Summary

A Thermo Scientific 75003606 contained rotor (Max speed 6,300 rpm) was supplied by Thermo Fisher and containment tested at 6,300 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By  **Report Authorised By**  (28/1/09)



B. 8. M-20 Microplate

B. 8. 1. Items Supplied

Article No.	Item	Quantity
75003624	M-20 Microplate	1
76003500	Rubber seal grease	1
75003786	Bolt grease	1
50158588	GP rotors information card	1

B. 8. 2. Technical Data

General Technical Data	
Weight (empty)	4.23 kg
Maximum Permissible Load	2 x 770 g
Max. Cycle Number	50 000
Radius r_{max} / min.	127 mm / 79 mm
Angle	90°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	4000 rpm
Maximum RCF-Value at n_{max}	2272 x g
K-Factor at n_{max}	7507
Acceleration / Braking Time	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	7 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4000 rpm	4000 rpm	4000 rpm
Maximum RCF-Value at n_{max}	2272 x g	2272 x g	2272 x g
K-Factor at n_{max}	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	4000 rpm	4000 rpm	4000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -18 °C 60 Hz: -20 °C	-14 °C	-11 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	4000 rpm
Maximum RCF-Value at n_{max}	2272 x g
K-Factor at n_{max}	7507
Acceleration / Braking Time	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	7 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	4000 rpm	4000 rpm	4000 rpm
Maximum RCF-Value at n_{max}	2272 x g	2272 x g	2272 x g
K-Factor at n_{max}	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	4000 rpm	4000 rpm	4000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -18 °C 60 Hz: -20 °C	-14 °C	-11 °C

B. 8. 3. Technical Data

General Technical Data	
Weight (empty)	4.23 kg
Maximum Permissible Load	2 x 770 g
Max. Cycle Number	50000
Radius max. / min.	127 mm / 79 mm
Angle	90°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges


Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4000 rpm	4000 rpm	4000 rpm
Max. RCF-Value at $n_{\max}$	2272 x g	2272 x g	2272 x g
K-Factor at $n_{\max}$	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	9 °C	9 °C	9 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4000 rpm	4000 rpm	4000 rpm
Max. RCF-Value at $n_{\max}$	2272 x g	2272 x g	2272 x g
K-Factor at $n_{\max}$	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	4000 rpm	4000 rpm	4000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-18 °C	-18 °C	-18 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4000 rpm	4000 rpm	4000 rpm
Max. RCF-Value at $n_{\max}$	2272 x g	2272 x g	2272 x g
K-Factor at $n_{\max}$	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	9 °C	9 °C	9 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	4000 rpm	4000 rpm	4000 rpm
Max. RCF-Value at $n_{\max}$	2272 x g	2272 x g	2272 x g
K-Factor at $n_{\max}$	7507	7507	7507
Acceleration / Braking Time	20 s / 30 s	20 s / 30 s	20 s / 30 s
Max. Speed at 4 °C	4000 rpm	4000 rpm	4000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-18 °C	-18 °C	-18 °C



B. 8. 4. Accessories

Article No.	Description
Accessories	
75002011	Replacement sealing lids (2x)
75002012	Replacement O-rings (4x)
Adapters for IVD Use	
Included	Microplate carriers
76003625	Aerosol-tight capsule
75003624	M-20 rotor cross

B. 8. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment testing of Thermo Scientific swing out bucket rotor 75003624 and buckets 75003625

Report No. 77- 08 C

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific centrifuge bucket 75003625 with aerosol tight lid (Max speed 4,000 rpm) was supplied by Thermo Fisher and containment tested at 4,000 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By



B. 9. BIOShield 720

B. 9. 1. Items Supplied

Article No.	Item	Quantity
75003183	BIOShield 720 rotor	1
76003500	Rubber seal grease	1
75003786	Bolt grease	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1

B. 9. 2. Technical Data

General Technical Data	
Weight (empty)	5.7 kg
Maximum Permissible Load	4 x 470 g
Max. Cycle Number	66000
Radius _{max} / min.	162 mm / 67 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	Gasket 50117078

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	6300 rpm
Maximum RCF-Value at n_{max}	7188 x g
K-Factor at n_{max}	5628
Acceleration / Braking Time	50 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6300 rpm	6300 rpm	6300 rpm
Maximum RCF-Value at n_{max}	7188 x g	7188 x g	7188 x g
K-Factor at n_{max}	5628	5628	5628
Acceleration / Braking Time	55 s / 65 s	50 s / 65 s	55 s / 65 s
Max. Speed at 4 °C	6300 rpm	6300 rpm	5900 rpm
Sample Temp. at n_{max} Speed (ambient temp. at 23 °C, run time 2 h), tolerance $\pm 2 K$	50 Hz: -2 °C 60 Hz: -6 °C	2 °C	6 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5300 rpm
Maximum RCF-Value at n_{max}	5088 x g
K-Factor at n_{max}	7952
Acceleration / Braking Time	50 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	14 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5300 rpm	5300 rpm	6300 rpm
Maximum RCF-Value at n_{max}	5088 x g	5088 x g	5088 x g
K-Factor at n_{max}	7952	7952	7952
Acceleration / Braking Time	55 s / 65 s	50 s / 65 s	55 s / 65 s
Max. Speed at 4 °C	5300 rpm	5300 rpm	5900 rpm
Sample Temp. at n_{max} Speed (ambient temp. at 23 °C, run time 2 h), tolerance $\pm 2 K$	50 Hz: -2 °C 60 Hz: -6 °C	2 °C	6 °C



B. 9. 3. Accessories

Article No.	Description
Accessories	
75003693	180 ml Bio-Bottle - Polypropylene (12x)
75003622	Sealing kit
Adapters for Laboratory Use	
75003813	150 ml round bottom open-top tube
75003814	100 ml round bottom open-top tube
75003816	50 ml DIN round bottom tube
75003817	25 ml DIN round bottom tube
75003820	15 ml Sarstedt tube
75003822	5/7 ml round bottom open-top tube
Adapters for IVD Use	
75003677	50 ml conical tube
75003818	30 ml Sterilin universal tube
75003678	15 ml conical tube
75003701	10 ml blood collection tube (16 x 100 mm)
75003821	5/7 ml blood collection tube (13 x 75-100 mm)
75003823	1.5/2 ml conical microtube

B. 9. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of contained Bioshield 720 Thermo Scientific rotor 75003621

Report No. 77- 08 F

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific 75003621 contained Bioshield 720 rotor (Max speed 6,300 rpm) was supplied by Thermo Fisher and containment tested at 6,300 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By



B. 10. BIOShield 1000A

B. 10. 1. Items Supplied

Article No.	Item	Quantity
75003182	BIOShield 1000A	1
75003786	Bolt grease	1
76003500	Rubber seal grease	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1

B. 10. 2. Technical Data

General Technical Data	
Weight (empty)	8.5 kg
Max. Permissible Load	4 x 600 g
Max. Cycle Number	30000
Radius max. / min.	178 mm / 82 mm
Angle	90°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C
Not Autoclavable Parts	Gasket 20290682

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6000 rpm	6000 rpm	6000 rpm
Maximum RCF-Value at n_{max}	7164 x g	7164 x g	7164 x g
K-Factor at n_{max}	5447	5447	5447
Acceleration / Braking Time	65 s / 85 s	75 s / 85 s	85 s / 85 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	14 °C	14 °C	14 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6000 rpm	6000 rpm	6000 rpm
Max. RCF-Value at n_{max}	7164 x g	7164 x g	7164 x g
K-Factor at n_{max}	5447	5447	5447
Acceleration / Braking Time	70 s / 85 s	70 s / 85 s	80 s / 85 s
Max. Speed at 4 °C	6000 rpm	6000 rpm	6000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	-2 °C	-1 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5300 rpm	5300 rpm	5300 rpm
Max. RCF-Value at n_{max}	5590 x g	5590 x g	5590 x g
K-Factor at n_{max}	6981	6981	6981
Acceleration / Braking Time	65 s / 85 s	75 s / 85 s	85 s / 85 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	10 °C	10 °C	10 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5300 rpm	5300 rpm	5300 rpm
Max. RCF-Value at n_{max}	5590 x g	5590 x g	5590 x g
K-Factor at n_{max}	6981	6981	6981
Acceleration / Braking Time	70 s / 85 s	70 s / 85 s	80 s / 85 s
Max. Speed at 4 °C	5300 rpm	5300 rpm	5300 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-7 °C	-7 °C	-7 °C



B. 10. 3. Accessories

Article No.	Description
Adapters for Laboratory Use	
75003737	250 ml flat bottom bottle
75003738	150 ml round bottom open-top tube
75003742	100 ml round bottom open-top tube
75003749	50 ml round bottom tube
75003750	45 ml flat/round tube
75003756	25 ml DIN round bottom tube
75003758	14 ml flanged round bottom tube
75003769	5/7 ml round bottom tube (13 x 75-100 mm)
Adapters for IVD Use	
75003755	30 ml Sterilin Universal tube
75003759	14 ml round or conical urine tube
75003767	10 ml blood collection (16 x 100 mm) or 15 ml DIN tube
75003768	5/7 ml or 4.5/6 ml blood collection tube
75003643	50 ml conical tube
75003642	15 ml conical tube
75003770	1.5/2 ml Microtube

B. 10. 4. Biocontainment Certificate



Public Health England
National Infection Service
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

**Containment Testing of
Thermo Scientific BIOShield™
1000A (75003182) Rotor in a
Thermo Scientific Centrifuge**

Report No. 18-051

Report Prepared For: Thermo Fisher Scientific
Issue Date: 04 April 2019

Test Summary

Thermo Scientific BIOShield™ 1000A (75003182) rotor was containment tested in a Thermo Scientific centrifuge at 6,000 rpm, using Annex AA of IEC 61010-2-020:2016 (3rd Ed.). The sealed rotor was shown to contain all contents.

Report Written By

Anna Moy

Name: Ms Anna Moy
Title: Biosafety Scientist

Report Authorised By

Sara Speight

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not use the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.



B. 11. CLINiConic

B. 11. 1. Items Supplied

Article No.	Item	Quantity
75003623	CLINiConic rotor	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1
50143707	Small benchtop rotors CD	1

B. 11. 2. Technical Data

General Technical Data	
Weight (empty)	4.7 kg
Maximum Permissible Load	30 x 30 g
Max. Cycle Number	50000
Radius r_{max} / min.	140 mm / 85 mm
Angle	37°
Aerosol-tight	No
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5650 rpm
Maximum RCF-Value at n_{max}	4997 x g
K-Factor at n_{max}	3955
Acceleration / Braking Time	20 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5650 rpm	5650 rpm	5650 rpm
Maximum RCF-Value at n_{max}	4997 x g	4997 x g	4997 x g
K-Factor at n_{max}	3955	3955	3955
Acceleration / Braking Time	20 s / 35 s	20 s / 35 s	20 s / 35 s
Max. Speed at 4 °C	5650 rpm	5650 rpm	5650 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -10 °C 60 Hz: -12 °C	-3 °C	0 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	5650 rpm
Maximum RCF-Value at n_{max}	4997 x g
K-Factor at n_{max}	3955
Acceleration / Braking Time	20 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	5650 rpm	5650 rpm	5650 rpm
Maximum RCF-Value at n_{max}	4997 x g	4997 x g	4997 x g
K-Factor at n_{max}	3955	3955	3955
Acceleration / Braking Time	20 s / 35 s	20 s / 35 s	20 s / 35 s
Max. Speed at 4 °C	5650 rpm	5650 rpm	5650 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -10 °C 60 Hz: -12 °C	-3 °C	0 °C



B. 11. 3. Accessories

Article No.	Description
Adapters for Laboratory Use	
75003702	10 ml round bottom tube
Adapters for IVD Use	
11172596	7 ml blood collection tubes (13 x 100 mm)
11172595	5 ml blood collection tubes (13 x 75 mm)



B. 12. 8 x 50 ml Sealed

B. 12. 1. Items Supplied

Article No.	Item	Quantity
75003694	8 x 50 Individually sealed fixed angle rotor	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1

B. 12. 2. Technical Data

General Technical Data	
Weight (empty)	3.3 kg
Maximum Permissible Load	8 x 189 g
Max. Cycle Number	50 000
Radius _{max.} / min.	143 mm / 69 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	6700 rpm
Maximum RCF-Value at n_{max}	7 177 x g
K-Factor at n_{max}	4 107
Acceleration / Braking Time	30 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	15 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6700 rpm	6700 rpm	6700 rpm
Maximum RCF-Value at n_{max}	7 177 x g	7 177 x g	7 177 x g
K-Factor at n_{max}	4 107	4 107	4 107
Acceleration / Braking Time	25 s / 35 s	25 s / 35 s	25 s / 35 s
Max. Speed at 4 °C	6700 rpm	6500 rpm	6400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -6 °C	3 °C	7 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	6700 rpm
Maximum RCF-Value at n_{max}	7 177 x g
K-Factor at n_{max}	4 107
Acceleration / Braking Time	25 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	15 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	6700 rpm	6700 rpm	6700 rpm
Maximum RCF-Value at n_{max}	7 177 x g	7 177 x g	7 177 x g
K-Factor at n_{max}	4 107	4 107	4 107
Acceleration / Braking Time	25 s / 35 s	25 s / 35 s	25 s / 35 s
Max. Speed at 4 °C	6700 rpm	6500 rpm	6400 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -6 °C	3 °C	7 °C



B. 12. 3. Accessories

Article No.	Description
Adapters for IVD Use	
75005755	15 ml conical tube
75005747	10 ml blood collection tube (16 x 100 mm)
75005748	7 ml blood collection tube (13 x 100 mm)
75005749	3.5 ml blood collection tube

B. 12. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment testing of Thermo Scientific Vessel 75003787

Report No. 77- 08 B

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific vessel 75003787 with aerosol tight lid (Max rcf 7177 x g) was supplied by Thermo Fisher and containment tested at max rcf 7177 x g using the method described in Annex AA of EN 61010-2-020. The vessel was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By



B. 13. HIGHConic II

B. 13. 1. Items Supplied

Article No.	Item	Quantity
75003620	HIGHConic II	1
75003103	HIGHConic II adapter 1x50 ml	6
50158588	GP rotors information card	1
50157859	Rotor safety information	1

B. 13. 2. Technical Data

General Technical Data	
Weight (empty)	3.6 kg
Maximum Permissible Load	6 x 140 g
Max. Cycle Number	50000
Radius _{max} / min.	126 mm / 61 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	10350 rpm
Maximum RCF-Value at n_{max}	15090 x g
K-Factor at n_{max}	1713
Acceleration / Braking Time	40 s / 55 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	10350 rpm	10350 rpm	10350 rpm
Maximum RCF-Value at n_{max}	15090 x g	15090 x g	15090 x g
K-Factor at n_{max}	1713	1713	1713
Acceleration / Braking Time	40 s / 60 s	40 s / 60 s	45 s / 60 s
Max. Speed at 4 °C	10350 rpm	10350 rpm	10350 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -8 °C 60 Hz: -10 °C	-2 °C	2 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	10350 rpm
Maximum RCF-Value at n_{max}	15090 x g
K-Factor at n_{max}	1713
Acceleration / Braking Time	40 s / 55 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	10350 rpm	10350 rpm	10350 rpm
Maximum RCF-Value at n_{max}	15090 x g	15090 x g	15090 x g
K-Factor at n_{max}	1713	1713	1713
Acceleration / Braking Time	40 s / 60 s	40 s / 60 s	45 s / 60 s
Max. Speed at 4 °C	10350 rpm	10350 rpm	10350 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -8 °C 60 Hz: -10 °C	-2 °C	2 °C



B. 13. 3. Technical Data

General Technical Data	
Weight (empty)	3.6 kg
Maximum Permissible Load	6 x 140 g
Max. Cycle Number	50000
Radius max. / min.	126 mm / 61 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10350 rpm	10350 rpm	10350 rpm
Maximum RCF-Value at $n_{\max}$	15090 x g	15090 x g	15090 x g
K-Factor at $n_{\max}$	1713	1713	1713
Acceleration / Braking Time	40 s / 55 s	40 s / 60 s	40 s / 60 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	15 °C	15 °C	15 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10350 rpm	10350 rpm	10350 rpm
Max. RCF-Value at $n_{\max}$	15090 x g	15090 x g	15090 x g
K-Factor at $n_{\max}$	1713	1713	1713
Acceleration / Braking Time	40 s / 60 s	40 s / 60 s	40 s / 60 s
Max. Speed at 4 °C	10350 rpm	10350 rpm	10350 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-11 °C	-10 °C	-8 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10350 rpm	10350 rpm	10350 rpm
Maximum RCF-Value at $n_{\max}$	15090 x g	15090 x g	15090 x g
K-Factor at $n_{\max}$	1713	1713	1713
Acceleration / Braking Time	40 s / 55 s	40 s / 60 s	40 s / 60 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	15 °C	15 °C	15 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10350 rpm	10350 rpm	10350 rpm
Max. RCF-Value at $n_{\max}$	15090 x g	15090 x g	15090 x g
K-Factor at $n_{\max}$	1713	1713	1713
Acceleration / Braking Time	40 s / 60 s	40 s / 60 s	40 s / 60 s
Max. Speed at 4 °C	10350 rpm	10350 rpm	10350 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-11 °C	-10 °C	-8 °C



6. 4. 3. Accessories

Article No.	Description
Accessories	
75003058	Replacement O-ring Kit
Adapters for Laboratory Use	
75003102	50 ml Nalgene Oak Ridge tube
75003094	30 ml Nalgene Oak Ridge tube / 38 ml round tube
76002906	16 ml Nalgene Oak Ridge tube
75003093	10 ml Nalgene Oak Ridge tube / 12 ml round tube
75003092	6.5 ml round bottom tube
Adapters for IVD Use	
75003103	50 ml conical tube
75003095	15 ml conical tube
75003091	1.5/2 ml Microtube

B. 13. 4. Biocontainment Certificate



Public Health England
Microbiology Services
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

**Containment Testing of
Thermo Scientific Rotor 75003620
HIGHConic II – 6x100ml
in a Thermo Scientific Centrifuge**

Report No. 36/13

Report Prepared For: Thermo Fisher Scientific
Issue Date: 4th November 2013

Test Summary

A Thermo Scientific 75003620 HIGHConic II – 6x100ml rotor was containment tested in a Thermo Scientific centrifuge at 12,000 rpm, using Annex AA of IEC 61010-2-020:2006 (2nd Ed.). The sealed rotor was shown to contain all contents.

Report Written By

Anna Moy

Name: Miss Anna Moy
Title: Biosafety Scientist

Report Authorised By

Sara Speight

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not put the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.



B. 14. Microliter 30 x 2

B. 14. 2. Technical Data

B. 14. 1. Items Supplied

Article No.	Item	Quantity
75003652	Microliter 30 x 2	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1
75003349	O-Ring kit	1

General Technical Data	
Weight (empty)	2.1 kg
Maximum Permissible Load	30 x 4 g
Max. Cycle Number	50000
Radius _{max.} / min.	100 mm / 64 mm
Angle	45°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm
Maximum RCF-Value at n_{max}	25830 x g
K-Factor at n_{max}	489
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	23 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25830 x g	25830 x g	25830 x g
K-Factor at n_{max}	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15200 rpm	14000 rpm	14700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	4 °C	7 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm
Maximum RCF-Value at n_{max}	25830 x g
K-Factor at n_{max}	489
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	23 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25830 x g	25830 x g	25830 x g
K-Factor at n_{max}	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15200 rpm	14000 rpm	14700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	4 °C	7 °C



B. 14. 3. Technical Data

General Technical Data	
Weight (empty)	2.1 kg
Maximum Permissible Load	30 x 4 g
Max. Cycle Number	50 000
Radius max. / min.	100 mm / 64 mm
Angle	45°
Aerosol-tight	Optional
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at $n_{\max}$	25830 x g	25830 x g	25830 x g
K-Factor at $n_{\max}$	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at $n_{\max}$	25830 x g	25830 x g	25830 x g
K-Factor at $n_{\max}$	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15200 rpm	15200 rpm	15200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	-5 °C	-3 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at $n_{\max}$	25830 x g	25830 x g	25830 x g
K-Factor at $n_{\max}$	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at $n_{\max}$	25830 x g	25830 x g	25830 x g
K-Factor at $n_{\max}$	489	489	489
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15200 rpm	14800 rpm	14800 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	-5 °C	-3 °C



B. 14. 4. Accessories

Article No.	Description
Accessories	
75003349	Replacement O-ring kit
Adapters for IVD Use	
75005754	0.25 ml Microtube
75005753	0.5 ml Microtube
76003752	0.2 ml PCR tube

B. 14. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of Thermo Scientific rotor 75003652

Report No. 77- 08 H

Report prepared for: Thermo Fisher
Issue Date: 1st June 2009

Test Summary

A Thermo Scientific contained rotor 75003652 (Max speed 15,200 rpm) was supplied by Thermo Fisher and containment tested at 15,200 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By

Report Authorised By



B. 15. Microliter 48 x 2

B. 15. 2. Technical Data

B. 15. 1. Items Supplied

Article No.	Item	Quantity
75003602	Microliter 48 x 2 rotor	1
76003500	Rubber seal grease	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1
75003349	O-Ring kit	1

General Technical Data	
Weight (empty)	2.5 kg
Maximum Permissible Load	48 x 4 g
Max. Cycle Number	50000
Radius _{max.} / min.	98 mm / 59 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	138 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g
K-Factor at n_{max}	556
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15200 rpm	14500 rpm	14700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	2 °C	6 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g
K-Factor at n_{max}	556
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15200 rpm	14500 rpm	14700 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	2 °C	6 °C



B. 15. 3. Technical Data

General Technical Data	
Weight (empty)	2.5 kg
Maximum Permissible Load	48 x 4 g
Max. Cycle Number	50 000
Radius max. / min.	98 mm / 59 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	138 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	35 s / 50 s	35 s / 50 s	35 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	35 s / 50 s	35 s / 50 s	35 s / 50 s
Max. Speed at 4 °C	15200 rpm	15200 rpm	15200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	-5 °C	-3 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Maximum RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	35 s / 50 s	35 s / 50 s	35 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C	21 °C	21 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25314 x g	25314 x g	25314 x g
K-Factor at n_{max}	556	556	556
Acceleration / Braking Time	35 s / 50 s	35 s / 50 s	35 s / 50 s
Max. Speed at 4 °C	15200 rpm	15200 rpm	15200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-3 °C	-5 °C	-3 °C



B. 15. 4. Accessories

Article No.	Description
Accessories	
75003349	Replacement O-ring kit
Adapters for IVD Use	
75005754	0.25 ml Microtube
75005753	0.5 ml Microtube
76003752	0.2 ml PCR tube

B. 15. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing


Containment Testing of Thermo Scientific Rotor 75003602

Report No. 59-08 E

Report prepared for: Thermo Fisher
Issue Date: 15th January 2009

Test Summary

A Thermo Scientific 75003602 contained rotor (Max speed 15,200 rpm) was supplied by Thermo Fisher and containment tested at 15,200 rpm using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill when tested in triplicate.

Report Written By  **Report Authorised By**  (28/1/09)



B. 16. MicroClick 30 x 2

B. 16. 2. Technical Data

B. 16. 1. Items Supplied

Article No.	Item	Quantity
75005719	MicroClick 30 x 2 rotor	1
70902041	ClickSeal lid	1
76003500	Rubber seal grease	1
75005726	O-ring set	1
50158588	GP rotors information card	1
50157859	Rotor safety information	1
50143707	Small benchtop rotors CD	1

General Technical Data	
Weight (empty)	1.44 kg
Maximum Permissible Load	30 x 4 g
Max. Cycle Number	50 000
Radius _{max.} / min.	99 mm / 64 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	138 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	14 000 rpm
Maximum RCF-Value at n_{max}	21 694 x g
K-Factor at n_{max}	563
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14 000 rpm	14 000 rpm	14 000 rpm
Maximum RCF-Value at n_{max}	21 694 x g	21 694 x g	21 694 x g
K-Factor at n_{max}	563	563	563
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 200 rpm	14 000 rpm	14 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -7 °C 60 Hz: -10 °C	-1 °C	1 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	14 000 rpm
Maximum RCF-Value at n_{max}	21 694 x g
K-Factor at n_{max}	563
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14 000 rpm	14 000 rpm	14 000 rpm
Maximum RCF-Value at n_{max}	21 694 x g	21 694 x g	21 694 x g
K-Factor at n_{max}	563	563	563
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 200 rpm	14 000 rpm	14 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -7 °C 60 Hz: -10 °C	-1 °C	1 °C



B. 16. 3. Technical Data

General Technical Data	
Weight (empty)	1.44 kg
Maximum Permissible Load	30 x 4 g
Max. Cycle Number	50 000
Radius max. / min.	99 mm / 64 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	138 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	14 000 rpm	14 000 rpm	14 000 rpm
Maximum RCF-Value at $n_{\max}$	21 694 x g	21 694 x g	21 694 x g
K-Factor at $n_{\max}$	563	563	563
Acceleration / Braking Time	30 s / 40 s	30 s / 40 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	18 °C	18 °C	18 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	14 000 rpm	14 000 rpm	14 000 rpm
Max. RCF-Value at $n_{\max}$	21 694 x g	21 694 x g	21 694 x g
K-Factor at $n_{\max}$	563	563	563
Acceleration / Braking Time	25 s / 40 s	30 s / 40 s	35 s / 45 s
Max. Speed at 4 °C	14 000 rpm	14 000 rpm	14 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-11 °C	-9 °C	-8 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	14 000 rpm	14 000 rpm	14 000 rpm
Max. RCF-Value at $n_{\max}$	21 694 x g	21 694 x g	21 694 x g
K-Factor at $n_{\max}$	563	563	563
Acceleration / Braking Time	30 s / 40 s	30 s / 40 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	18 °C	18 °C	18 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	14 000 rpm	14 000 rpm	14 000 rpm
Max. RCF-Value at $n_{\max}$	21 694 x g	21 694 x g	21 694 x g
K-Factor at $n_{\max}$	563	563	563
Acceleration / Braking Time	30 s / 40 s	30 s / 40 s	35 s / 45 s
Max. Speed at 4 °C	14 000 rpm	14 000 rpm	14 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-11 °C	-9 °C	-8 °C



B. 16. 4. Accessories

Article No.	Description
Accessories	
75005726	Replacement O-ring Kit
Adapters for IVD Use	
75005754	0.25 ml Microtube
75005753	0.5 ml Microtube
76003752	0.2 ml PCR tube

B. 16. 5. Biocontainment Certificate

Health Protection Agency
Microbiology Services
Porton Down
Salisbury
Wiltshire
SP4 0JG



Certificate of Containment Testing

**Containment Testing
of Rotor 75005719 MicroClick 30x2
in a
Thermo Scientific Centrifuge**


Report No. 194-12 B

Report Prepared For: Thermo Fisher Scientific

Issue Date: 30th October 2012

Test Summary

A 75005719 MicroClick 30x2 rotor was containment tested in a Thermo Scientific centrifuge at 15,000 rpm, using Annex AA of IEC 61010-2-20:2006 (2nd Ed.). The sealed rotor was shown to contain all contents.

Report Written By  Name: Ms Anna Moy Title: Biosafety Scientist	Report Authorised By  Name: Mrs Sara Speight Title: Senior Biosafety Scientist
---	---

Thermo Scientific is a trademark of Thermo Fisher Scientific and is registered with the USPTO.



B. 17. MicroClick 18 x 5

B. 17. 1. Items Supplied

Article No.	Item	Quantity
75005765	MicroClick 18 x 5	1
20059119	ClickSeal lid	1
76003500	Rubber seal grease	1
50158588	GP rotors information card	1
75005726	O-ring set	1
50157859	Rotor safety information	1

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15 000 rpm
Maximum RCF-Value at n_{max}	24 652 x g
K-Factor at n_{max}	378
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C

B. 17. 2. Technical Data

General Technical Data	
Weight (empty)	1.7 kg
Maximum Permissible Load	18 x 9 g
Max. Cycle Number	50 000
Radius r_{max} / min.	98 mm / 70 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15 000 rpm	15 000 rpm	15 000 rpm
Maximum RCF-Value at n_{max}	24 652 x g	24 652 x g	24 652 x g
K-Factor at n_{max}	378	378	378
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 000 rpm	14 500 rpm	13 800 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -1 °C 60 Hz: -3 °C	5 °C	8 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	15 000 rpm
Maximum RCF-Value at n_{max}	24 652 x g
K-Factor at n_{max}	378
Acceleration / Braking Time	45 s / 30 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15 000 rpm	15 000 rpm	15 000 rpm
Maximum RCF-Value at n_{max}	24 652 x g	24 652 x g	24 652 x g
K-Factor at n_{max}	378	378	378
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 000 rpm	14 500 rpm	13 800 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -1 °C 60 Hz: -3 °C	5 °C	8 °C



B. 17. 3. Technical Data

General Technical Data	
Weight (empty)	1.7 kg
Maximum Permissible Load	18 x 9 g
Max. Cycle Number	50000
Radius max. / min.	98 mm / 70 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14000 rpm	14000 rpm	14000 rpm
Max. RCF-Value at n_{max}	21475 x g	21475 x g	21475 x g
K-Factor at n_{max}	434	434	434
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	17 °C	17 °C	17 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15000 rpm	15000 rpm	15000 rpm
Max. RCF-Value at n_{max}	24652 x g	24652 x g	24652 x g
K-Factor at n_{max}	378	378	378
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15000 rpm	15000 rpm	15000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	0 °C	-3 °C	0 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14000 rpm	14000 rpm	14000 rpm
Max. RCF-Value at n_{max}	21475 x g	21475 x g	21475 x g
K-Factor at n_{max}	434	434	434
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	17 °C	17 °C	17 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15000 rpm	15000 rpm	15000 rpm
Max. RCF-Value at n_{max}	24652 x g	24652 x g	24652 x g
K-Factor at n_{max}	378	378	378
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15000 rpm	15000 rpm	15000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	0 °C	-3 °C	0 °C



B. 17. 4. Accessories

Article No.	Description
Accessories	
75005726	Replacement O-ring Kit
Adapters for Laboratory Use	
75005756	1.2/2 ml Microtube
Adapters for IVD Use	
75005756	1.5/2 ml Microtube

B. 17. 5. Biocontainment Certificate



Public Health England
Microbiology Services
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

Containment Testing of Thermo Scientific Rotor MicroClick 18x5 (75005765) in a Thermo Scientific Centrifuge

Report No. 102/13

Report Prepared For: Thermo Fisher Scientific
Issue Date: 13th February 2014

Test Summary

A Thermo Scientific MicroClick 18x5 rotor (75005765) was containment tested in a Thermo Scientific centrifuge at 15,000 rpm, using Annex AA of IEC 61010-2-020:2006 (2nd Ed.). The sealed rotor was shown to contain all contents.

Report Written By

Report Authorised By

Anna Moy

Sara Speight

Name: Miss Anna Moy
Title: Biosafety Scientist

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not put the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.



B. 18. Fiberlite F13-14 x 50cy

B. 18. 1. Items Supplied

Article No.	Item	Quantity
75003661*	Fiberlite F13-14 x 50cy	1
50158588	GP rotors information card	1

* Identical with 096-149027.

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed $n_{\max}$	8500 rpm
Maximum RCF-Value at $n_{\max}$	12359 x g
K-Factor at $n_{\max}$	2142
Acceleration / Braking Time	85 s / 80 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	23 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Max. Speed $n_{\max}$	10000 rpm	9250 rpm	9250 rpm
Max. RCF-Value at $n_{\max}$	17105 x g	14636 x g	14636 x g
K-Factor at $n_{\max}$	1640	1917	1917
Acceleration / Braking Time	100 s / 95 s	95 s / 90 s	100 s / 90 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	26 °C	21 °C	21 °C

B. 18. 2. Technical Data

General Technical Data	
Weight (empty)	7.48 kg
Maximum Permissible Load	14 x 75 g
Radius $r_{\max}$ / min.	153 mm / 80 mm
Angle	34°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	8500 rpm	8500 rpm	8500 rpm
Max. RCF-Value at $n_{\max}$	12359 x g	12359 x g	12359 x g
K-Factor at $n_{\max}$	2142	2142	2142
Acceleration / Braking Time	80 s / 85 s	80 s / 80 s	90 s / 85 s
Max. Speed at 4 °C	8500 rpm	8100 rpm	7800 rpm
Sample Temp. at $n_{\max}$ Speed (ambient temp. at 23 °C, run time 2 h), tolerance $\pm 2 K$	50 Hz: 0 °C 60 Hz: -4 °C	6 °C	9 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10000 rpm	9250 rpm	9000 rpm
Max. RCF-Value at $n_{\max}$	17105 x g	14636 x g	13855 x g
K-Factor at $n_{\max}$	1640	1917	2025
Acceleration / Braking Time	105 s / 100 s	95 s / 90 s	100 s / 90 s
Max. Speed at 4 °C	9250 rpm	9250 rpm	9000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	7 °C	3 °C	3 °C



B. 18. 3. Accessories

Article No.	Description
Accessories	
021-149027	Replacement O-ring Kit
Adapters for Laboratory Use	
010-0377	50 ml Nalgene Oak Ridge tube
010-1147	30 ml Nalgene Oak Ridge tube
010-0376	16 ml Nalgene Oak Ridge tube
010-1311	10 ml Nalgene Oak Ridge tube / 12 ml round tube
Adapters for IVD Use	
75100378	15 ml conical tube
010-1340	15 ml nunc conical tube and filtration devices

B. 18. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of F13-14x50c Rotor
in a Thermo Fisher Scientific Centrifuge.
MFG No: 096-145001 and 096-149027

Report No. 46-09 A

Report prepared for: Thermo Fisher Scientific
Issue Date: 22nd July 2009

Test Summary

A Piramoon technologies Inc. Fiberlite F13-14X50cy (max speed 13,000rpm) rotor was containment tested in a Thermo Fisher Scientific centrifuge at 13,000rpm, using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill within the rotor.

Report Written By

Report Authorised By

NOTICE This certificate is also valid for 75003661.



B. 19. Fiberlite F14-6 x 250 LE

B. 19. 2. Technical Data

B. 19. 1. Items Supplied

Article No.	Item	Quantity
75003662*	Fiberlite F14-6 x 250 LE	1
50158588	GP rotors information card	1

* Identical with 096-062153.

General Technical Data	
Weight (empty)	8.39 kg
Maximum Permissible Load	6 x 400 g
Radius max. / min.	137 mm / 37 mm
Angle	23°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	11 000 rpm	10 000 rpm	10 000 rpm
Max. RCF-Value at n_{max}	18 533 x g	15 317 x g	15 317 x g
K-Factor at n_{max}	2 737	3 312	3 312
Acceleration / Braking Time	90 s / 95 s	90 s / 85 s	100 s / 85 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C	19 °C	17 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	11 000 rpm	10 000 rpm	10 000 rpm
Max. RCF-Value at n_{max}	18 533 x g	15 317 x g	15 317 x g
K-Factor at n_{max}	2 737	3 312	3 312
Acceleration / Braking Time	95 s / 100 s	85 s / 90 s	95 s / 85 s
Max. Speed at 4 °C	10 000 rpm	10 000 rpm	10 000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	9 °C	3 °C	4 °C



B. 19. 3. Accessories

Article No.	Description
Accessories	
010-1309	Replacement O-ring Kit
Adapters for Laboratory Use	
010-1119	85 ml Nalgene Oak Ridge tube
010-1072	30 ml Nalgene Oak Ridge tube / 38 ml round tube
010-1074	16 ml Nalgene Oak Ridge tube
010-1309	10 ml Nalgene Oak Ridge tube / 12 ml round tube (each)
010-0138	50 ml Nalgene Oak Ridge tube
Adapters for IVD Use	
75100136	50 ml conical tube
010-1410	15 ml conical tube

B. 19. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

**Containment testing of F14-6x250
Rotor in a Thermo Fisher Scientific
Centrifuge includes items 096-062153
and 096-062034.**

Report No. 46-09 B

Report prepared for: Thermo Fisher Scientific
Issue Date: 22nd July 2009

Test Summary

A Piramoon technologies Inc. Fiberlite F14-6X250y (max speed 14,000rpm) rotor was containment tested in a Thermo Fisher Scientific centrifuge at 14,000rpm, using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill within the rotor.

Report Written By

Report Authorised By

NOTICE This certificate is also valid for 75003662.



B. 20. Fiberlite F15-6 x 100y

B. 20. 1. Items Supplied

Article No.	Item	Quantity
75003698*	Fiberlite F15-6 x 100y	1
50158588	GP rotors information card	1

* Identical with 096-069031.

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 000 rpm
Maximum RCF-Value at $n_{\max}$	24 652 x g
K-Factor at $n_{\max}$	1 536
Acceleration / Braking Time	50 s / 60 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C

B. 20. 2. Technical Data

General Technical Data	
Weight (empty)	3.63 kg
Maximum Permissible Load	6 x 126 g
Radius $r_{\max}$ / min.	98 mm / 25 mm
Angle	25°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 000 rpm	15 000 rpm	15 000 rpm
Maximum RCF-Value at $n_{\max}$	24 652 x g	24 652 x g	24 652 x g
K-Factor at $n_{\max}$	1 536	1 536	1 536
Acceleration / Braking Time	50 s / 65 s	50 s / 60 s	55 s / 65 s
Max. Speed at 4 °C	14 500 rpm	12 800 rpm	13 600 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: 4 °C 60 Hz: 1 °C	10 °C	14 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed $n_{\max}$	13 000 rpm
Maximum RCF-Value at $n_{\max}$	18 516 x g
K-Factor at $n_{\max}$	2 045
Acceleration / Braking Time	50 s / 60 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	19 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 000 rpm	15 000 rpm	15 000 rpm
Maximum RCF-Value at $n_{\max}$	18 516 x g	18 516 x g	18 516 x g
K-Factor at $n_{\max}$	2 045	2 045	2 045
Acceleration / Braking Time	50 s / 65 s	50 s / 65 s	55 s / 65 s
Max. Speed at 4 °C	14 500 rpm	12 800 rpm	13 600 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: 4 °C 60 Hz: 1 °C	10 °C	14 °C



B. 20. 3. Technical Data

General Technical Data	
Weight (empty)	3.63 kg
Maximum Permissible Load	6 x 126 g
Radius max. / min.	98 mm / 25 mm
Angle	25°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15000 rpm	15000 rpm	15000 rpm
Max. RCF-Value at n_{max}	24652 x g	24 652 x g	24 652 x g
K-Factor at n_{max}	1536	1 536	1 536
Acceleration / Braking Time	45 s / 60 s	50 s / 65 s	50 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	23 °C	23 °C	23 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15000 rpm	15000 rpm	15000 rpm
Max. RCF-Value at n_{max}	24652 x g	24 652 x g	24 652 x g
K-Factor at n_{max}	1536	1 536	1 536
Acceleration / Braking Time	50 s / 65 s	50 s / 65 s	50 s / 65 s
Max. Speed at 4 °C	15000 rpm	15000 rpm	15000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	3 °C	4 °C	4 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14000 rpm	14000 rpm	14000 rpm
Max. RCF-Value at n_{max}	21474 x g	21474 x g	21474 x g
K-Factor at n_{max}	1763	1763	1763
Acceleration / Braking Time	45 s / 60 s	50 s / 60 s	50 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	20 °C	20 °C	20 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14000 rpm	14000 rpm	14000 rpm
Max. RCF-Value at n_{max}	21474 x g	21474 x g	21474 x g
K-Factor at n_{max}	1763	1763	1763
Acceleration / Braking Time	50 s / 65 s	50 s / 65 s	50 s / 65 s
Max. Speed at 4 °C	14000 rpm	14000 rpm	14000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	1 °C	1 °C	1 °C



B. 20. 4. Accessories

Article No.	Description
Accessories	
021-069031	Replacement O-ring Kit
Adapters for Laboratory Use	
75003102	50 ml Nalgene Oak Ridge tube
76002906	16 ml Nalgene Oak Ridge tube
75003093	10 ml Nalgene Oak Ridge tube / 12 ml round tube
75003092	6.5 ml round bottom tube
75003094	30 ml Nalgene™ Oak Ridge tube / 38 ml round tube
Adapters for IVD Use	
75003103	50 ml conical tube
75003095	15 ml conical tube
75003091	1.5/2 ml Microtube

B. 20. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of Fiberlite F15-6x100y Rotor in the Thermo Fisher Scientific Centrifuge

Report No. 59-09 B

Report prepared for: Thermo Fisher Scientific
Issue Date: 22nd April 2010

Test Summary

A Piramoon Technologies Inc. Fiberlite F15-6x100y (max speed 15,000rpm) rotor was containment tested in the Thermo Fisher Scientific centrifuge at 15,000rpm, using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill within the rotor.

Report Written By

Report Authorised By



B. 21. Fiberlite F15-8 x 50cy

B. 21. 1. Items Supplied

Article No.	Item	Quantity
75003663*	Fiberlite F15-8 x 50cy	1
50158588	GP rotors information card	1

* Identical with 096-085077.

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	14 500 rpm
Maximum RCF-Value at n_{max}	24 446 x g
K-Factor at n_{max}	1 063
Acceleration / Braking Time	65 s / 65 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	24 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14 500 rpm	14 500 rpm	14 500 rpm
Max. RCF-Value at n_{max}	24 446 x g	24 446 x g	24 446 x g
K-Factor at n_{max}	1 063	1 063	1 063
Acceleration / Braking Time	65 s / 65 s	65 s / 65 s	70 s / 70 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	23 °C	23 °C	23 °C

B. 21. 2. Technical Data

General Technical Data	
Weight (empty)	4.45 kg
Maximum Permissible Load	8 x 75 g
Radius r_{max} / min.	104 mm / 43 mm
Angle	34°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14 500 rpm	14 500 rpm	14 500 rpm
Max. RCF-Value at n_{max}	24 446 x g	24 446 x g	21 191 x g
K-Factor at n_{max}	1 063	1 063	1 226
Acceleration / Braking Time	65 s / 65 s	75 s / 70 s	75 s / 70 s
Max. Speed at 4 °C	50 Hz: 13 500 rpm 60 Hz: 13 800 rpm	12 300 rpm	11 800 rpm
Sample Temp. at n_{max} Speed (ambient temp. at 23 °C, run time 2 h), tolerance $\pm 2 K$	50 Hz: 11 °C 60 Hz: 7 °C	17 °C	19 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	14 500 rpm	14 500 rpm	14 500 rpm
Max. RCF-Value at n_{max}	24 446 x g	24 446 x g	24 446 x g
K-Factor at n_{max}	1 063	1 063	1 063
Acceleration / Braking Time	65 s / 70 s	65 s / 70 s	70 s / 70 s
Max. Speed at 4 °C	13 500 rpm	13 500 rpm	13 500 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	8 °C	9 °C	9 °C



B. 21. 3. Accessories

Article No.	Description
Accessories	
021-085077	Replacement O-ring kit
Adapters for Laboratory Use	
010-0377	50 ml Nalgene Oak Ridge tube
010-1147	30 ml Nalgene Oak Ridge tube
010-0376	16 ml Nalgene Oak Ridge tube
010-1311	10 ml Nalgene Oak Ridge tube / 12 ml round tube
Adapters for IVD Use	
75100378	15 ml conical tube
010-1340	15 ml Nunc conical tube and filtration devices

B. 21. 4. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of Fiberlite F15-8x50cy Rotor in the Thermo Fisher Scientific Centrifuge

Report No. 43-10


Report prepared for: Thermo Fisher Scientific
Issue Date: 22nd April 2010

Test Summary

A Piramoon Technologies Inc. Fiberlite F15-8x50cy (max speed 15,000rpm) rotor was containment tested in the Thermo Fisher Scientific centrifuge at 14,500rpm, using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill within the rotor.

Report Written By

Report Authorised By



B. 22. Fiberlite F21-48 x 2

B. 22. 1. Items Supplied

Article No.	Item	Quantity
75003664*	Fiberlite F21-48 x 2	1
50158588	GP rotors information card	1

* Identical with 096-489021.

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 200 rpm
Maximum RCF-Value at $n_{\max}$	25 055 x g
K-Factor at $n_{\max}$	455
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 200 rpm
Maximum RCF-Value at $n_{\max}$	25 055 x g
K-Factor at $n_{\max}$	455
Acceleration / Braking Time	30 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C

B. 22. 2. Technical Data

General Technical Data	
Weight (empty)	2.6 kg
Maximum Permissible Load	48 x 4 g
Radius $r_{\max}$ / min.	97 mm / 64 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 200 rpm	15 200 rpm	15 200 rpm
Maximum RCF-Value at $n_{\max}$	25 055 x g	25 055 x g	25 055 x g
K-Factor at $n_{\max}$	455	455	455
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 200 rpm	14 500 rpm	14 500 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	4 °C	7 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	15 200 rpm	15 200 rpm	15 200 rpm
Maximum RCF-Value at $n_{\max}$	25 055 x g	25 055 x g	25 055 x g
K-Factor at $n_{\max}$	455	455	455
Acceleration / Braking Time	30 s / 45 s	30 s / 45 s	30 s / 45 s
Max. Speed at 4 °C	15 200 rpm	14 500 rpm	14 500 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -2 °C 60 Hz: -5 °C	4 °C	7 °C



B. 22. 3. Technical Data

General Technical Data	
Weight (empty)	2.6 kg
Maximum Permissible Load	48 x 4 g
Radius max. / min.	97 mm / 64 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25055 x g	25055 x g	25055 x g
K-Factor at n_{max}	455	455	455
Acceleration / Braking Time	30 s / 45 s	35 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C	22 °C	22 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25055 x g	25055 x g	25055 x g
K-Factor at n_{max}	455	455	455
Acceleration / Braking Time	35 s / 45 s	35 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15200 rpm	15200 rpm	15200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	1 °C	-4 °C	-2 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25055 x g	25055 x g	25055 x g
K-Factor at n_{max}	455	455	455
Acceleration / Braking Time	35 s / 45 s	30 s / 45 s	35 s / 45 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	22 °C	22 °C	22 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	15200 rpm	15200 rpm	15200 rpm
Max. RCF-Value at n_{max}	25055 x g	25055 x g	25055 x g
K-Factor at n_{max}	455	455	455
Acceleration / Braking Time	35 s / 45 s	35 s / 45 s	35 s / 45 s
Max. Speed at 4 °C	15200 rpm	15000 rpm	15000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	1 °C	-4 °C	-2 °C



B. 22. 4. Accessories

Article No.	Description
Accessories	
021-489021	Replacement O-ring Kit
Adapters for IVD Use	
76003750	0.2 ml PCR tube

B. 22. 5. Biocontainment Certificate

Centre of Emergency Preparedness and Response
Health Protection Agency
Porton Down
Salisbury
Wiltshire SP4 0JG
United Kingdom



Certificate of Containment Testing

Containment Testing of Fiberlite F21-48X1.5 Rotor in the Thermo Scientific GP3 Centrifuge

Report No. 59-09 A

Report prepared for: Thermo Fisher Scientific
Issue Date: 9th December 2009

Test Summary

A Piramoon technologies Inc. Fiberlite F21-48X1.5 (max speed 15,200rpm) rotor was containment tested in the Thermo Scientific GP3 centrifuge at 15,200rpm, using the method described in Annex AA of EN 61010-2-020. The rotor was shown to contain a spill within the rotor.

Report Written By

Anna Mey

Report Authorised By

[Signature]



B. 23. Fiberlite H3-LV

B. 23. 1. Items Supplied

Article No.	Item	Quantity
75003665	Fiberlite H3-LV	1
50158588	GP rotors information card	1

* Identical with 096-029051.

Performance data of the compatible ventilated
4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	3600 rpm	3600 rpm	3600 rpm
Max. RCF- Value at $n_{\max}$	1840 x g	1840 x g	1840 x g
K-Factor at $n_{\max}$	28 169	28 169	28 169
Acceleration / Braking Time	30 s / 35 s	30 s / 35 s	30 s / 35 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	6 °C	6 °C	6 °C

B. 23. 2. Technical Data

General Technical Data	
Weight (empty)	6.5 kg
Maximum Permissible Load	2 x 1200 g
Radius max. / min.	127 mm / 30 mm
Angle	90°
Aerosol-tight	No
Max. Autoclaving Temperature	121 °C

Performance data of the compatible refrigerated
4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	3600 rpm	3600 rpm	3600 rpm
Max. RCF- Value at $n_{\max}$	1840 x g	1840 x g	1840 x g
K-Factor at $n_{\max}$	28 169	28 169	28 169
Acceleration / Braking Time	30 s / 35 s	30 s / 35 s	30 s / 35 s
Max. Speed at 4 °C	3600 rpm	3600 rpm	3600 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-13 °C	-13 °C	-9 °C

B. 23. 3. Accessories



Article No.	Description
Accessories	
Included	Microplate Carriers



B. 24. Fiberlite F10-6 x 100 LEX

B. 24. 2. Technical Data

B. 24. 1. Items Supplied

Article No.	Item	Quantity
75003340*	Fiberlite F10-6 x 100 LEX	1
50158588	GP rotors information card	1

* Identical with 096-069035.

General Technical Data	
Weight (empty)	3.3 kg
Maximum Permissible Load	6 x 126 g
Radius _{max} / min.	122 mm / 33 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 2 L centrifuges

Thermo Scientific X2T / X2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	10500 rpm
Maximum RCF-Value at n_{max}	15038 x g
K-Factor at n_{max}	3000
Acceleration / Braking Time	45 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C

Performance data of the compatible refrigerated 2 L centrifuges

Thermo Scientific X2TR / X2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	10500 rpm	10500 rpm	10500 rpm
Maximum RCF-Value at n_{max}	15038 x g	15038 x g	15038 x g
K-Factor at n_{max}	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 50 s	45 s / 50 s
Max. Speed at 4 °C	10500 rpm	10000 rpm	10200 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -4 °C 60 Hz: -8 °C	2 °C	5 °C

Thermo Scientific S2T / S2T-MD	
Centrifuge Voltage	100-240 V, 50/60 Hz
Maximum Speed n_{max}	10500 rpm
Maximum RCF-Value at n_{max}	15038 x g
K-Factor at n_{max}	3000
Acceleration / Braking Time	45 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	21 °C

Thermo Scientific S2TR / S2TR-MD			
Centrifuge Voltage	220-230 V, 50/60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed n_{max}	10500 rpm	10500 rpm	10500 rpm
Maximum RCF-Value at n_{max}	15038 x g	15038 x g	15038 x g
K-Factor at n_{max}	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 50 s	45 s / 50 s
Max. Speed at 4 °C	10500 rpm	10000 rpm	10000 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	50 Hz: -4 °C 60 Hz: -8 °C	2 °C	5 °C



B. 24. 3. Technical Data

General Technical Data	
Weight (empty)	3.3 kg
Maximum Permissible Load	6 x 126 g
Radius max. / min.	122 mm / 33 mm
Angle	45°
Aerosol-tight	Yes
Max. Autoclaving Temperature	121 °C

Performance data of the compatible ventilated 4 L centrifuges

Thermo Scientific X4T / X4T IVD-MD Thermo Scientific X4F / X4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10500 rpm	10500 rpm	10500 rpm
Max. RCF- Value at $n_{\max}$	15038 x g	15038 x g	15038 x g
K-Factor at $n_{\max}$	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 50 s	50 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	13 °C	13 °C

Performance data of the compatible refrigerated 4 L centrifuges

Thermo Scientific X4TR / X4TR IVD-MD Thermo Scientific X4FR / X4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10500 rpm	10500 rpm	10500 rpm
Max. RCF- Value at $n_{\max}$	15038 x g	15038 x g	15038 x g
K-Factor at $n_{\max}$	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 40 s	50 s / 50 s
Max. Speed at 4 °C	10500 rpm	10500 rpm	10500 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-8 °C	-4 °C	-5 °C

Thermo Scientific S4T / S4T IVD-MD Thermo Scientific S4F / S4F IVD-MD			
Centrifuge Voltage	208-240 V, 50/60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10500 rpm	10500 rpm	10500 rpm
Max. RCF- Value at $n_{\max}$	15038 x g	15038 x g	15038 x g
K-Factor at $n_{\max}$	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 50 s	50 s / 50 s
Sample temperature increase after 1 h continuous run, tolerance $\pm 2K$	13 °C	13 °C	13 °C

Thermo Scientific S4TR / S4TR IVD-MD Thermo Scientific S4FR / S4FR IVD-MD			
Centrifuge Voltage	220 V, 60 Hz 220-240 V, 50 Hz 230 V, 60 Hz	120 V, 60 Hz	100 V, 50/60 Hz
Maximum Speed $n_{\max}$	10500 rpm	10500 rpm	10500 rpm
Max. RCF- Value at $n_{\max}$	15038 x g	15038 x g	15038 x g
K-Factor at $n_{\max}$	3000	3000	3000
Acceleration / Braking Time	45 s / 50 s	45 s / 50 s	50 s / 50 s
Max. Speed at 4 °C	10500 rpm	10500 rpm	10500 rpm
Min. Sample Temperature at Max. Speed (ambient temperature of 23 °C, run time 2 h)	-8 °C	-4 °C	-5 °C



B. 24. 4. Accessories

Article No.	Description
Adapters for Laboratory Use	
75003102	50 ml Nalgene Oak Ridge tube
76002906	16 ml Nalgene Oak Ridge tube
75003093	10 ml Nalgene Oak Ridge tube / 12 ml round tube
75003092	6.5 ml round bottom tube
75003094	30 ml Nalgene™ Oak Ridge tube / 38 ml round tube
Adapters for IVD Use	
75003103	50 ml conical tube
75003095	15 ml conical tube
75003091	1.5/2 ml Microtube

B. 24. 5. Biocontainment Certificate



Public Health England
Microbiology Services
Porton Down
Salisbury
Wiltshire
SP4 0JG

Certificate of Containment Testing

**Containment Testing of
Thermo Scientific Fiberlite
F10-6 x 100 LEX rotor
(096-069035, 75003340) in a
Thermo Scientific Centrifuge
Report No. 18-022**

Report Prepared For: Thermo Fisher Scientific
Issue Date: 07 September 2018

Test Summary

Thermo Scientific Fiberlite F10-6 x 100 LEX rotor (096-069035, 75003340) was containment tested in a Thermo Scientific centrifuge at 10,500 rpm, using Annex AA of IEC 61010-2-020:2016 (3rd Ed.). The sealed rotor was shown to contain all contents.

Report Written By

Anna Moy

Name: Ms Anna Moy
Title: Biosafety Scientist

Report Authorised By

Sara Speight

Name: Mrs Sara Speight
Title: Senior Biosafety Scientist

Please be aware that the use of the Royal Coat of Arms is highly restricted and cannot be copied. Please do not put the PHE logo on your website or use our name to endorse your products. Any reference to PHE needs to be approved by us before it can be used.

C. Chemical Compatibility

Chemical Compatibility																					
CHEMICAL	MATERIAL																				
		2-MERCAPTOETHANOL	ACETALDEHYDE	ACETONE	ACETONITRILE	ALCONOX™	ALLYL ALCOHOL	ALUMINUM CHLORIDE	FORMIC ACID (100%)	AMMONIUM ACETATE	AMMONIUM CARBONATE	AMMONIUM HYDROXIDE (10%)	AMMONIUM HYDROXIDE (28%)	S	M	U	/				
		S	S	M	S	U	/	U	S	M	U	U	U	S	S	U	/				
		S	/	S	S	S	/	S	S	S	S	S	S	S	S	S	S				
		S	M	U	M	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	S	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				
		S	/	U	S	S	/	S	U	S	S	S	S	S	S	S	S				

Chemical Compatibility		MATERIAL		CHEMICAL	
		Viton™	U	S	S
		Tygon™	/	S	S
		Titanium	S	S	S
		Stainless Steel	S	M	U
		Silicone Rubber	S	S	S
		Rulon A™, Teflon™	S	S	S
		Polyvynil Chloride	M	S	S
		Polysulfone	/	S	S
		Polypropylene	S	S	S
		Polyethylene	S	S	S
		Polythermide	S	/	/
		Polyester, Glass Thermoset	U	M	S
		Polycarbonate	U	S	S
		Polyallomer	S	S	S
		PET ¹ , Polyclear™, Clear Crimp™	U	/	S
		Nylon	S	S	S
		Noryl™	/	S	S
		Neoprene	S	S	S
		Glass	/	S	S
		EPDM rubber	S	S	S
		Delrin™	M	S	U
		Composite Carbon Fiber/Epoxy	U	S	S
		Polyurethane Rotor Paint	S	S	/
		Cellulose Acetate Butyrate	U	/	/
		Buna N	U	S	S
		Anodic Coating for Aluminum	U	/	M
		Aluminium	U	U	S
		AMMONIUM HYDROXIDE (CONC.)	U	/	M
		AMMONIUM PHOSPHATE	U	S	S
		AMMONIUM SULFATE	U	S	S
		AMYL ALCOHOL	S	/	M
		ANILINE	S	S	U
		SODIUM HYDROXIDE (<1%)	U	/	M
		SODIUM HYDROXIDE (10%)	U	/	M
		BARIUM SALTS	M	U	S
		BENZENE	S	S	U
		BENZYL ALCOHOL	S	/	M
		BORIC ACID	U	S	M
		CESIUM ACETATE	M	/	S
		CESIUM BROMIDE	M	S	/
		CESIUM CHLORIDE	M	S	U
		CESIUM FORMATE	M	S	/
	S	Satisfactory			
	M	Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use			
	U	Unsatisfactory, not recommended			
	/	Performance unknown; suggest testing, using sample to avoid loss of valuable material			

Chemical Compatibility																												
CHEMICAL	MATERIAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	S	S	M	S	S	S	S	S	S	/	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	M
CESIUM IODIDE		S	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	M	
CESIUM SULFATE		S	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	M	
CHLOROFORM		S	M	U	U	M	S	U	U	S	M	U	U	M	S	U	U	M	U	U	U	U	U	U	U	U	U	
CHROMIC ACID (10%)		S	S	S	U	M	S	M	U	S	S	M	U	M	S	S	U	U	S	/	/	U	U	U	U	U	/	
CHROMIC ACID (50%)		S	/	M	U	/	S	U	/	S	U	/	/	U	U	U	U	S	U	S	/	S	/	/	/	S	U	
CRESOL MIXTURE		S	U	S	S	S	S	U	/	U	M	S	M	U	U	S	U	S	U	U	U	S	S	S	/	S	S	
CYCLOHEXANE		S	U	M	M	U	S	M	M	U	M	S	M	U	U	S	S	S	S	U	S	U	S	S	/	S	S	
DEOXYCHOLATE		S	S	S	S	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	S	
DISTILLED WATER		S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	
DEXTRAN		M	S	S	M	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S	S	S	M	
DIETHYL ETHER		S	M	S	S	S	S	U	U	U	U	U	U	U	U	U	S	U	U	S	U	S	S	U	U	S	S	
DIETHYL KETONE		S	U	S	/	/	S	U	/	M	M	U	U	U	M	/	S	/	U	U	/	M	/	/	U	U	S	
DIETHYLPYRO-CARBONATE		S	S	S	S	S	S	M	S	S	S	/	/	U	S	U	S	U	S	S	/	S	S	S	/	S	S	
DIMETHYLSULFOXIDE		S	U	S	S	S	S	U	U	S	S	/	U	U	S	U	S	S	U	U	/	S	S	S	U	S	U	
DIOXANE		M	U	S	S	S	S	U	M	M	M	/	U	U	M	U	S	U	U	U	M	M	S	S	U	S	U	
FERRIC CHLORIDE		U	/	S	U	M	/	/	/	S	S	/	/	/	S	/	S	/	M	M	S	M	/	/	/	S	/	
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																												
CHEMICAL	MATERIAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		U	/	S	U	U	S	S	M	/	S	S	M	U	U	U	U	U	S	U	S	M	U	S	S	U	S	S
ACETIC ACID (GLACIAL)		U	/	S	U	U	S	M	M	U	S	M	U	U	U	U	U	S	U	U	S	U	S	S	U	U	S	
ACETIC ACID (5%)		M	S	S	M	S	S	M	S	S	S	S	S	U	M	U	S	S	S	S	S	M	S	S	S	M	S	
ACETIC ACID (60%)		U	M	S	U	M	S	M	S	M	S	/	U	U	S	U	U	S	M	S	/	M	U	S	U	U	S	
ETHYL ACETATE		U	S	S	M	M	S	U	U	S	S	S	S	U	M	U	S	U	S	S	M	M	S	S	U	M	M	
ETHYL ALCOHOL (50%)		U	S	S	M	S	S	S	S	S	S	S	S	U	S	U	S	S	S	S	S	M	M	S	S	S	S	
ETHYL ALCOHOL (95%)		U	S	S	U	S	S	S	M	S	S	S	/	U	S	U	S	S	S	U	S	M	S	S	U	U	S	
ETHYLENE DICHLORIDE		S	/	S	/	U	S	U	/	U	U	U	U	U	S	U	S	U	U	/	M	S	/	U	U	/	S	
ETHYLENE GLYCOL		S	M	S	M	S	S	S	S	S	S	S	S	U	S	/	S	S	S	S	S	S	S	S	S	S	S	
ETHYLENE OXIDE VAPOR		S	S	S	S	U	S	U	S	S	S	/	U	M	S	/	S	/	U	S	/	/	U	U	/	/	S	
FICOLL-HYPAQUE™		M	S	S	M	S	S	S	S	S	S	S	/	S	S	/	S	S	S	S	/	S	S	S	/	S	S	
HYDROFLUORIC ACID (10%)		U	/	U	U	U	S	M	S	S	S	S	U	M	S	/	S	U	U	U	/	/	/	/	U	U	U	
HYDROFLUORIC ACID (50%)		U	/	U	U	U	S	M	M	S	S	U	U	U	S	U	U	U	U	U	/	/	/	/	U	U	U	
HYDROCHLORIC ACID (CONC.)		U	/	U	U	U	S	U	/	S	/	U	U	U	M	U	U	M	U	U	/	M	U	U	U	U	U	
FORMALDEHYDE (40%)		M	M	S	M	S	S	S	M	S	S	U	S	S	S	M	S	S	S	S	M	M	S	S	S	M	U	
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																													
CHEMICAL	MATERIAL	Aluminium	Anodic Coating for Aluminum	Buna N	Cellulose Acetate Butyrate	Polyurethane Rotor Paint	Composite Carbon Fiber/Epoxy	Delrin™	EPDM rubber	Glass	Neoprene	Noryl™	Nylon	PET¹, Polyclear™,Clear Crimp™	Polyallomer	Polycarbonate	Polyester, Glass Thermoset	Polythermide	Polyethylene	Polypropylene	Polysulfone	Polyvynil Chloride	Rulon A™, Teflon™	Silicone Rubber	Stainless Steel	Titanium	Tygon™	Viton™	
		S	S	S	S	/	/	S	/	S	S	S	S	S	S	S	S	/	/	S	S	S	/	S	S	S	S	/	S
GLUTARALDEHYDE		S	S	S	/	S	S	S	/	S	S	S	S	S	S	S	S	/	/	S	S	S	/	S	S	S	S	/	S
GLYCEROL		M	S	S	/	S	S	S	S	S	S	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	S	S	S
GUANIDINE HYDROCHLORIDE		U	U	S	/	S	S	S	/	S	S	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	S	S	S
HAEMO-SOL™		S	S	S	/	/	/	S	/	S	S	S	S	S	S	S	/	/	U	S	S	M	S	S	S	S	S	S	S
HEXANE		S	S	S	/	S	S	S	/	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S
ISOBUTYL ALCOHOL		/	/	M	U	/	/	S	S	/	U	/	S	U	S	S	M	S	S	S	S	S	S	S	/	S	/	S	S
ISOPROPYL ALCOHOL		M	M	M	U	S	S	S	S	S	U	S	S	U	S	U	M	M	S	S	S	S	S	S	M	M	M	S	S
IODOACETIC ACID		S	S	M	/	S	S	S	/	S	M	S	S	M	S	S	/	M	S	S	S	S	S	M	S	S	M	M	M
POTASSIUM BROMIDE		U	S	S	/	S	S	S	/	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	M	S	S	S	S
POTASSIUM CARBONATE		M	U	S	S	S	S	S	/	S	S	S	S	S	S	U	S	S	S	S	S	S	S	S	S	S	S	S	S
POTASSIUM CHLORIDE		U	S	S	/	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S	S	S	S	S	U	S	S	S	S
POTASSIUM HYDROXIDE (5%)		U	U	S	S	S	S	M	/	S	S	S	S	/	S	U	S	S	S	S	S	S	S	M	U	M	S	U	U
POTASSIUM HYDROXIDE (CONC.)		U	U	M	U	/	/	M	/	M	S	S	/	U	M	U	U	U	S	M	M	M	U	/	U	U	/	U	U
POTASSIUM PERMANGANATE		S	S	S	/	S	S	S	/	S	S	S	U	S	S	S	M	/	S	M	M	U	S	S	M	S	U	U	S
S		Satisfactory																											
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																											
U		Unsatisfactory, not recommended																											
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																											

Chemical Compatibility																												
MATERIAL	CHEMICAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	S	S	M	S	S	S	S	S	S	/	S	S	M	S	S	S	S	S	S	S	S	S	S	S	U	M
	CALCIUM CHLORIDE	S	/	S	U	M	S	M	S	S	S	/	S	M	S	S	/	S	U	M	/	S	M	S	/	U	M	
	CALCIUM HYPOCHLORITE	S	U	S	S	M	S	S	M	M	M	/	S	M	M	/	S	/	M	/	S	S	S	S	/	U	M	
	KEROSENE	S	U	S	S	U	S	S	M	M	M	/	S	M	M	U	S	U	/	/	/	S	S	S	/	S	S	
	SODIUM CHLORIDE (10%)	S	/	M	S	S	/	S	S	S	S	/	S	S	S	U	S	/	/	/	/	S	S	S	S	/	S	
	SODIUM CHLORIDE (sat'd)	S	/	M	S	S	/	S	/	S	S	/	S	S	S	U	S	/	/	/	/	S	S	S	S	/	S	
	CARBON TETRACHLORIDE	S	S	U	M	M	M	M	S	M	M	S	S	U	U	U	S	U	U	U	S	U	U	U	S	U	U	
	AQUA REGIA	M	/	S	/	/	/	/	/	U	U	U	U	U	U	U	/	/	/	/	/	U	/	/	U	/	U	
	SOLUTION 555 (20%)	S	S	S	S	S	S	/	S	S	S	/	/	S	S	S	S	S	S	S	S	S	/	/	/	S	S	
	MAGNESIUM CHLORIDE	S	S	S	M	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	M	
	MERCAPTOACETIC ACID	S	S	S	S	U	S	M	S	U	U	S	/	U	U	U	U	S	M	S	/	S	M	S	/	U	U	
	METHYL ALCOHOL	U	M	S	M	S	S	S	S	S	S	S	M	U	U	U	S	S	S	S	S	M	S	S	U	S	S	
	METHYLENE CHLORIDE	U	S	U	M	S	S	U	U	U	M	U	U	U	U	U	U	U	U	U	S	S	S	S	U	U	U	
	METHYL ETHYL KETONE	S	U	S	S	S	S	U	U	S	S	U	U	U	S	U	S	U	U	U	S	M	S	S	U	S	S	
	METIZAMIDE™	M	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	S	S	S	S	/	S	M	
	LACTIC ACID (100%)	/	/	S	S	/	/	M	/	S	S	M	S	S	S	/	U	S	M	/	/	/	/	/	/	/	/	
	LACTIC ACID (20%)	/	/	S	S	M	S	M	S	S	S	S	S	S	S	/	M	S	M	/	/	/	/	/	/	/	/	
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																												
MATERIAL	CHEMICAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	/	S	/	M	S	M	M	S	S	U	S	S	M	S	U	/	M	S	/	/	S	/	U	S	/	S
N/BUTYL ALCOHOL		S	/	S	/	M	S	M	M	S	S	S	M	S	S	U	/	M	S	S	/	S	/	/	U	S	/	S
N/BUTYL PHTHALATE		S	U	S	M	M	S	U	S	U	U	/	M	U	U	U	S	U	U	S	S	S	S	S	/	U	S	S
N, N-DIMETHYLFORMAMIDE		S	S	S	S	M	S	U	S	S	S	/	U	U	S	U	S	S	S	S	S	S	M	S	U	S	S	S
SODIUM BORATE		M	S	S	M	S	S	S	S	S	S	/	S	S	S	S	U	S	S	S	S	S	S	S	S	S	M	U
SODIUM BROMIDE		U	S	S	M	S	S	S	S	S	S	/	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	M
SODIUM CARBONATE (2%)		M	S	S	S	S	S	S	S	S	S	S	/	U	S	S	S	S	S	S	S	S	S	S	S	S	U	M
SODIUM DODECYL SULFATE		S	S	S	S	S	S	S	S	S	S	S	/	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S
SODIUM HYPOCHLORITE (5%)		U	M	S	U	M	S	S	S	M	S	S	S	S	M	S	S	S	S	M	S	U	M	S	S	U	U	U
SODIUM IODIDE		M	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	/	S	/	S	S	M
SODIUM NITRATE		S	S	S	S	U	S	S	S	S	S	/	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S
SODIUM SULFATE		U	S	S	M	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	U
SODIUM SULFIDE		S	/	S	S	S	/	/	/	S	/	/	U	U	S	S	S	S	/	/	/	/	/	/	S	S	/	S
SODIUM SULFITE		S	S	S	S	S	S	S	S	S	S	/	M	S	S	S	S	S	S	S	M	S	S	S	/	S	S	S
NICKEL SALTS		U	S	S	M	S	S	S	S	S	S	/	S	S	S	S	/	/	S	S	S	/	S	S	S	S	S	S
OILS (PETROLEUM)		S	S	S	S	U	S	S	S	U	U	M	S	M	U	U	U	S	S	S	S	S	/	/	/	S	S	S
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																												
CHEMICAL	MATERIAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	M	S	S	/	S	S	S	/	M	U	S	S	S	S	U	S	S	S	S	M	S	/	/	S	/	S
OILS (Other)		S <td>M<td>S<th>S</th><th>/</th><th>S</th><th>S</th><th>/</th><th>M</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>/</th><th>/</th><th>/</th><th>S</th><th>/</th><th>S</th></td></td>	M <td>S<th>S</th><th>/</th><th>S</th><th>S</th><th>/</th><th>M</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>/</th><th>/</th><th>/</th><th>S</th><th>/</th><th>S</th></td>	S <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>/</th> <th>M</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>/</th> <th>/</th> <th>/</th> <th>S</th> <th>/</th> <th>S</th>	S	/	S	S	/	M	U	S	S	S	S	U	S	S	S	S	U	S	/	/	/	S	/	S
OLEIC ACID		M <th>M</th> <th>S</th> <th>U</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>/</th> <th>S</th>	M	S	U	M	S	S	S	S	S	S	S	S	S	M	S	S	U	S	U	U	S	S	S	U	/	S
OXALIC ACID		S <th>S</th> <th>M</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>U</th> <th>U</th>	S	M	U	S	S	S	S	S	S	S	S	U	S	U	S	S	S	S	S	U	S	S	S	M	U	U
PERCHLORIC ACID (10%)		S <th>/</th> <th>S</th> <th>/</th> <th>U</th> <th>S</th> <th>M</th> <th>/</th> <th>M</th> <th>M</th> <th>S</th> <th>U</th> <th>U</th> <th>M</th> <th>/</th> <th>U</th> <th>/</th> <th>M</th> <th>U</th> <th>/</th> <th>U</th> <th>U</th> <th>U</th> <th>/</th> <th>/</th> <th>U</th> <th>U</th>	/	S	/	U	S	M	/	M	M	S	U	U	M	/	U	/	M	U	/	U	U	U	/	/	U	U
PERCHLORIC ACID (70%)		S <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>M</th> <th>U</th> <th>S</th> <th>M</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>/</th> <th>M</th> <th>M</th> <th>S</th> <th>/</th> <th>U</th> <th>U</th> <th>U</th>	U	S	U	U	S	M	U	S	M	U	M	U	S	U	U	U	U	U	/	M	M	S	/	U	U	U
PHENOL (5%)		S <th>M</th> <th>M</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>/</th> <th>M</th> <th>U</th> <th>S</th> <th>/</th> <th>S</th> <th>U</th> <th>U</th>	M	M	U	U	S	U	U	M	U	S	U	U	S	U	U	M	U	S	/	M	U	S	/	S	U	U
PHENOL (50%)		S <th>M</th> <th>U</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>U</th> <th>U</th>	M	U	U	U	S	U	U	M	U	S	U	U	S	U	U	S	U	U	S	U	S	S	S	U	U	U
PHOSPHORIC ACID (10%)		S <th>S</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>U</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>U</th> <th>U</th>	S	U	M	U	S	S	S	S	S	S	S	S	S	/	U	U	S	S	S	U	S	S	S	M	U	U
PHOSPHORIC ACID (conc.)		S <th>/</th> <th>U</th> <th>M</th> <th>U</th> <th>S</th> <th>M</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>M</th> <th>U</th> <th>U</th> <th>S</th> <th>M</th> <th>U</th> <th>S</th> <th>/</th> <th>/</th> <th>/</th> <th>M</th> <th>M</th> <th>U</th> <th>U</th>	/	U	M	U	S	M	S	M	S	S	S	M	M	U	U	S	M	U	S	/	/	/	M	M	U	U
PHYSIOLOGIC MEDIA (SERUM, URINE)		S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>/</th> <th>/</th> <th>S</th> <th>S</th> <th>M</th> <th>M</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	/	/	S	S	M	M
PICRIC ACID		S <th>M</th> <th>S</th> <th>M</th> <th>U</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>U</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th>	M	S	M	U	S	U	S	S	S	S	U	S	S	S	U	S	M	S	S	S	M	U	/	S	S	S
PYRIDINE (50%)		U <th>U</th> <th>U</th> <th>U</th> <th>S</th> <th>S</th> <th>U</th> <th>M</th> <th>S</th> <th>U</th> <th>/</th> <th>U</th> <th>U</th> <th>M</th> <th>U</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th>	U	U	U	S	S	U	M	S	U	/	U	U	M	U	U	S	S	S	U	U	U	S	U	S	U	U
RUBIDIUM BROMIDE		M <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>M</th> <th>M</th>	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	M	M
RUBIDIUM CHLORIDE		M <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>M</th> <th>M</th>	S	S	M	S	S	S	S	S	S	/	/	S	S	S	S	S	S	S	/	S	S	S	/	S	M	M
SUCROSE		M <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																												
MATERIAL	CHEMICAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	S	S	M	S	S	S	S	/	S	S	S	S	U	S	S	S	S	S	/	S	S	S	/	S	S	M
	SUCROSE, ALKALINE	S	S	S	U	S	S	S	/	S	S	S	S	U	S	S	S	S	S	S	/	S	S	S	S	S	S	U
	SULFOSALICYLIC ACID	S	S	S	U	S	S	S	S	S	S	S	S	U	S	S	U	U	S	U	/	S	S	S	S	S	U	U
	NITRIC ACID (10%)	S	S	S	S	M	S	S	S	M	M	U	U	M	M	U	U	U	U	U	/	U	U	U	U	U	/	U
	NITRIC ACID (50%)	S	M	S	S	U	S	U	S	M	U	U	U	U	M	U	U	U	U	U	/	U	U	U	U	U	/	U
	NITRIC ACID (95%)	S	/	S	S	U	S	U	S	M	U	U	U	U	M	U	U	U	U	U	/	U	U	U	U	U	/	U
	HYDROCHLORIC ACID (10%)	S	S	M	U	S	S	S	S	S	S	S	S	U	S	U	U	S	S	S	/	U	U	S	S	M	U	U
	HYDROCHLORIC ACID (50%)	M	M	U	U	M	S	M	S	S	S	S	U	U	M	U	U	U	M	S	/	U	U	U	U	U	U	U
	SULFURIC ACID (10%)	S	S	U	U	U	S	S	S	S	S	S	S	S	S	S	U	U	M	S	/	U	U	U	U	U	U	M
	SULFURIC ACID (50%)	S	M	U	U	U	S	S	S	S	S	M	U	U	S	U	U	U	M	S	/	U	U	U	U	U	U	M
	SULFURIC ACID (CONC.)	S	/	U	U	U	S	M	U	S	M	U	U	U	S	U	U	U	M	/	M	M	U	/	U	U	U	M
	STEARIC ACID	S	S	S	M	M	S	S	S	S	S	S	S	S	S	S	/	S	S	S	S	S	/	U	U	S	S	S
	TETRAHYDROFURAN	S	U	S	S	U	S	U	U	U	U	M	/	U	U	U	S	U	U	U	M	U	U	U	U	S	S	S
	TOLUENE	S	U	U	S	U	S	U	U	U	M	U	/	U	U	U	S	U	U	U	U	M	S	S	U	S	S	S
	TRICHLOROACETIC ACID	U	M	U	U	U	S	U	U	S	S	M	/	M	S	U	U	S	U	U	M	U	S	S	/	U	U	U
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

Chemical Compatibility																												
CHEMICAL	MATERIAL	Viton™	Tygon™	Titanium	Stainless Steel	Silicone Rubber	Rulon A™, Teflon™	Polyvynil Chloride	Polysulfone	Polypropylene	Polyethylene	Polythermide	Polyester, Glass Thermoset	Polycarbonate	Polyallomer	PET ¹ , Polyclear™,Clear Crimp™	Nylon	Noryl™	Neoprene	Glass	EPDM rubber	Delrin™	Composite Carbon Fiber/Epoxy	Polyurethane Rotor Paint	Cellulose Acetate Butyrate	Buna N	Anodic Coating for Aluminum	Aluminium
		S	/	S	/	U	S	S	/	S	S	S	S	S	M	S	S	S	/	S	/	M	/	S	/	U	S	S
TRICHLOROETHANE		S	/	S	/	U	S	U	U	U	U	U	U	U	U	U	S	/	U	U	U	M	/	/	/	U	/	S
TRICHLOROETHYLENE		/	/	U	/	U	S	U	U	U	U	U	U	U	U	U	S	/	U	U	U	/	/	/	U	U	/	S
TRISODIUM PHOSPHATE		/	/	S	/	/	S	/	/	S	S	S	/	/	S	/	/	/	/	/	/	M	/	/	S	S	/	S
TRIS BUFFER (NEUTRAL pH)		U	S <td>S<td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th></td></td>	S <td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th></td>	S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	S	S	S	S	U
TRITON X/100™		S	S <td>S<td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>/</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th></td></td>	S <td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>/</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th></td>	S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	/	S	S	S	S	S	/	S
UREA		S	/	S <td>M<th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>S</th><th>U</th><th>M</th><th>S</th><th>S</th><th>S</th><th>U</th><th>/</th><th>S</th><th>/</th><th>/</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th></td>	M <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>U</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>/</th> <th>S</th> <th>/</th> <th>/</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th>	S	S	S	/	S	S	U	M	S	S	S	U	/	S	/	/	U	S	S	S	S	S	S
HYDROGEN PEROXIDE (10%)		U	U <td>S<td>M<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>M</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>/</th><th>U</th><th>U</th><th>U</th><th>S</th><th>U</th><th>U</th><th>U</th></td></td>	S <td>M<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>M</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>/</th><th>U</th><th>U</th><th>U</th><th>S</th><th>U</th><th>U</th><th>U</th></td>	M <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>U</th> <th>U</th> <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>U</th>	S	S	S	S	S	S	U	M	S	S	S	U	S	S	S	/	U	U	U	S	U	U	U
HYDROGEN PEROXIDE (3%)		S	S <td>S<td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>/</th><th>S</th><th>S</th><th>M</th><th>M</th><th>S</th></td></td>	S <td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>/</th><th>S</th><th>S</th><th>M</th><th>M</th><th>S</th></td>	S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>M</th> <th>M</th> <th>S</th>	S	S	S	S	S	S	M	S	S	S	S	S	S	S	S	/	S	/	S	S	M	M	S
XYLENE		S	U <td>S<td>M<th>U</th><th>S</th><th>U</th><th>U</th><th>U</th><th>M</th><th>U</th><th>M</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th></td></td>	S <td>M<th>U</th><th>S</th><th>U</th><th>U</th><th>U</th><th>M</th><th>U</th><th>M</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>U</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th></td>	M <th>U</th> <th>S</th> <th>U</th> <th>U</th> <th>U</th> <th>M</th> <th>U</th> <th>M</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>U</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th>	U	S	U	U	U	M	U	M	U	U	U	U	U	U	U	U	M	S	S	S	S	S	S
ZINC CHLORIDE		U	S <td>S<td>U<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>U</th></td></td>	S <td>U<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>S</th><th>S</th><th>S</th><th>S</th><th>U</th><th>U</th></td>	U <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>U</th> <th>U</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	U	S	S	S	S	U	U
ZINC SULFATE		U	S <td>S<td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>S</th><th>U</th></td></td>	S <td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>/</th><th>S</th><th>S</th><th>U</th></td>	S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>/</th> <th>S</th> <th>S</th> <th>U</th>	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	/	S	S	U
CITRIC ACID (10%)		M	S <td>S<td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>M</th></td></td>	S <td>S<th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>M</th><th>S</th><th>S</th><th>M</th></td>	S <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>M</th> <th>S</th> <th>S</th> <th>M</th>	S	S	S	S	S	S	M	S	S	S	S	S	S	S	S	S	M	S	S	M	S	S	M
S		Satisfactory																										
M		Moderate attack, may be satisfactory for use in centrifuge depending on length of exposure, speed involved, etc.; suggest testing under actual conditions of use																										
U		Unsatisfactory, not recommended																										
/		Performance unknown; suggest testing, using sample to avoid loss of valuable material																										

¹ Polyethyleneterephthalate

NOTICE Chemical resistance data is included only as a guide to product use. Because no organized chemical compatibility data exists for materials under the stress of centrifugation, when in doubt we recommend pretesting sample lots.

Index

Symbole

8 x 50 mL Sealed B-20

A

Acceleration and Deceleration Profiles 2-11, 3-9

Acceleration Profile 4-3

Access Control 3-32

Advanced Program Settings 3-22

Aerosol-Tightness

Basic Principles 2-13

Fill Level 2-13

Aerosol-Tight Rotor Buckets 2-13

Aerosol-Tight Rotor Lids 2-13

Alarms 3-17, 3-29

Alarm Tone 3-30

Alarm Volume 3-29

Alert Option Checkboxes 3-32

Alerts 3-15, 3-31

Alert Tone 3-31

Alert Volume 3-31

Autoclaving 5-5

Auto Date/Time 3-42

Automate Processes Using Programs 3-20

B

Balanced Loading 2-7

Basics 5-1

Before loading a Rotor 2-8

BIOShield 1000A B-16

Brightness 3-41

C

Centrifugation 2-12, 3-12

Centrifugation (LCD Models) 4-6

Changing the Admin Passcode 3-33

Changing User Passcodes 3-34

Chart 3-48

Checking the Aerosol-Tightness 2-14

Chemical Compatibility C-1

Cleaning 5-2

Cleaning Intervals 5-1

CLINIConic B-18

Compressor Off 3-38

Continuous Mode Operation 4-6

Control Panel 3-5

Controls 3-34

Correct Loading 2-8

Cycles of Rotors and Buckets 5-2

D

Date 3-42

Deceleration Profiles (LCD Models) 4-4

Decontamination 5-4

Deleting a Program 3-24

Deleting a Rotor from the Log 3-47

Directives, Standards and Guidelines A-4

Disinfection 5-4

Display 3-41

Disposal 5-6

E

Editing Program Parameters 3-23

Ethernet 1-12

Event Log 3-45

Exporting Chart Data 3-49

Exporting Programs 3-26

Exporting the Event Log 3-46

Exporting the Rotor Log 3-47

F

Fiberlite F10-6 x 100 LEX B-51

Fiberlite F13-14 x 50cy B-37

Fiberlite F14-6 x 250 LE B-39

Fiberlite F15-6 x 100y B-41

Fiberlite F15-8 x 50cy B-44

Fiberlite F21-48 x 2 B-46

Fiberlite H3-LV B-49

Files and Info 3-50

G

Graphical User Interface 3-1

Overview 3-1

H

Handling Error Messages 4-7

H-FLEX 1 B-9

H-FLEX HS4 B-9

High and Low Temperature Alarms 3-30

HIGHConic II B-22

HIGHPlate 6000 B-11

Home Screen 3-3

How to Install and Remove a Rotor 2-5

I

Ice Formation 6-2

Identify Rotor and Buckets 2-10

Importing Programs 3-27

Incorrect Loading 2-8

Info & Health Status Area 3-2

Information about my Centrifuge v

Information for the Customer Service 6-3

Initial Startup 1-12

Install and Remove a Rotor 2-5

Intended Use v

Intended Use for IVD Centrifuges v

Intended Use for Laboratory Use Centrifuges v

Intended User vi

Items Supplied v, 1-1

L

Language 3-42

LCD Control Panel 4-1

Overview 4-1

Lid Auto Open 3-37

Load the Rotor 2-7

Location 1-1

Logs 3-44

M

M-20 Microplate B-13

Mains Connection 1-12
Main Screen 3-2
Mains Supply A-6
Maintenance and Care 5-1
Maximum Loading 2-9
Mechanical Emergency Door Release 6-1
Metal Parts 5-1
MicroClick 18 x 5 B-34
MicroClick 30 x 2 B-31
Microliter 30 x 2 B-25
Microliter 48 x 2 B-28

N

Navigation Bar 3-5

O

Open/Close the Centrifuge Lid 2-4
Operation 2-1

P

Plastic Parts 5-2
Position of parts 2-1
Power on/off the Centrifuge 2-4
Preface v
Pre-Temper the Centrifugation Chamber 2-11, 3-11
Pre-Temper the Centrifugation Chamber (LCD Models) 4-4
Previewing Program Parameters 3-23
Product Overview 1-7
Program Mode Operation 4-7
Programs 4-6
Pulse Customization 3-37

R

Refrigerants A-5
Region 3-43
Resetting the Rotor Counter 3-47
Rotor and Accessories Inspection 5-1
Rotor Bucket 3-40
Rotor Log 3-47
Rotor Program A-7
Rotors for Laboratory Use Centrifuges A-7
Rotor Specifications B-1
RS232 1-12
Run in Continuous or Timed Mode 3-12
Run in Pulse Mode 3-13
Running a Program 3-25

S

Safety Instructions viii
Scheduling 3-38
Select the Bucket Type 4-5
Service 3-50, 5-5
Set Basic Centrifugation Parameters 2-11, 3-6
Set Basic Centrifugation Parameters (LCD Models) 4-2
Setpoints 3-34
Setpoints Mode 3-36
Set Run Time 2-11, 3-8, 4-3
Set Speed / RCF-Value 2-11, 3-6, 4-2
Set Temperature 2-11, 3-10

Set Temperature (LCD Models) 4-5
Settings 3-29
Settings Screen 3-4
Setting Up and Saving a Program 3-20
Setting Up and Saving a Program (LCD Models) 4-6
Sharing Programs between Centrifuges 3-25
Shipping 5-6
Signal Words and Symbols vii
Slide Coated Rotors 5-1
Snooze Timeout 3-30
Status 3-14
Stop an Ongoing Centrifugation Run 4-7
Storage 5-6
Switching to Secure Mode 3-33
Symbols used in the Instructions for Use vii
Symbols used on Unit and Accessories vii
System Menu 4-8

T

Technical Specifications A-1
Time 3-43
Timed Mode Operation 4-7
Touchscreen 5-3
Transport and Set Up 1-1
Transporting 1-2
Troubleshooting 6-1
Troubleshooting by Guide 6-2
TX-750 B-2
TX-1000 B-7

U

Unit Name 3-44
Unpacking 1-1
USB 1-12
Use of Tubes and Consumables 2-10

V

Ventilation Grid 5-3
Viewing and Handling Alarms 3-18
Viewing and Handling Alerts 3-16
Viewing Charts 3-48
Viewing Events 3-45
View Time As 3-37

List of Figures

Figure 1-1: Safety Zone	1-2
Figure 1-2: Lifting the Tabletop Centrifuge at Both Sides	1-2
Figure 1-3: Space Required for Unloading	1-3
Figure 1-4: Removing the Outer Strapping and Packaging	1-3
Figure 1-5: Removing the Inner Strapping and Cardboard Protectors	1-4
Figure 1-6: Removing the Stops from the Pallet	1-4
Figure 1-7: Mounting the Rails for Unloading	1-5
Figure 1-8: Rolling the Centrifuge off the Pallet	1-5
Figure 1-9: Locking the Centrifuge Castors	1-6
Figure 1-10: Product overview — refrigerated 4 L benchtop centrifuge with GUI	1-7
Figure 1-11: Product overview — refrigerated 4 L benchtop centrifuge with LCD control panel	1-7
Figure 1-12: Product overview — ventilated 4 L benchtop centrifuge with GUI	1-8
Figure 1-13: Product overview — ventilated 4 L benchtop centrifuge with LCD control panel	1-8
Figure 1-14: Product overview — Refrigerated 4 L floorstanding centrifuge with GUI	1-9
Figure 1-15: Product overview — Refrigerated 4 L floorstanding centrifuge with LCD control panel	1-10
Figure 2-1: Position of centrifuge parts shown on a ventilated centrifuge with LCD control panel	2-1
Figure 2-2: Position of rotor parts shown on a fixed angle rotor	2-1
Figure 2-3: Position of the slot in the bucket and the corresponding adapter key	2-2
Figure 2-4: Position of rotor parts shown on a swinging bucket rotor	2-2
Figure 2-5: Position of rotor parts shown on a windshielded swinging bucket rotor	2-3
Figure 2-6: Rear view of ventilated benchtop centrifuges, position of the mains switch	2-4
Figure 2-7: Side view of refrigerated benchtop centrifuge, position of the mains switch	2-4
Figure 2-8: Side view of floorstand centrifuge, position of the mains switch	2-4
Figure 2-9: Put on/off the rotor lid	2-5
Figure 2-10: Turn the rotor knob	2-6
Figure 2-11: Pressing the Auto-Lock key	2-6
Figure 2-12: Auto-Lock on the drive shaft	2-7
Figure 2-13: Slot and Key on Paired Buckets and Rotors	2-7
Figure 2-14: Correct loading examples for fixed angle rotors	2-8
Figure 2-15: Correct loading examples for swinging bucket rotors	2-8
Figure 2-16: Incorrect loading examples for fixed angle rotors	2-8
Figure 2-17: Incorrect loading examples for swinging bucket rotors	2-8
Figure 2-18: Rotor Detection: Choosing a Bucket Type for a TX-750 Rotor	2-10
Figure 2-19: Setting the Correct Bucket Code	2-11
Figure 2-20: Lid of an aerosol-tight rotor with mandrel	2-13
Figure 2-21: Bucket with open lid (left) and closed lid (right)	2-14
Figure 3-1: Screen Areas	3-1
Figure 3-2: Touchscreen Display for Ventilated Centrifuge	3-1
Figure 3-3: Touchscreen Display for Refrigerated Centrifuge	3-2
Figure 3-4: Info & Health Status Area	3-2
Figure 3-5: Home Screen for Idle Centrifuge	3-3
Figure 3-6: Home Screen for Running Centrifuge, Ventilated Models	3-3
Figure 3-7: Home Screen for Running Centrifuge, Refrigerated Models	3-3
Figure 3-8: Settings Main Screen	3-4
Figure 3-9: Control Panel for Ventilated Centrifuge	3-5
Figure 3-10: Control Panel for Refrigerated Centrifuge	3-5
Figure 3-11: Navigation bar	3-6
Figure 3-12: Speed Box on Home Screen	3-7
Figure 3-13: Setpoints: Standard Screen for Refrigerated Centrifuge	3-7
Figure 3-14: Settings -> Controls -> Setpoints: Advanced Screen for Ventilated Centrifuge	3-7

Figure 3–15: Setpoints Screen Detail for Centrifuge Speed, and Range	3-8
Figure 3–16: Settings -> Controls -> Setpoints Screen: Out of Range Value Alert	3-8
Figure 3–17: Invalid Rotor Speed Pop-up Window)	3-8
Figure 3–18: Run Time Box on Home Screen	3-8
Figure 3–19: Run Time Box on Home Screen	3-9
Figure 3–20: Acceleration / Deceleration Profile Box on Home Screen	3-9
Figure 3–21: Temperature Box on Home Screen	3-10
Figure 3–22: Temperature Box on Home Screen	3-11
Figure 3–23: Pre-Temp Complete Pop-up Window	3-11
Figure 3–24: Screen in Lighthouse Mode	3-12
Figure 3–25: Pulse Mode: Centrifuge Running for One Minute	3-13
Figure 3–26: Status Screen	3-14
Figure 3–27: Rotor End of Life Alert Message on Top of Home Screen	3-15
Figure 3–28: Home Screen with Alert Message	3-15
Figure 3–29: Status – Alert Screen with Alert List	3-16
Figure 3–30: Status – Alert Screen: Operating Details Expanded	3-16
Figure 3–31: Alarm Message on Top of Home Screen	3-17
Figure 3–32: Alarm Message after Snoozing	3-17
Figure 3–33: Full Screen Alarm Message	3-18
Figure 3–34: Status – Alarm Screen with Rotor Imbalance Message	3-18
Figure 3–35: Status – Alarm Screen: Operating Details Expanded	3-19
Figure 3–36: Status – Screen	3-19
Figure 3–37: Pristine Programs Screen (Prior to Creating Programs)	3-20
Figure 3–38: Programs -> Add New Program Screen, First Set of Options	3-20
Figure 3–39: Programs with Keypad Overlay	3-21
Figure 3–40: Programs -> Add New Program Screen, Second Set of Options	3-21
Figure 3–41: Programs -> Add New Program Screen, Speed and Time for Step 1	3-22
Figure 3–42: Programs -> Advanced Settings Screen	3-22
Figure 3–43: Programs -> Program Quick View Pop-up Window	3-23
Figure 3–44: Programs -> Edit Program Screen	3-23
Figure 3–45: Programs -> Delete Confirm Window for Program Step)	3-24
Figure 3–46: Programs -> Delete Confirm Window for Program	3-24
Figure 3–47: Programs Screen with Pre-Stored User Programs	3-25
Figure 3–48: Programs -> Export Programs Screen	3-26
Figure 3–49: Programs -> Import Programs Screen	3-26
Figure 3–50: Programs -> Export Programs Pop-up Window with Progress Bar	3-27
Figure 3–51: Programs -> Export Complete Pop-up Window	3-27
Figure 3–52: Programs -> Import Programs Pop-up Window with Progress Bar	3-28
Figure 3–53: Programs -> Import Complete Pop-up Window	3-28
Figure 3–54: Settings Main Screen	3-29
Figure 3–55: Alarms Settings -> Alarm Volume Slider	3-29
Figure 3–56: Settings -> Alerts Screen	3-31
Figure 3–57: Alerts Settings -> Alert Volume Slider	3-31
Figure 3–58: Settings -> Access Control Screen	3-32
Figure 3–59: Settings -> Access Control: Access Control Screen in Secure Mode	3-34
Figure 3–60: Settings -> Controls -> Setpoints: Standard Screen for Refrigerated Centrifuge	3-35
Figure 3–61: Settings -> Controls -> Setpoints: Advanced Screen for Ventilated Centrifuge	3-36
Figure 3–62: Settings -> Controls -> Setpoints Screen: Out of Range Value Alert	3-36
Figure 3–63: Settings -> Scheduling -Screen with All Schedules Disabled	3-40
Figure 3–64: Settings -> Display Screen	3-41
Figure 3–65: Settings -> Display Screen -> Brightness	3-41
Figure 3–66: Logs Main Screen	3-44

Figure 3-67: Event Log Screen	3-45
Figure 3-68: Event Log Screen with Event Expanded	3-45
Figure 3-69: Rotor Log Screen	3-47
Figure 3-70: Chart Screen	3-48
Figure 3-71: Chart Details Screen	3-49
Figure 3-72: Files and Info Screen	3-50
Figure 4-1: Functions on the LCD Control Panel	4-1
Figure 4-2: Choosing between RCF / rpm and setting the Centrifuge Speed	4-2
Figure 4-3: Setting the Centrifuge Run Time	4-3
Figure 4-4: Setting the Acceleration Profile	4-3
Figure 4-5: Setting the Deceleration Profile	4-4
Figure 4-6: Setting the Pre-cooling or Pre-warming Temperature (left)	4-4
Figure 4-7: Setting the Temperature for the Centrifugation Run (right)	4-5
Figure 4-8: Setting the Correct Bucket Code for the Rotor	4-5
Figure 5-1: Removing the ventilation grid	5-3
Figure 6-1: Emergency door release on the back side	6-1

List of Tables

Table i: List of Thermo Scientific Centrifuges	vi
Table ii: Signal Words and Symbols	vii
Table iii: Symbols Used on the Unit and Its Accessories	viii
Table iv: Symbols used in the Instructions for Use	ix
Table 1-1: Items Supplied	1-1
Table 3-1: Navigation bar icons	3-6
Table 3-2: Passcode Login Requirements in Open and Secure Mode	3-33
Table 3-3: Settings -> Controls Settings -> Setpoints Screen Items Explained	3-35
Table 6-1: Error Messages	6-3
Table A-1: Technical Data – Thermo Scientific S4T / X4T Benchtop Ventilated Centrifuges	A-1
Table A-2: Technical Data – Thermo Scientific S4T / X4T Benchtop Ventilated Centrifuges	A-2
Table A-3: Technical Data – Thermo Scientific S4FR / X4FR Floor Standing Refrigerated Centrifuges	A-3
Table A-4: Directives and Standards for S/X IVD-MD Series Centrifuges	A-4
Table A-5: Directives and Standards for S/X Series Centrifuges	A-5
Table A-6: Refrigerants Used for S Series and X Series Centrifuges	A-6
Table A-7: Electrical Connection Data for Used for S Series and X Series Centrifuges	A-7
Table A-8: Rotor Program	A-8
Table A-9: Connectivity Options	A-8



Thermo Electron LED GmbH
Zweigniederlassung Osterode
Am Kalkberg, 37520 Osterode am Harz
Germany

UK
CA

CE

IVD

thermofisher.com/centrifuge

© 2025–2026 Thermo Fisher Scientific Inc. All rights reserved.
All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries unless otherwise indicated.

Delrin is a registered trademark of Dupont Polymers, Inc. TEFLON and Viton are registered trademarks of The Chemours Company FC. Noryl and Valox are registered trademarks of Sabic Global Technologies. POLYCLEAR is a registered trademark of Hongye CO., Ltd. Hypaque is a registered trademark of Amersham Health AS. RULON A and Tygon are registered trademarks of Saint-Gobain Performance Plastics. Alconox is a registered trademark of Alconox, Inc. Ficoll is a registered trademark of Cytiva Sweden AB. Haemo-Sol is a registered trademark of Haemo-Sol International, LLC. Triton is a registered trademark of Union Carbide Corporation.

Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

Shown pictures within the manual are examples and may differ considering the set parameters and language. Pictures of the user interface within the manual are showing the English version as example.

Australia +61 39757 4300

Austria +43 1 801 40 0

Belgium +32 9 272 54 82

China +800 810 5118, +400 650 5118

France +33 2 2803 2180

Germany national toll free
0800 1 536 376

Germany international +49 6184 90 6000

India toll free +1800 22 8374

India +91 22 6716 2200

Italy +39 02 95059 552

Japan +81 3 5826 1616

Korea +82 2 2023 0600

Netherlands +31 76 579 55 55

New Zealand +64 9 980 6700

Nordic/Baltic/CIS countries
+358 10 329 2200

Russia +7 812 703 42 15, +7 495 739 76 41

Singapore +82 2 3420 8700

Spain/Portugal +34 93 223 09 18

Switzerland +41 44 454 12 12

UK/Ireland +44 870 609 9203

USA/Canada +1 866 984 3766

Other Asian Countries +852 3107 7600

Countries not listed +49 6184 90 6000

en

