CERTIFICATE OF CALIBRATION

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD

DATE OF ISSUE: 23 October 2023 CERTIFICATE NUMBER: 1151580





0654



Unit 5 Octavian Way Team Valley Trading Estate Gateshead **NE11 0HZ**

Tel: +44 (0)191 4875951

Page 1 of 3							
Approved Signatory							
Electronically A	authorised Document						
P K CLARK	☐ J FRYER						
RJWADE	☐ M FOY						
M A FROST							
I M S PARDOF							

CUSTOMER

DJB LABCARE LTD **UNIT 12 HOWARD WAY** CROMWELL BUSINESS CENTRE **NEWPORT PAGNELL** BUCKINGHAMSHIRE **MK16 9QS** UNITED KINGDOM

STANDARD MANUFACTURER

DESCRIPTION TACHOMETER OPTICAL

AT-6 **MODEL**

SERIAL No. 200552135

IDENT No. UNKNOWN

DATE RECEIVED 19 OCTOBER 2023

DATE OF CALIBRATION 23 OCTOBER 2023

ORDER No. NS23560

INSTRUMENT CONDITION

Adjustments Made No Repairs Made No

ENVIRONMENT

The instrument was placed in the Laboratory environment for a minimum period of 4 hours prior to calibration.

The ambient conditions were: 18 to 23°C and 45 %rh ± 15 %rh.

STABILITY

The results contained in this Certificate refer to the measurements made at the time of test and not to the instrument's ability to maintain calibration.

PROCEDURE

Measurements were performed in accordance with the in house Laboratory procedure No.1053

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k = 2, providing a coverage probability of approximately 95 %. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

CERTIFICATE OF CALIBRATION

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD



CERTIFICATE NUMBER

1151580

Page 2 of 3

UKAS ACCREDITED CALIBRATION LABORATORY No. 0654

Calibration Equipn	Test Equipment			
Cert Number	Ident Number	Model	Serial Number	Calibration Due
1150572IH	143	33220A	MY44025316	28 Sep 2024
1149140IH	475	A002206.G1	13572091	4 Sep 2024

Notes:

Results relate only to the items calibrated.

CERTIFICATE OF CALIBRATION

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD



UKAS ACCREDITED CALIBRATION LABORATORY No. 0654

RESULT SHEET 1053-NC-UKAS: STANDARD AT-6 OPTICAL TACHOMETER

AS FOUND

BATTERY REPLACED: NO

The Revolution Per Minute (RPM) was simulated using a precision Frequency Generator with an attached optical light source.

RPM

Range	Simulated	Indicated	Units	Indicated Deviation	Measurement Uncertainty ±
2 to	600.000	600.0	RPM	0.000	0.064
99999RPM	1000.00	1000	RPM	0.00	0.58
	2500.00	2500	RPM	0.00	0.58
	5000.00	5000	RPM	0.00	0.58
	7499.96	7500	RPM	0.04	0.58
	9999.80	10000	RPM	0.20	0.58
	14999.46	15000	RPM	0.54	0.58
	19999.13	20000	RPM	0.87	0.58
	24998.71	25000	RPM	1.29	0.58
	29998.40	30000	RPM	1.60	0.58

Manufacturer stated Accuracy: ±(0.05%+1 digit)

COMMENTS:

TEST ENGINEER: M Foy DATE: 23rd October 2023

Issue No 1 Page 3 of 3