CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

DATE OF ISSUE: 27 February 2023 CERTIFICATE No: 763591





Lambda

Units 11 - 13 Chorley Central Business Park Stump Lane, Chorley Lancashire PR6 0BL Tel: 01257 244670 Page 1 of 3

APPROVED SIGNATORY

C Reed E Santos R Armitage K Quigley D Pilkington

Customer:

DJB Labcare Ltd

Address:

Unit 12, Cromwell Business Centre Newport Pagnell, Buckinghamshire

.....poze zagnoża, bac

Item Number:

13070033 (4046)

Description:

Digital Thermometer

Model/Range:

TMD-56

MK16 9QS

Manufacturer:

Amprobe

Date of Cal:

27 Feb 2023

Calibrated by:

Gabor Szabo

Procedure Name:

Amprobe, Digital Thermometer, TMD-56 (DJB Labcare)

Rev/Basis:

05:E-650, Based on BS EN 60584.1

Temp/Humidity:

20.0°C ± 2°C <80%rh

The Results on the following pages are: As Found All Measurements are Traceable to National Standards.

Note 1: The unit under test was calibrated using a multifunction calibrator.

Note 2: Where the reported value lies within the specified tolerance then this will be indicated by the word "PASS", if outside then by the word "FAIL".

Note 3: Any supplied test leads have been checked as part of the Visual/Operational test but have not been used during calibration.

Note 4: Temperature indicating instruments that contain an internal reference junction for use with thermocouples are calibrated with the reference junction enabled. Note 5: Unless otherwise stated, the device has been calibrated with its protective cover removed (if a cover was fitted) and was powered by battery (if applicable).

Engineers' Notes:

Equipment Used:

Multi-function Calibrator: LMMC-02 / LMMC-04 / LMMC-10 / LMMC-14

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a coverage probability of approximately 95%. The uncertainty evaluation has been carried out in accordance with UKAS requirements. Unless otherwise stated: [1] The 'Compliance Statement' is based on 'simple acceptance' (result vs tolerance) with the relevant calibration uncertainty being no greater than the tolerance. [2] Reported activities were carried out at the address detailed in the header. [3] The results relate only to the items calibrated. This certificate is issued in accordance with the laboratory accreditation requirements of the United Kingdom Accreditation Service. It provides traceability of measurement to the SI system of units and / or to units of measurement realised at the National Physical Laboratory or other recognised national metrology institutes. This certificate may not be reproduced other than in full, except with the prior written approval of the issuing laboratory.

CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495

CERTIFICATE No: 763591

Page 2 of 3

Date of Issue: 27 February 2023

Parameter	UUT Range	UUT Indicated Value	Applied Value	Acceptance Low	e Limits High	Summary
Visual/Opera Result of	tional Test Operator E					PASS
Measurement	of Thermoco	ouples (Electrical Sim	ulation)			
Channel T1						
Type T		-190.0°C -80.0°C -50.0°C -30.0°C -10.0°C 4.0°C 37.0°C 50.0°C 100.0°C 150.0°C 200.0°C 250.0°C 37.0°C 200.0°C	-190.2 -80.1 -50.1 -30.0 -10.0 -0.1 3.9 37.0 50.0 100.0 150.0 200.1 250.0 300.0 390.1	-190.8 -80.7 -50.7 -30.3 -10.3 -0.3 3.7 36.7 49.7 99.7 149.6 199.6 249.6 299.6 389.5	-189.2 -79.3 -49.3 -29.7 -9.7 0.3 4.3 37.3 50.3 100.3 150.4 200.4 250.4 300.4 390.5	PASS PASS PASS PASS PASS PASS PASS PASS
Type K		0.0°C 500.0°C 1000.0°C	100.1 0.0 500.0 999.9	99.3 -0.3 499.4 999.2	100.7 0.3 500.6 1000.8	PASS PASS PASS PASS
Type J Type E		20.0°C 1100.0°C	20.0 1100.1	19.7 1099.2	20.3 1100.8	PASS PASS
Type N		20.0°C 900.0°C	20.0 900.1	19.7 899.3	20.3 900.8	PASS PASS
Type R		20.0°C 1100.0°C	19.9 1100.2	19.6 1099.1	20.4 1101.0	PASS PASS
Type S		500°C 1100°C	500 1100	498 1097	502 1103	PASS PASS
		500°C 1100°C	500 1100	498 1097	502 1103	PASS PASS

CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495

CERTIFICATE No: 763591

Page 3 of 3

Parameter	UUT Range	UUT Indicated Value	Applied Value	Acceptanc Low	ce Limits High	Summary
Channel T2						
Type T						
		-190.0°C	-190.3	-190.8	-189.2	PASS
		-80.0°C	-80.2	-80.7	-79.3	PASS
		-50.0°C	-50.1	-50.7	-49.3	PASS
		-30.0°C	-30.1	-30.3	-29.7	PASS
		-10.0°C	-10.1	-10.3	-9.7	PASS
		0.0°C	-0.1	-0.3	0.3	PASS
		4.0°C	3.9	3.7	4.3	PASS
		37.0°C	36.9	36.7	37.3	PASS
		50.0°C	50.0	49.7	50.3	PASS
		100.0°C	100.0	99.7	100.3	PASS
		150.0°C	150.0	149.6	150.4	PASS
		200.0°C	200.0	199.6	200.4	PASS
		250.0°C	250.0	249.6	250.4	PASS
		300.0°C	300.0	299.6	300.4	PASS
		390.0°C	390.1	389.5	390.5	PASS
Elma V		100.0°F	100.1	99.3	100.7	PASS
Type K		0.0°C	0.0	0 0	0 0	
		500.0°C	0.0	-0.3	0.3	PASS
		1000.0°C	500.0	499.4	500.6	PASS
П		1000.0 C	1000.0	999.2	1000.8	PASS
Type J		20.0°C	00.0	10 =	^^ ^	
		1100.0°C	20.0 1100.1	19.7	20.3	PASS
Type E		1100.0 C	1100.1	1099.2	1100.8	PASS
TAbe F		20.0°C	20.0	19.7	20.3	DAGG
		900.0°C	900.1	899.3	900.8	PASS
Type N		900.0 C	300.1	099.3	900.0	PASS
13PC N		20.0°C	19.9	19.6	20.4	PASS
		1100.0°C	1100.2	1099.1	1101.0	PASS
Type R		1100.0 C	1100.2	1099.1	1101.0	rass
*1 P ~ 1/		500°C	500	498	502	PASS
		1100°C	1100	1097	1103	PASS
Type S		2200	1100	1.031	1100	radd
1350 0		500°C	500	498	502	DACC
		1100°C	1100	1097	1103	PASS PASS
		1.00	1100	1001	1100	rass

End of Calibration Data

Estimated Uncertainty of Measurement:

Electrical Measurement of Thermocouples

Type: B +500°C to +1820°C ±0.65°C

Type: C +0°C to +2320°C ±0.48°C

Type: E -200°C to +1000°C ±0.29°C

Type: J -210°C to +1200°C ±0.32°C

Type: K -200°C to -250°C ±0.67°C

Type: K -200°C to +1300°C ±0.34°C

Type: L -200°C to +900°C ±0.33°C

Type: N -200°C to -100°C ±0.40°C

Type: N -100°C to 1300°C ±0.31°C

Type: N -100°C to 1300°C ±0.31°C

Type: R +0°C to +1767°C ±0.61°C

Type: S +0°C to +1767°C ±0.58°C

Type: T -250°C to -200°C ±0.70°C

Type: T -200°C to +400°C ±0.34°C

(+0.5°C where UUT resolution is 1°C)