

# CERTIFICATE OF CALIBRATION

ISSUED BY: **M K I S** CALIBRATION COMPANY

DATE OF ISSUE: 10 March 2015

CERTIFICATE NUMBER: 2805




0236

## STANDARDS LABORATORY

Page 1 of 2 pages

# MKIS

10 Potters Lane  
Kiln Farm



Calibration Company

Milton Keynes  
MK11 3HE

Tel: 01908 568250  
Fax: 01908 564661

Approved  
Signatories

R Younger   
C Kemp

Signature

Equipment Description:	Digital Tachometer
Manufacturer:	Standard
Type:	AT-6
Serial Number:	12078446
Order Number:	20006
Customer:	D J B Labcare
Location:	Newport Pagnell
Date Received:	09 March 2015
Date Calibrated:	10 March 2015

The instrument was kept in the laboratory environment for 24 hours, to allow the instrument to stabilise, prior to the tests being carried out.

The ambient temperature and relative humidity throughout the test was  $20^{\circ}\text{C} \pm 2^{\circ}\text{C}$  and  $50\% \pm 20\%$  respectively.

The uncertainties reported refer to the applied and indicated values only with no account being taken of the instruments ability to maintain its calibration.

Remarks: No adjustments were made.

# CERTIFICATE OF CALIBRATION

UKAS Accredited Calibration Laboratory No. 0236

Certificate Number: 2805

PAGE 2 OF 2 PAGES

Applied Value	Equivalent Value	Indicated Value
99.999 ms	600.00 rpm	600.0 rpm
60.002 ms	999.97 rpm	1000 rpm
30.004 ms	1999.7 rpm	2000 rpm
15.003 ms	3999.2 rpm	3999 rpm
10.000 4 ms	5999.8 rpm	6000 rpm
6.000 08 ms	9 999.8 rpm	10 000 rpm
3.999 94 ms	15 000.2 rpm	15 000 rpm
2.999 96 ms	20 000.3 rpm	20 000 rpm
1.500 05 ms	39 998.7 rpm	39 999 rpm

The measurement uncertainties were:

RPM  $\pm 0.05$  RPM + 1 LSD

END

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor  $k = 2$ , providing a level of confidence of approximately 95%. The uncertainty evaluation has been carried out in accordance with UKAS requirements.